

# **FLI 425**

## **Forklift Scale Instrument**



## **User Instructions**

# Table of Contents

	<i>page</i>
<b>Chapter 1 Daily Operation Quick Reference</b> .....	5
<b>Chapter 2 General information and warnings</b> .....	6
About this manual .....	6
Text conventions .....	6
Special messages .....	6
Installation .....	7
Safe handling of equipment with batteries .....	7
Routine maintenance .....	7
Cleaning the machine .....	8
Training .....	8
Sharp objects .....	8
FCC and EMC declarations of compliance .....	8
<b>Chapter 3 Introduction</b> .....	11
Product Introduction .....	11
Front & Back Panels and Keys .....	11
Front Panel .....	11
Back Panel .....	12
Front Panel Keys .....	13
Display Symbols, Icons and Messages .....	13
Upon Power Up .....	15
To Power Off .....	16
Entering Alphanumeric Values .....	17
<b>Chapter 4 Operations in Standard Mode</b> .....	19
Start Up and Entering the Employee ID .....	19
Processing a PRO# .....	20
Stored Data / Out of Radio Range .....	21
Aborting a PRO# .....	21
<b>Chapter 5 Operations in Counting Mode</b> .....	22
Start Up and Entering the Employee ID .....	22
Performing a Counting Operation .....	23
Stored Data / Out of Radio Range .....	24
<b>Chapter 6 Operations in Checkweighing Mode</b> .....	26
Introduction .....	26
Checkweighing Setup .....	27
Setting Over/Under Values .....	27
Setting Target Weight with Tolerances .....	28
Typical Checkweighing Operation .....	28
Start Up and Entering the Operator ID .....	28
<b>Chapter 7 Calibration Validation</b> .....	30
Daily Validation Procedure .....	30
Accessing the Menu .....	30
<b>Chapter 8 Menu Access and Use</b> .....	33
Accessing the Menus and Modules .....	33
Overview of the Modules in the <i>User Management</i> Menu .....	35
<i>User Settings</i> Module .....	36
Date and Time .....	36

Display Contrast Control .....	37
Speaker Volume .....	37
External Keyboard Repeat .....	38
View Service Contact .....	38
Seal Switch .....	38
<i>About FLI 425</i> Module .....	39
<i>Audit Trail</i> Module .....	39
Print Output from Audit Trail Screen .....	41
<i>Database Viewer</i> Module .....	43
Print Output from Database Viewer .....	44
<i>Transaction Log Viewer</i> Module (EU only) .....	46
<i>DataManager Viewer</i> Module .....	47
<b>Chapter 9 Available Options .....</b>	<b>48</b>
FLW 100 Wireless Carriage .....	48
RM 100 FL Bluetooth® interface .....	49
Compact Flash® Wifi and Memory .....	49
RM 200 Radio .....	49
FLR 100 Remote Display Option .....	50
Bar Code Scanners .....	50
FLP 100 Power Conditioner .....	51
<b>Daily Inspection Checklist for Forklift Scale .....</b>	<b>52</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Weigh-Tronix/FLI-425 user manual.html](https://the-checkout-tech.com/manuals/Weigh-Tronix/FLI-425%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)