WEIGH-TRONIX



PC-810 Precision Counting Scale User's Manual

Table of Contents

YVNACS IN This Manual:
Keyboard and Display Panel
PC-810 Operation
Soft Key Definitions2
System (Hard) Key Definitions3
Weighing Operation4
Entering a Tare Value4
Clearing a Tare Value4
Use of Remote Base4
Accumulation5
Printing5
Changing Units of Measure5
Counting Operation6
Understanding the Part Information Scrolling Feature 6
Auto Base Switching (ABS)6
Using the X Key to Take a Quick Sample7
Choosing an Oddball Sample Size in Dribble Mode8
Choosing an Oddball Sample Size in Bulk Mode8
Retrieving a Known Piece Weight from Scale Memory 9
by the Part #9
by the PWLU #9
Direct Piece Weight Entry9
Serial Communication10
I/O Connector10
Computer and Bar Code Command Set
Scale Status Byte Definitions12
The TEST Key
The *MGR* (database) Menu
Using Bar Code Scanning with the PC-810
Appendix: Flowcharts
Normal Operation Menu Flowchart18
MGR (Database) Menu Flowchart20
Test Menu Flowchart22

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/Weigh-Tronix/PC-810 user manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM