


Avery Weigh-Tronix



PC-820/821 Parts Counter Service Manual

Table of Contents

Table of Contents	3
Specifications	4
Introduction	5
About This Manual	5
PC-820 Description	5
Front Panel Keys	6
Hard Keys	6
PC-820 Menus	6
Entering the Menu	7
Test Menu	7
Setup Menus	9
User Menu (password is 111)	9
Configuration Menu (password is 2045)	12
Calibration Menu (password is 30456)	20
Configuration of Remote 1 for Analog Scale Base	21
Calibration Error Messages	21
Serial Communication	22
Scale Status Byte Definition	24
Appendix A: Available PC-820 Displays	25
Appendix B: Tips on Using Harmonizer	27
Technical Drawings and Parts Lists	29-45
10 lb / 5 kg 12" x 14" Parts and Assembly	29
Draft Shield Parts and Assembly	30
50 lb / 25 kg and 100 lb / 50 kg 12" x 14" Parts and Assembly	31
System Wiring Block Diagram	32
Main Computer & I/O, Remote Analog, Internal Battery Charger PC Boards	33
Display & Interface Bd. Display Assembly, Keypad Assembly and Matrix	34
Internal Battery & Charger PC Board Parts and Assembly	35
Dimensional Outline for 12" x 14" Base	36
COM2 Interface Cable Options and Pin-outs	37
COM1 Interface Cables, 820 to Quartzell Base and 820 to Eltron Printer	
Cable Assemblies	38
BP-25R External Battery	39
Zeus Kits, Internal and External	40
SSCU Parts and Assembly	41
SSCU-8 Remote Expanded Control I/O Board	42
SSCU External (16) I/O Cutoff Expansion Board	43
Opto-22 Control Interface Devices	44
Wiring Diagram for Input and Output Modules	45

Pages are numbered consecutively beginning with the cover page.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*