

RD-125

Operations Guide

Introduction

This RD-125 Remote Display provides weight readings on its LCD display. Connected to a host indicator via RS-232 serial communications, the RD-125 mirrors the weight displayed on the host indicator. The RD-125 is available in a carbon steel or Lexan enclosure. It has annunciators which identify pound or kilogram units of measure, gross or net weights, and data reception. It is compatible with any device that transmits data in the same format as the following:

G<sp>+00000 <sp> LB<cr><lf>

<sp>=space <cr>= carriage return <lf>=line feed

Note: <ff> Form feeds are ignored

Protocol must match host device's baud rate, parity and stop bits.



Figure1
RD-125 Front Panel

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Weigh-Tronix/RD-125 operations guide manual.h](https://the-checkout-tech.com/manuals/Weigh-Tronix/RD-125%20operations%20guide%20manual.h)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)