

WEIGH-TRONIX



Model WI-120 Indicator User's Manual

TABLE OF CONTENTS

PART 1: INTRODUCTION TO THE WI-120 INDICATOR	1
DEFINITION AND OVERVIEW	1
SPECIFICATIONS FOR THE WI-120 INDICATOR	1
ENCLOSURES	2
FEATURES	3
System Support Features	3
Features Selectable Through Configuration Mode	3
Peripheral Printer or Computer Support Features	3
Optional Features	4
FRONT PANEL KEYBOARD FUNCTIONS	4
Keyboard Summary	4
Alphabetical Glossary of Key Functions	5
DISPLAY MESSAGES	6
PART II: OPERATING THE WI-120 INDICATOR	9
INITIAL OPERATING PROCEDURES	9
Setting the Operating Voltage	9
Powering-Up and Initializing	10
Accessing Configuration Mode and Viewing the Parameters	11
Applying Security Code for Tare and Cutoff Registers	13
Reading and Setting Time and Date	14
Enabling and Entering Identification Number	16
WEIGHING FUNCTIONS	17
Zeroing the Scale	17
Obtaining a Gross Weight Value	18
Using Pushbutton Tare Function to Store Container Weights	18
Using Keypad Multiple Tare Function to Store Container Weights	19
Entering Setpoints for Over/Under Indication	23
Entering Cutoff Values for Automated Scale Systems	24
Transmitting Data to Peripheral Devices	27

continued ...

PART III: CONFIGURING THE WI-120 INDICATOR	29
PLANNING PERIPHERAL DEVICES FOR TRANSMISSION OF DATA	29
ENABLING CONFIGURATION MODE	31
SELECTING OPTIONS FOR FUNCTION PARAMETERS	32
Security Code	33
Time/Date	35
Units of Measure	37
Scale Capacity Multiplier	38
Decimal Point Placement	38
Division Size	39
Display Rate	39
Digital Motion Stabilizer (DMS)	40
Blank Display During Motion	41
Digital or Analog Zero	41
Automatic Zero Tracking (AZT)	42
Motion Send Window	42
Auto-Send After Motion	43
USA or Canadian Compliance	44
Power-Up Display	45
Identification Number	45
BCD Error Message	46
BCD Computer Interface with or without Data-Inhibit Signal	47
Serial Communication Parameters for Printer Port A	48
Port A: Printer Control Codes Parameter	50
Page-Formatting Parameters for Printer Port A	57
Serial Communication Parameters for Computer / Programmable Controller Port B	62
Formatting Parameters for Computer / Programmable Controller Port B	65
LOCKING IN SELECTIONS AND DISABLING CONFIGURATION	67
Appendix A: Addendum to the WI-120 Indicator User's Manual	68

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*