



## WI-127 Inbound/Outbound User's Manual

# Table of Contents

Table of Contents .....	3
Specifications .....	4
Introduction .....	5
Operations Mode .....	5
Front Panel .....	6
Keys .....	6
Standard Scale Keys .....	6
Function Keys .....	7
Keypad Keys .....	7
Directional Keys .....	7
Annunciators .....	7
Gross Weighing .....	8
Method 1: Inbound/Outbound Weighing .....	8
Capturing an Inbound or Outbound Weight .....	8
Inbound/Outbound Shortcut .....	9
Printing a Report .....	9
Editing and Deleting Channels .....	9
Method 2: Multiple Tare Registers .....	10
Defining Tare Registers .....	10
Creating New Registers or Accessing Existing Registers .....	10
Entering and/or Editing Tare Register Values .....	10
Clearing/Deactivating Tare Register Values .....	11
Editing and Deleting Tare Registers .....	11
Net Weighing .....	11
Printing a Report .....	11
Using Cutoff Registers .....	12
Viewing Cutoffs .....	12
Entering Cutoff Values .....	12
Clearing/Deactivating Cutoff Values .....	12
Checkweighing .....	13
Setting Target and Over/Under Values .....	13
Checkweighing Operation .....	14
Customizing the Indicator .....	14
Viewing and Setting Time .....	14
Viewing and Setting Date .....	15
Viewing and Editing the ID Number .....	15
Operations Menu .....	16
Description of Operations Menu .....	17
Serial Communication .....	18
Inbound/Outbound Printouts .....	18
Tare Register Printouts .....	19
Error Messages .....	20
Indicator Diagnostics .....	21
Test Mode .....	21

**Pages are numbered consecutively beginning with the cover page.**

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*