

XK3190-A1+

Weighing Indicator

MANUAL

Content

CHAPTER 1 SPECIFICATION

CHAPTER 2 INSTALLATION

- 2.1 FRONT & BACK VIEW
- 2.2 KEYBOARD
- 2.3 CONNECTING LOAD CELL TO INDICATOR

CHAPTER 3 CALIBRATION

CHAPTER 4 OPERATING INSTRUCTIONS

- 4.1 TURNING ON
- 4.2 ZERO SETTING (AUTOMATICALLY/MANUALLY)
- 4.3 TARE OPERATION
- 4.4 CONNECTING SCOREBOARD TO INDICATOR
- 4.5 CONNECTING PINTER TO INDICATOR
- 4.6 SERIAL COMMUNICATION INTERFACE
- 4.7 DATE AND TIME SETTING
- 4.8 DATA STORE CHECK AND CLEAR
- 4.9 INSUFFICIENT VOLTAGE INDICATION

CHAPTER 5 MAINTENANCE AND ANNOUNCEMENTS

CHAPTER 6 ERRORS AND INFORMATION

Attention:

Please read this User's Guide carefully when you use the indicator!

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*