

# **Weighing Indicator**

# **XK3190-A12**

## **User Manual**

---

# Content

|   |      |
|---|------|
| CHAPTER 1 MAIN SPECIFICATION .....                      | -2-  |
| CHAPTER 2 INSTALLATION .....                            | -3-  |
| 2.1 FRONT AND BACK VIEW OF INDICATOR .....              | -3-  |
| 2.2 KEY FUNCTIONS .....                                 | -4-  |
| 2.3 CONNECTING LOAD CELL TO INDICATOR.....              | -4-  |
| CHAPTER 3 OPERATION .....                               | -5-  |
| 3.1 POWER ON & ZERO SETTING.....                        | -5-  |
| 3.2 MANUAL ZERO SETTING.....                            | -5-  |
| 3.3 TARE .....  | -5-  |
| 3.4 ACCUMULATING .....                                  | -5-  |
| 3.5 COUNTING .....                                      | -5-  |
| 3.6 USER FUNCTION STEETING .....                        | -6-  |
| 3.7 CONNECT SCOREBOARD TO INDICATOR .....               | -6-  |
| 3.8 SERIAL COMMUNICATION AND INDICATOR COMMECTION ..... | -8-  |
| CHAPTER 4 CALIBRATION .....                             | -9-  |
| CHAPTER 5 ERROR INDICATION .....                        | -10- |
| CHAPTER 6 CHARGEABLE BATTERY .....                      | -10- |
| CHAPTER 7 MAINTENTANCE .....                            | -11- |

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*