

WEIGHING INDICATOR XK3190-C5

- 1 Get to Know the Indicator-----1
- 2 Main Parameters-----2
- 3 Outlines, Interface & Data Format-----3
 - 3.1 Front & Back View of the Indicator
 - 3.2 Connection between Indicator & Load Cell
 - 3.3 Connection between Indicator & Printer
 - 3.4 Scoreboard Interface
 - 3.5 Serial Communication Interface
 - 3.6 Keyboard Function Illustration
 - 3.7 Input & Output Interface
 - 3.8 Analog Output Interface
 - 3.9 Hardware Check during Control Input & Output
 - 3.10 Input & Output board
- 4 Parameters Setup & Calibration-----6
 - 4.1 [SET 1] System Parameters Setup
 - 4.2 [SET 2] Control Parameters Setup
 - 4.3 Calibration
- 5 Operation Illustrations-----9
- 6 Control Process-----10
 - 6.1 Plus Scale

- 6.2 Minus Scale
- 6.3 Information Cues during Control Process
- 6.4 Solution of Over Errors & Point Supplement of Insufficient Material
- 6.5 Manual Feeding/Discharging

- Appendix 1 Errors Information and Solution of Frequent Questions
- Appendix 2 Data Diagram & Data Format of Scoreboard
- Appendix 3 Data Format of Serial Communication – Order Response

1 Get to Know the Indicator

Indicator XK3190-C5 adopts MCS-51 single-chip micro processing unit and accurate, speedy Sigma-Delta A/D conversion technology. It is convenient to connect the indicator with strain gauge load cell as the fix-valued scales, accumulating scales and packing scales. Indicator XK3190-C5 can be widely applied in the field of business, industrial and mineral enterprise, storage dock and related weighing environments.

Main Functions of XK3190-C5:

1. Keyboard’s calibration and adjustment
2. Parallel printing interface, can be coupled with variety of needle-type printer, fast printing
3. Capable of printing weighing records, accumulating value, material number, etc. in Chinese and English
4. Capable of saving, deleting and inspection. The data can be protected when power off
5. Accurate clock, calendar and auto leap year and leap month, all of which are not affected when power off
6. Multi-function zero setting (zero-tracking, auto zero when power on and manual zero)
7. Standard asynchronism serial communication interface (RS232 or

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*