

# **Electronic Crane Scale**

**XK3190-H2B Weighing Indicator**

## **USER GUIDE**

**VER 1.02**

**Shanghai Yaohua Weighing System Co.,Ltd.**

**Version: May,2004**

# Content

## **I Technical Specification**

## **II Configuration, Installation and Application**

- I. Configuration of the scale body
- II. External layout of indicator
- III. Wireless working mode
- IV. Wire working style
- V. Replacing the printing paper and the ink ribbon of the micro printer
- VI. External printer installation
- VII. Communication interfaces
- VIII. Scoreboard Connection
- IX. Charge

## **III Keypad Functions**

- I. Keys setting and keypad layout
- II. Keys functions

## **IV Data Printing Format**

- I. Micro-printer printing format
- II. External printer printing format

## **V Error message from wrong operation**

## **VI Error message from wrong inner operation**

## **VII Trouble Shooting**

## **Appendix**

**Attention: Please read the instruction before operating the instrument.**

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*