TEC Electronic Cash Register

MA-1530 SERIES

Programming Manual

Document No. **EO3-11100**

Original **Jun., 2002**
(Revised)

PRINTED IN JAPAN

TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

Page

1. INTRODUCTION 1- 1

1.1 Main Features 1- 1

2. SPECIFICATIONS 2- 1

3. RAM CLEAR, DATA CLEAR, STATUS CLEAR 3- 1

3.1 RAM Clear 3- 1
3.2 DATA Clear 3- 2
3.3 STATUS Clear 3- 2

4. PROGRAMMING OPERATIONS 4- 1

4.1 Basic Key Functions 4- 2
4.2 Character Entry Method 4- 3
4.3 Condition Required for Programming Operations 4- 5
4.4 RAM Allocation Setting 4- 6
4.5 SFKC (Selective Function Key Code) Programming 4- 8
4.6 Memory Balance/TAX System Programming 4-11
4.7 Store Message and Commercial Message Programming (Submode 1) 4-12
4.8 Cashier Code and Name Programming (Submode 2) 4-14
4.9 Department Table Programming (Submode 3) 4-17
4.10 PLU Table Programming (Submode 4) 4-20
4.11 Time Setting or Adjustment (Submode 5) 4-23
4.12 Date Setting or Adjustment (Submode 6) 4-24
4.13 Media Tender Key Setting (Submode 8) 4-24
4.14 Financial Report Item Name Programming (Submode 9) 4-26
4.15 Print Line Item Name Programming (Submode 10) 4-29
4.16 Print Item on Reports Setting (Submode 11) 4-32
4.17 VAT or Add-on Tax Rate Setting (Submode 12) 4-34
4.18 Department Group Name Programming (Submode 13) 4-37
4.19 Display Upper-Row Message Programming (Submode 17) 4-38
4.20 System Option Programming (Submode 18) 4-43
4.21 Endorsement (or France Check Print) Message Programming (Submode 22) 4-47
4.22 Link-PLU Table Programming (Submode 25) 4-48
4.23 PLU Preset-Code Key Setting (Submode 27) 4-49
4.24 PLU Group Programming (Submode 29) 4-49
4.25 Advertisement Message Programming (Submode 31) 4-51
4.26 Report Header Name Programming (Submode 32) 4-53
4.27 Function Key (Combination Key) Setting (Submode 34) 4-55
4.28 PLU Cashier Report Setting (Submode 35) 4-56
4.29 %+ and %- Preset Rate Setting (Submode 36) 4-56
4.30 Foreign Currency Exchange Rate Setting (Submode 37) 4-58
4.31 + (Amount Charge) and - (Amount Discount) Preset Setting (Submode 38) 4-59
4.32 Manager Pass Code Programming (Submode 39) 4-61

4.33 Network Terminal No. Setting (Submode 40) 4-61
4.34 COM Port Setting (Submode 41) 4-62
4.35 In-Store Marking Bar Code Programming (Submode 42) 4-63
4.36 Register No. Setting (Submode 43) 4-64
4.37 Line Feed Value of Endorsement Message (Submode 46) 4-64
4.38 Rounding Process Setting (Submode 47) 4-65
4.39 European Rounding Process Setting (Submode 48) (QP balance only) 4-65
4.40 Date Format Setting (Submode 49) 4-66
4.41 Printer Stamp Setting (Submode 52) 4-67
4.42 Store Coupon, Vender Coupon, Bottle Return Taxable Status Programming (Submode 53) 4-67
4.43 Food Stamp Programming (Submode 54) (US balance only) 4-68
4.44 PLU Stock Loading or Changing (Submode 90) 4-69

5. PROGRAMMED DATA VERIFICATION 5- 1

5.1 Programmed Data Verification in BLIND Mode 5- 1
5.2 Programmed Data Verification in X or SET Mode 5- 2

CAUTION!

1. ***This manual may not be copied in whole or in part without prior written permission of TOSHIBA TEC.***
2. ***The contents of this manual may be changed without notification.***
3. ***Please refer to your local Authorised Service representative with regard to any queries you may have in this manual.***

Copyright © 2002
by TOSHIBA TEC CORPORATION
All Rights Reserved
570 Ohito, Ohito-cho, Tagata-gun, Shizuoka-ken, JAPAN

Click here to download the full manual at THE-CHECKOUT-TECH.COM