SHARP

ER-2970 OPTIONS
SONDERZUBEHÖRTEILE DER ER-2970
OPTIONS DE LA ER-2970
ADITAMENTOS OPTATIVOS DE LA ER-2970

INSTALLATION MANUAL
EINBAUANLEITUNG

MANUEL D'INSTALLATION
MANUAL PARA LA INSTALACION

CONTENTS

		Page
1.	General	1
2.	Summary of the ER-2970 Options	2
3.	Before Installing Options	4
4.	Printing Out the SRV1-Mode and PGM-Mode Programs	6
	4.1 Procedures	6
	4.2 Sample printouts	7
5.	Removing the Top Cabinet	9
6.	PLU Memory (ER-45PL4 or ER-45PL6)	11
	6.1 Outline	11
	6.2 Installation procedure	11
	6.3 Operational check	12
	6.4 Modification of the SRV1-mode program	12
	6.5 PGM-mode programming	13
7.	Flexible Key Kit (ER-29DT)	14
8.	Flexible Key Layout	18
	8.1 Outline	18
	8.2 Procedure for changing the key layout	18
	8.3 Changing the key layout to reflect the one shown in Fig. 9	22
9.	Slip Printer (ER-46SP1)	25
	9.1 Outline	25
	9.2 Installation procedure	25
	9.3 Operational check	28
	9.4 Modification of the SRV1-mode program	30
	9.5 PGM-mode programming	30
10.	Remote Drawer (ER-29DW1)	31
	10.1 Outline	31
	10.2 Installation procedure	31
	10.3 Modification of the PGM-mode program	33

Click here to download the full manual at THE-CHECKOUT-TECH.COM