CASTON SERVICE MANUAL

(CASTON II & CASTON III & CASTON III PLUS)

< Table of Contents >

1 Classification 4

1.1. Preface 4

1.2. Precaution 4

1.3. Specification 6

1.4. Sealing Method 9

2 Classification 13

2.1. Overall View 13

2.2. Display & Key Functions 14

2.3. Options 15

2.3.1. Remote Control 16

2.3.2. TW-100 (Option) 17

2.3.3. TWN (Option) 18

2.4. Battery Usage 19

2.5. Use of Battery Charger 21

3 Getting Started 22

3.1. AP MODE 23

3.2. SLEEP MODE 23

3.3. BA MODE 24

3.4. CO MODE 24

3.5. ID MODE 25

3.6. BR MODE 25

3.7. OP MODE 25

3.8. CH MODE 25

3.9. PANID MODE 26

3.10. HL MODE 26

4 CASTON III Command Mode Protocol 27

5 Calibration 29

5.1. General Calibration 29

5.1.1. C4 Setting 31

5.1.1.1. C4-1 Setting 31

5.1.1.2. C4-2 Setting 31

5.1.1.3. C4-3 Setting 31

5.1.1.4. C4-4 Setting 31

5.1.1.5. C4-5 Setting 31

5.1.2. SPAN Calibration Setting (C-3) 31
5.1.3. Gravity Constant Value Setting (C-9) 31
5.1.4. Calibration factor Setting (C-10) 32
5.1.5. Displaying Real A/D Value (C-5) 33
5.1.6. Input Function Key Code (C-6) 33
5.1.7. Percent Calibration (C-7) 33
5.1.8. Battery Calibration (C-8) 33
6 The Schematics and Diagram 34
6.1. System Block Diagram 34
6.2. Circuit Diagram 36
7 Exploded View 42
8 Part Location 55
9 Error Messages & Solution 60
10 Part List (Common Part) 61
11 Part List (ETC Part) 94

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/CAS/CASTON II CASTON III CASTON III PLUS

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM