CL5000 Series

Network's Manual

(English)

Rev. 2005. 07.12
F/W Version. 1.00, 1.01, 1.02, 1.03, 1.04, 1.08



Table of Contents

1. Introduction 4
Getting started 4
1.1 Network card 5
1.2. Install Network card 6
2. Scale and System Configuration 8
2.1. General Terms 8
2.2. How to set Network method and scale 9
2.2.1. PC Control 9
2.2.2. Floating Clerk (Vender) 13
2.3. Wireless LAN 18
3. Application 19
3.1. Time Synchronize 19
3.2. Remote Call PLU 20
4. Protocol 21
4.1. General 21
4.2. Table 1 27
4.2.1. Department 27
4.3.2. Group 29
4.3.3. Label Message 30
4.3.4. Origin 31
4.3.5. PCS 32
4.3.6. Tax 33
4.3.7. Tare 34
4.3.8. Barcode Type 35
4.3. Table2 36
4.3.1. Ingredient 36
4.3.2. Nutrition Facts 37
4.3.3. Traceability 39
4.3.4. Country 40
4.3.5. Slaughter House 41
4.3.6. Cutting Hall 42

4.4. Store,Customer,Scroll Message and Clerk Table 43
4.4.1. Store 43
4.4.2. Customer 44
4.4.3. Scroll Message 45
4.4.4. Clerk 46
4.5. Discount Table 47
4.6. Report 49
4.7. Label and Image 53
4.7.1. Label format 53
4.7.2. Bitmap size (for printing size allowance) 53
4.7.3. Data File 54
4.7.4. Transfer 56
4.8. Keypad 58
4.8.1. Speed Key Set 58
4.8.2. Function Key setting 59
4.9. Other 60
4.9.1. Date / Time 60
4.9.2. System Password 61
4.9.3. Scale Information 61
4.9.4. Weight 62
4.10. PLU Field Control 63
5. Internal Communication 64
5.1 Transaction Number 64
6. Example 64
6.1. PLU 64
6.2. Department 66
6.3. Ingredient 67
6.4. Barcode Format 67
6.5. Discount 69
6.6. Report 71
6.7. Label and Image 71
4. Reference 72
Ref 1. Use of Terms 72

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/CAS/CL-5000 Series network manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM