AIRLINE BAGGAGE SCALE

ABS 4100

Technical Reference Manual 2.0

SPX GSE scale systems

CONTENTS

CHAPTER 1: INTRODUCTION 1

CONVENTIONS AND SYMBOLS 1
DISPLAY 2
Annunciators *2*
KEYPAD 3
KEYPAD FUNCTIONS 3
SPECIFICATIONS 5

CHAPTER 2: INSTALLATION 7

MOUNTING 7
Load Cell Connections *10*
Serial Port Connections *11*

CHAPTER 3: ABS 4100 CONFIGURATION 15

SETUP MODE 15
SELECTION PARAMETERS 18
KEY-IN PARAMETERS 19
PARAMETER MAP 20
Parameter Map Details *22*
CUSTOM TRANSMIT SETUP 28
Elements of a Custom Transmit *28*
Writing a custom transmit ASCII text file *28*
Accessing Setup and Clearing Existing Custom Transmit *28*
Entering ASCII Text *29*
Entering ASCII Control Codes *29*
Exiting Setup Mode and Saving Changes *32*
Display Capture Utility *33*
GENERAL SETUP AND OPERATION 34
Baggage Weighing and accumulation *35*
RS-485 MULTI-DROP NETWORK SETUP AND OPERATION 36
Setup *36*
Operation *36*
Network Protocol *37*

CHAPTER 4: CALIBRATION MODE 39

SETUP MODE CALIBRATION 39
FAST CALIBRATION 39
PERFORMING CALIBRATION 40
Establishing Zero *40*

Establishing Span *46*
Exiting Calibration *46*

CHAPTER 5: LEGAL-FOR-TRADE 49

NTEP REQUIREMENTS 49
OIML REQUIREMENTS 49
OTHER REQUIREMENTS 50
SEALING AND AUDIT TRAILS 50
Physical Seal *51*
Audit Trails *52*

CHAPTER 6: ABS 4100 OPTION 55

RS-485 NETWORKING 55
Network Connections *56*

CHAPTER 7: TROUBLESHOOTING 60

ERROR MESSAGES 60
Operational Errors *60*
Setup Mode Errors *61*
Hardware Errors *62*
Calibration Errors *62*
Communication Errors *63*
Miscellaneous Errors *63*
VIEWING SETUP 63
INFORMATION MODE PARAMETERS 64
A/D CALIBRATION PROCEDURE 66

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/GSE/ABS-4100 technical reference manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM