ISHIDA

AstraLink

User's Guide

RICE LAKE WEIGHING SYSTEMS
Industrial Solutions on a Global Scale®

ISO 9001 REGISTERED

68808

Contents

1. Introduction 1
    System Requirements 1
    How to Use This Manual 1
2. Getting Started 2
    Before You Start 2
    Starting AstraLink for the First Time 2
        Troubleshooting 5
    Starting AstraLink (second and subsequent times) 7
        Finding a PLU 8
            If you know the PLU number 8
            If you know some or all of the PLU name 8
            If you do not know the PLU number or name 8
        Adding a New PLU 9
        Editing and Deleting PLUs 9
            To edit the selected PLU 9
            To delete the selected PLU 9
        Changing PLU Prices 10
            Using the Price Change Dialog 10
        Using the PLU Edit Dialog 11
            Entering the PLU description 12
            Entering the PLU settings 12
            Changing the PLU number 12
            Saving your changes 12
            Changing the displayed PLU 13
            Adding a new PLU 13
            Closing the PLU Edit window 13
        Extra Messages 13
        Storage Instructions (Sweden Only) 14
        Nutrition (USA Only) 15
        Keyboard 17
            1. Upper Keys 18
            2. Lower Keys 18
            3. Keysheet 18
            Using the keyboard window 18
        Scale Communications 19
        PLU List and Extra Message List Reports 21
        PLU Production Report 21
    Other Features 22
3. Communicating with the Scale 23
    3.1 Receiving Data From the Scale 23
    3.2 Sending Data to the Scale 25
4. The Astra Database 27
        Selecting the Database 27
        Automatic Database Backup 27
5. Editing PLUs 28
    5.1 Using the PLU Search Window 28
        Finding a PLU 28
            If you know the PLU number 28
            If you know some or all of the PLU name 28
            If you do not know the PLU number or name 29
        Adding a New PLU 29
        Editing or Deleting a PLU 29
        Deleting a Range of PLUs 30
        Cutting and Pasting PLUs 30
        Quick Price Changes 30
    5.2 Using the PLU Edit Dialog 32

6. Extra Messages and Storage Instructions 35
Creating and Editing Extra Messages 35
Assigning an Extra Message to a PLU 37
Deleting an Extra Message 37
7. Nutrition (USA) 38
Creating and Editing Nutrition Information 38
Assigning Nutrition Information to a PLU 38
Deleting Nutrition Records 39
8. Nutrition and Ingredients (NZ) 40
Creating and Editing Nutrition Information 40
Creating and Editing Ingredients Information 41
Deleting Nutrition Data 41
Deleting Ingredient Data 41
9. Keyboard 42
9.1 Defining the Upper and Lower Key Meanings 42
9.2 Printing Keysheet Templates 46
10. Store Name and Address 48
11. PLU and Extra Message List Reports 49
12. Production Totals Report 51
13. Price Importing 53

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/ishida/AstraLink users manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM