VECTOR-VL 200

Weighing Indicator

User Manual

(Version 1.02)

Content

Chapter 1 Technical Parameter…….1

Chapter 2 Installation …… 2

(1)VL 200（column type）weighing indicator front side function instruction and back side function instruction.

(2) Load cell & weighing indicator VL 200（column type）connection

(3) VL 200（desktop）weighing indicator front side function instruction and back side function instruction.

(4)Load cell & weighing indicator VL 200（desktop）connection

Chapter 3 Operation Instruction…… 4

(1). Button function

(2). Startup&Shut down

(3). Battery use

(4). Startup Zero operation and Manual zero operation

(5) Tare operation

(6). Unit price input

(7) Accumulation clear and Accumulation display and accumulation clear

(8)Saving and re-call of unit price

(9)Power-saving mode

(10)Inner code display

Chapter4 Optional function 8

(1)RS232 communication

(2)Serial port print

(3)Scoreboard output

(4)Upper and lower limits alarming

Chapter 5 Information Instruction 14

Chapter 6 Maintenance and Attention 15

Dear user:

Please read this manual before using.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

http://the-checkout-tech.com : the biggest supplier of cash register and scale manuals on the net