Avery Weigh-Tronix

PC-820/821 Parts Counter Service Manual

Table of Contents

Table of Contents 3
Specifications 4
Introduction 5
About This Manual 5
PC-820 Description 5
Front Panel Keys 6
Hard Keys 6
PC-820 Menus 6
Entering the Menu 7
Test Menu 7
Setup Menus 9
User Menu (password is 111) 9
Configuration Menu (password is 2045) 12
Calibration Menu (password is 30456) 20
Configuration of Remote 1 for Analog Scale Base 21
Calibration Error Messages 21
Serial Communication 22
Scale Status Byte Definition 24
Appendix A: Available PC-820 Displays 25
Appendix B: Tips on Using Harmonizer 27
Technical Drawings and Parts Lists 29-45
10 lb / 5 kg 12" x 14" Parts and Assembly 29
Draft Shield Parts and Assembly 30
50 lb / 25 kg and 100 lb / 50 kg 12" x 14" Parts and Assembly 31
System Wiring Block Diagram 32
Main Computer & I/O, Remote Analog, Internal Battery Charger PC Boards 33
Display & Interface Bd. Display Assembly, Keypad Assembly and Matrix 34
Internal Battery & Charger PC Board Parts and Assembly 35
Dimensional Outline for 12" x 14" Base 36
COM2 Interface Cable Options and Pin-outs 37
COM1 Interface Cables, 820 to Quartzell Base and 820 to Eltron Printer Cable Assemblies 38
BP-25R External Battery 39
Zeus Kits, Internal and External 40
SSCU Parts and Assembly 41
SSCU-8 Remote Expanded Control I/O Board 42
SSCU External (16) I/O Cutoff Expansion Board 43
Opto-22 Control Interface Devices 44
Wiring Diagram for Input and Output Modules 45

Pages are numbered consecutively beginning with the cover page.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/Weigh-Tronix/PC-820 PC-821 service manual.ht

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM