

IB-600
Weighmobile
Owner's Manual

Thank you for purchasing our DETECTO™ Model IB-600 Weighmobile. It has been manufactured with quality and reliability at our factory in Webb City, MO USA. This scale has been tested before leaving our factory to insure accuracy and dependability for years to come.

When removing the scale from its packing, inspect it for signs of damage, such as exterior dents and scratches. Keep the carton and packing material for return shipment if it should become necessary. It is the responsibility of the purchaser to file all claims for any damages or loss incurred during transit, unless this responsibility has been accepted by the seller in its proposal.

This manual is provided to guide you through installation, operation and maintenance of your scale. Please read it thoroughly before attempting to install or operate your IB-600 and keep it handy for future reference.

FCC COMPLIANCE STATEMENT WARNING! This equipment generates, uses and can radiate radio frequency and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC rules, which are designed to against reasonable protection provide interference when operated in a commercial environment. Operation of this equipment in a residential area may cause interference in which case the user will be responsible to take whatever measures necessary to correct the interference.

You may find the booklet "How to Identify and Resolve Radio TV Interference Problems" prepared by the Federal Communications Commission helpful. It is available from the U.S. Government Printing Office, Washington, D.C. 20402. Stock No. 001-000-00315-4.

All rights reserved. Reproduction or use, without expressed written permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this manual, the Seller assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from use of the information contained herein. All instructions and diagrams have been checked for accuracy and ease of application; however, success and safety in working with tools depend to a great extent upon the individual accuracy, skill and caution. For this reason the Seller is not able to guarantee the result of any procedure contained herein. Nor can they assume responsibility for any damage to property or injury to persons occasioned from the procedures. Persons engaging the procedures do so entirely at their own risk.

TABLE OF CONTENTS

Specifications
Introduction
Assembly Instructions
Weighing the Patient
Component Identification
Preventive Maintenance 6
Service Information 6
Parts List 7
SERIAL NUMBER
DATE OF PURCHASE
PURCHASED FROM
RETAIN THIS INFORMATION FOR FUTURE USE

PRECAUTIONS

Before using this instrument, read this manual and pay special attention to all "WARNING" symbols:



IMPORTANT

SPECIFICATIONS

Capacity: 600 lbs (270 kg) Resolution: 0.2 lb (0.1kg)

Display: LCD digital display mounted on

Weighmobile, operating from replaceable Alkaline, Ni-Cad or NiMH batteries. Refer to 758C Indicator manual for battery

operation.

Casters: Four (4); full swivel ball bearing,

rear pair locking

Lift Hydraulic

Mechanism:

Stretcher: Staph-Chek® 44" W x 72" L

 $(1.1 \text{m W} \times 1.8 \text{m L})$

Closed 60" H x 32" W x 62" D

Overall (1.52m H x 0.81m W x 1.57m D)

Dimensions:

Shipping 460 lbs (209 kg)

Weight:

Operating 9.0 VDC nominal

Voltage:

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net