SERVICE MANUAL
5000 Series
T51 Indicators

T51P

T51XW

Ohaus Corporation 19A Chapin Road, P.O. Box 2033, Pine Brook, NJ 07058-2033 (973) 377-9000

CHAPTER 1 GETTING STARTED

Page No.

1.1 Introduction 1-1
1.2 Service Facilities 1-1
1.3 Tools and Test Equipment Required 1-2
1.3.1 Special Tools and Test Equipment List 1-2
1.3.2 Standard Tools and Test Equipment List 1-2
1.4 Top and Bottom Housing 1-2
1.5 Specifications 1-4
1.6 Hardware Setup or Disassembly 1-5
1.6.1 Jumper Connections 1-5
1.6.2 RS232 Interface 1-6
1.7 Operation 1-7
1.7.1 Power Supply 1-7
1.8 Overview of the Controls 1-7
1.8.1 Overview of the Display Indicators 1-7
1.8.2 Overview of the Control Functions 1-8
1.8.3 Menu Setup 1-8
1.9 Calibration 1-10
1.9.1 Zero Calibration 1-10
1.9.2 Span Calibration 1-11
1.9.3 Linearity Calibration 1-12
1.9.4 Calibration Test 1-13
1.9.5 Geographical Adjustment Factor 1-13
1.10 RS232 Interface Connection 1-14
1.10.1 Setting Communications Parameters 1-14
1.10.2 Interface Commands 1-15
1.10.3 Output Format 1-15
1.11 Legal For Trade (LFT) 1-16

CHAPTER 2 TROUBLESHOOTING

2.1 Introduction 2-1
2.2 Visual Inspection 2-1
2.3 Diagnostic Guide 2-2
2.2.1 Diagnosis 2-2

CHAPTER 3 MAINTENANCE PROCEDURES

3.1 Preventive Maintenance 3-1
3.1.1 Preventive Maintenance Checklist 3-1
3.2 Replacement of Major Components 3-1
3.2.1 Main Printed Circuit Board (PCB) Replacement 3-2
3.2.1 Display Printed Circuit Board (PCB) Replacement 3-3
3.2.3 Membrane Replacement 3-4

CHAPTER 4 TESTING

4.1. Testing 4-1
4.2 Power Test 4-1
4.3 Performance Tests Using a Scale Base 4-1
4.3.1 Increasing/Decreasing Load Test 4-2
4.3.2 Overload/Underload Test 4-2
4.4 Performance Tests Using a Load Cell Simulator 4-3

CHAPTER 4 TESTING *(continued)* **Page No.**
4.5 Calibration Retention Test 4-3
4.6 RS232 Interface Test 4.3
4.7 Print Test 4-3

CHAPTER 5 PARTS LISTS & DIAGRAMS
5-1 5000 Series T51P Indicator: Housing & Internal Parts 5-2
5-2 5000 Series T51XW Indicator: Housing & Internal Parts 5-4

APPENDIX A SETUP & CALIBRATION VALUES
Appendix A. Geographical Adjustment Values A-1

LIST OF TABLES

TABLE NO. **TITLE** **Page No.**
1-1 Specifications 1-4
1-2 T51P RS232 Pin Configuration 1-6
1-3 T51XW RS232 Terminal 1-6
1-4 Functions of Display Controls 1-8
1-5 T51 Menu Structure 1-9
1-6 Interface Command Table 1-15
1-7 Default Serial Output Format 1-15
2-1 Diagnostic Guide 2-3
4-1 Increasing/Decreasing Load Test 4-2
5-1 T51P Indicator: Housing & Internal Parts 5-3
5-2 T51XW Indicator: Housing & Internal Parts 5-5
A-1 Geographical Adjustment Values A-1

LIST OF ILLUSTRATIONS

FIGURE NO. **TITLE**
1-1 Top and Bottom Housing, and Rear Panel, T51P 1-2
1-2 Top and Bottom Housing, and Rear Panel, T51XW 1-3
1-3 Printed Circuit Board (PCB), T51 Indicator 1-4
1-4 Load Cell wiring 1-4
1-5 Open/shorted jumpers 1-4
1-6 RS232 Pins (T51P) 1-5
1-7 RS232 Terminal (T51XW) 1-5
1-8 Battery charge symbol 1-6
1-9 T51 Display 1-6
1-10 T51 Display Indicator 1-6
1-11 T51P Wire Seal 1-15
1-12 T51P Paper Seal 1-15
1-13 T51XW Wire Seal 1-15
1-14 T51XW Paper Seal 1-15
2-1 Visual Checking Procedures 2-1
5-1 Series 5000 T51P Indicator: Housing & Internal Parts 5-2
5-1 Series 5000 T51XW Indicator: Housing & Internal Parts 5-4

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/ohaus/Defender 5000 with T51 Indicator service

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM