Sharp ER-A570 and ER-A610 programming IRC Manual

SHARP®

ER-A570/A610 INTER-REGISTER COMMUNICATION SYSTEM
ER-A570/A610 MASTER/SATELLIT-KOMMUNIKATIONSSYSTEM (IRC)
SYSTEME DE COMMUNICATION DIRECTE ENTRE ENREGISTREUSES DE LA ER-A570/A610
SISTEMA DE COMUNICACION ENTRE CAJAS REGISTRADORAS ER-A570/A610

MODEL
MODELL
MODELE
MODELO
ER-A57R1
ER-A61R1

INSTRUCTION MANUAL
BEDIENUNGSANLEITUNG
MANUEL D'INSTRUCTIONS
MANUAL DE INSTRUCCIONES

ER-03RP
ER-04RP

CAUTION:
The socket-outlet shall be installed near the equipment and shall be easily accessible.

VORSICHT:
Die Netzsteckdose muß nahe dem Gerät angebracht und leicht zugänglich sein.

ATTENTION:
La prise de courant murale devra être installée à proximité de l'équipement et devra être facilement accessible.

AVISO:
El tomacorriente debe estar instalado cerca del equipo y debe quedar bien accesible.

VARNING:
Det matande vägguttaget skall placeras nära apparaten och vara lätt åtkomligt.

TABLE OF CONTENTS

ENGLISH

Page

- INTRODUCTION 4
- IRC PROGRAMMING SETUP 5
  1. Setting the machine numbers – master and satellite (#2612) 5
  2. Setting the terminal numbers (IRC machine number) – master and satellite (#3610) 6
  3. Creating/updating the master list 7
     (1) Adding a machine to the master list – master (#3611) 7
     (2) Deleting a machine from the master list – master (#3612) 8
  4. Programming to enable or disable the manager retry function when a transmission error occurs – master and satellite (#3631) 9
  5. Specifying the terminal to serve as the back-up master (#3616) 10
  6. Specifying how the EAN/UPC code is searched – master and satellite (Only for ER-A610) (#3623) 11
  7. Specifying whether the registration is disabled or enabled when the T-LOG buffer becomes full – master and satellite (Only for ER-A610) (#3640) 12
  8. Reading the contents of the IRC programming – master and satellite (#3610) 13
  9. Downloading IRC programming to satellites – master (#4900) 13
  10. Programming for the remote printer 14
      (1) Assigning remote printer numbers to the terminal numbers – master and satellite (#3650) 14
      (2) Assigning the 2nd remote printer numbers to each remote printer – master and satellite (#3653) 14
      (3) Naming the remote printer – master and satellite (#3654) 15
      (4) Assigning printer numbers to departments – master and satellite (#2118) 15
      (5) Assigning printer numbers to PLUs – master and satellite (#2218) 16
      (6) Choosing the format of printing – master and satellite (#3655) 17
      (7) Programming whether to enable or disable the data transmission to the remote printer – master and satellite (#3651) .. 17
  11. Reading the contents of the remote printer programming – master and satellite (#3650) 18

Page

12. Downloading the contents of the remote printer programming to satellites (#4950) 18
13. Programming of PLU/EAN/UPC stock quantity (#1220, 1221, 1222, 1020, 1021 and 1022) 19

• INLINE OPERATION 21
1. Message displays 21
(1) The status of the display during inline communication 21
(2) Error messages 21
2. Open store operation – master and satellite (#500) 23
3. Close store operation – master and satellite (#501) 24
4. Downloading of preset data 25
(1) Outline 25
(2) Downloading of preset data in the preset data file (or memory) of the master 25
List of downloading jobs 27
5. Sign on operation (Clerk assignment) 29
6. Cancellation of the sign on operation when a transmission error occurs – master (#5940) 30
7. Sign off operation (Cancellation of clerk assignment) 30
8. Manual sign on function – satellite 31
9. Notes on the inline system that uses the overlapped clerk system 31
10. Look-up and updating of the GLU/PBLU file 32
11. T-LOG polling (Only for ER-A610) 33
(1) T-LOG polling of EAN/UPC data 34
(2) T-LOG polling of customer management data 35
12. Price change function (Only for ER-A610) 36
13. Communications with a remote printer 37

• CONSOLIDATED AND INDIVIDUAL REPORTS 38
1. Mode switch positions 38
2. Job number 38
3. Notes for printing 38
4. List of consolidated reports – master/back-up master 39
• Sample print 48
5. List of individual reports – master/back-up master/satellite 49
6. Clerk report 54
7. Cashier report (Only for ER-A610) 56

Page

8. List of reports that can be generated when a Compulsory Cash/Cheque Declaration (CCD) entry is compulsory 57
   (1) When the individual clerk file allocation system is selected 57
   (2) When the centralized clerk file allocation system is selected 58
9. Sales data resetting at individual machines with no save files 59
10. Reset clear operation – master (#1Y99) 60

- SYSTEM BACK-UP 60
  (1) When the master and the back-up master is in normal working order . 61
  (2) When the master breaks down 61
  (3) When the back-up master breaks down 62
    - Master declaring operation 62
  (4) When the master resumes its normal condition 63
  (5) When the back-up master resumes its normal condition 63
    - Recover declaring operation 63
  - Summery of PGM-mode operations to be performed when the master (inline master) or back-up master breaks down 64
    (1) When the master breaks down 64
    (2) When the back-up master breaks down 65
- ERROR RECOVERY 66
  1. Memory clear operation (master/satellite) 66
  2. GLU/PBLU file recovery (master) 67
  3. Error messages 67
     - Transmission errors 67
     - Application errors 68
  4. Manager retry function (master/satellite) 69
     (1) Retry function 70
     (2) Accept function 70
     (3) Cancel function 70
- BASIC SPECIFICATIONS 70
- HANDLING THE REMOTE PRINTER 71
  - ER-03RP 71
  - ER-04RP 76
  - Appendix 81

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/sharp/ER-A570 and ER-A610 programming IRC

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM