OHAUS

Instruction Manual
MB45 Moisture Analyzer


On/Off
Test Menu
Display
Setup
START/STOP
MB45
Enter
Print
OHAUS
TARE

Contents

OVERVIEW OF CONTROLS **8**

1. **GETTING TO KNOW YOUR MOISTURE ANALYZER** **9**
1.1 Introduction 9
1.2 Overview of the Moisture Analyzer 9
1.3 What is a Moisture Analyzer ? 9
1.4 Safety is first 11
1.5 What you should know about these instructions 13

2. **INSTALLATION** **14**
2.1 Unpacking and checking the standard equipment 14
2.2 Selecting the location 15
2.3 Installing the heat shield, draft shield and pan support 15
2.4 Leveling the Moisture Analyzer 16
2.5 Connecting to a power supply 16
2.6 Switching the Moisture Analyzer on or off 17

3. **MAKING A SIMPLE MEASUREMENT** **18**

4. **THE MENUS** **22**
4.1 What are the menus? 22
4.2 Menu operation 23

5. **ANALYZER SETUP** **25**
5.1 Lockout 25
5.2 Weight calibration 26
5.3 Temperature calibration 27
5.4 Language setting 28
5.5 Audible signal level 28
5.6 Time and date setting 28
5.7 RS232 settings 30
5.8 Setting print and GLP printing on or off 32
5.9 Adjusting display contrast and brightness 33
5.10 Factory reset 34

6. OPERATING YOUR MOISTURE ANALYZER **35**
6.1 The operating concept 35
6.2 Entering test ID 35
6.3 Setting the drying profile 36
6.4 Setting the drying temperature 38
6.5 Selecting the switch-off criterion 39
6.6 Result 41
6.7 Custom units 41
6.8 Target weight 44
6.9 Print interval 44
6.10 Saving test setup 45
6.11 Exiting test setup and not saving changes 45
6.12 Running test setup or after completion 45
6.13 Displaying data during run mode 48
6.14 Statistical data 48

7. USING THE LIBRARY **49**

8. HOW TO OBTAIN THE BEST RESULTS **50**
8.1 Measurement principle of the Halogen Moisture Analyzer 50
8.2 Sampling and sample preparation 51
8.3 Selection of the drying temperature 54
8.4 Selection of the drying program 55
8.5 Selection of the drying time 57
8.6 Analysis of the drying profile 58

9. PRINTING TEST DATA **59**
9.1 RS232 command table 61
9.2 RS232 Pin out 61

10. CARE AND MAINTENANCE **62**
10.1 Cleaning interior/exterior components 62
10.2 Replacing power line fuse 64
10.3 Troubleshooting 65
10.4 Error detection 66
10.5 Service information 66

10.6 Accessories 66
10.7 Specifications 67
A1 APPENDIX - APPLICATION EXAMPLES 68

This is a “Table of Contents preview” for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

http://the-checkout-tech.com : the biggest supplier of cash register and scale manuals on the net