

NCR 7870 Scanner/Scale
Release 1.0
User's Guide



BST0-2121-90
Issue G

Table of Contents

Chapter 1: Introduction

About the NCR 7870 Scanner/Scale.....	1-2
Models.....	1-2
Reading the Product Number	1-3
Common Features	1-3
7870-1000-9090	1-4
7870-2000-9090	1-4
7870-3000-9090	1-4
7870-4000-9090	1-4
7870-4500-9090	1-4

Chapter 2: Features, Functions, and Kits

General Features and Functions.....	2-1
Bar Code Recognition.....	2-1
Bi-Optic Scanning.....	2-2
Decode Features	2-2
PACESETTER <i>Plus</i>	2-2
Displays.....	2-3
NCR 7825 Remote Display	2-3
Integrated Display.....	2-4
No Display	2-5
Interface Types	2-5
Laser Scanner	2-5
Power Supply	2-5
Programming the 7870.....	2-6
Scale Certifications	2-7
Scan Zone.....	2-8

Scanner Power Requirements.....	2-8
Soft Power Down.....	2-8
Top Plates and Scan Windows	2-9
Top Plates.....	2-9
Slot Scanner Window.....	2-9
Side Scanner Window.....	2-10
Scale Features and Functions.....	2-11
Scale Functions and Features.....	2-11
Kits	2-12

Chapter 3: Site Preparation

Getting Started.....	3-2
About Site Preparation.....	3-4
Customer Responsibilities.....	3-6
Environmental Requirements.....	3-7
Operating Range	3-7
Extreme Operating Range	3-7
Storage Range.....	3-8
Transit Range.....	3-8
Checkstand Power and Wiring Considerations	3-9
Power Considerations	3-9
Power Applications.....	3-9
Power Transients Protection.....	3-9
Wiring Considerations.....	3-10
U.S., Canadian, and Japanese Checkstand Wiring	3-10
European Checkstand Wiring	3-11
International Checkstand Wiring.....	3-12
Wiring Instructions	3-13
Running Feeder Lines from Main Service Panel.....	3-13
Circuit A.....	3-13

Circuit B	3-14
Circuit C	3-14
Checkstand Considerations	3-15
Ventilation Requirements	3-15
Service Clearance.....	3-16
Display Clearance.....	3-17
Item Diverter.....	3-17
Checkstand Hole	3-18
Checkstand Hole - Models 1000 & 2000	3-19
Checkstand Hole - Models 3000, 4000, & 45003-20	
Cable Lengths and Hole Sizes	3-21
Cable Hole Diameters	3-21
DC Power Cable – Power Supply to 7870.....	3-21
AC Power Cords – Outlet to Power Supply.....	3-22
Remote Display Cables	3-22
Interface Cables - NCR Host Terminals.....	3-23
Interface Cables – NCR Host Terminals (cont.) .	3-24
Interface Cables – NCR Host Terminals (cont.) .	3-25
Interface Cables - Casio Host Terminals.....	3-25
Interface Cables – Data Checker Host Terminals	3-26
Interface Cables – Epson Host Terminals.....	3-26
Interface Cables – Gilbarco Host Terminals	3-26
Interface Cables – IBM Host Terminals	3-27
Interface Cables – ICL Host Terminals	3-27
Interface Cables – ICL Host Terminals (cont.)....	3-28
Interface Cables – Microbilt Host Terminals	3-28
Interface Cables – NEC Host Terminals	3-28
Interface Cables – SASI Host Terminals	3-29
NCR 7870 Dimensions.....	3-30
NCR 7870-1000 & 2000 Models	3-30
NCR 7870-3000 Model.....	3-31

NCR 7870-4000 & 4500 Models 3-32

Chapter 4: Installation

Getting Started 4-1
 Reporting a Damaged Unit..... 4-1
 What's in the Box..... 4-1
 Cable Verification 4-2
 Checkstand Verification..... 4-2
Installing Unit in Checkstand 4-3
 Instructions 4-3
 Install Cables..... 4-3
Determining if the Unit is Operational 4-8
 NCR 7870-1000 and 3000 Scanners..... 4-8
 NCR 7875-2000, 4000, and 4500 Scanner/Scales .. 4-8
 If the NCR 7870 Does Not Pass Level O
 Diagnostics..... 4-8
 Checkout Reading Operation..... 4-9
 Programming..... 4-9
Determining Communications Protocol 4-10
Scale Address for IBM 4-11

Chapter 5: Calibration

General 5-1
Calibration Procedure 5-3
 Section 1: Exercising the Scale 5-3
 Section 2: Accessing the Calibration Switch 5-4
 Section 3: Connecting the Field Service
 Calibration Display 5-7
 Section 4: Performing the Calibration 5-9
Verifying Calibration..... 5-11
 Procedure 1: Increasing Load Test 5-12
 Procedure 2: Over-Capacity Test..... 5-13

Procedure 3: Decreasing Load Test	5-14
Instructions	5-14
Procedure 4: Shift Test	5-15
Securing the Calibration Switch	5-16

Chapter 6: Operation

About Using the Operator Controls.....	6-2
Scan Windows	6-2
Status Indicators	6-2
Motion Detector.....	6-3
Reset / Scale Zero Button	6-3
Audible Tone	6-3
Voice Messages.....	6-3
About Using the Scanner	6-4
Proper Label Orientation	6-4
Active Scan Zone.....	6-5
Multiple Reads.....	6-5
Bar Code Quality	6-6
Operating Instructions	6-7
Power Up	6-7
Scanner Only Models.....	6-7
Scanner/Scale Models	6-7
Scanning Procedure.....	6-8
Instructions	6-8
Not-On-File Error	6-8
Weighting Procedure	6-9
Instructions	6-9
Changing the Good Read Tone	6-10
Instructions	6-10
Routine Maintenance.....	6-11
Instructions	6-11

Chapter 7: Programming

General	7-1
How to Program the NCR 7870	7-3
Creating the Program	7-3
Step 1. Writing the Program	7-3
Step 2. Entering the Program	7-3
Step 3. Save the Program	7-4
Programming Mode	7-5
Programming Tags	7-6
Abort	7-6
Default	7-7
End	7-7
Hex 0 – Hex F	7-7
Programming Mode	7-8
Save and Reset	7-8
Program Entry Example	7-9
Programming Tips	7-12
Program Parameter Descriptions	7-13
Communications Protocol	7-13
Defaults	7-13
Specific Program Parameters	7-13
Programming Example	7-17
Good Read Tone	7-18
Defaults	7-18
Specific Program Parameters	7-18
Program Example	7-19
Timers	7-20
Defaults	7-20
Specific Program Parameters	7-20
Program Example	7-21
Bar Codes – 1	7-22

Defaults	7-22
Specific Program Parameters.....	7-22
Program Example.....	7-24
Bar Codes – 2	7-25
Defaults	7-25
Specific Program Parameters.....	7-25
Program Example.....	7-27
Bar Codes – 3	7-28
Defaults	7-28
Specific Program Parameters.....	7-28
Program Example.....	7-30
Bar Codes – 4	7-31
Defaults	7-31
Specific Program Parameters.....	7-31
Program Example.....	7-32
Label Identifiers.....	7-33
Defaults	7-33
Specific Program Parameters.....	7-34
Program Example.....	7-37
RS-232 Parameters – 1	7-39
Defaults	7-39
Specific Program Parameters.....	7-39
Program Example.....	7-41
RS-232 Parameters – 2	7-42
Defaults	7-42
Specific Program Parameters.....	7-42
Program Example.....	7-44
RS-232 Prefix Byte	7-45
Defaults	7-45
Specific Program Parameters.....	7-45
Program Example.....	7-46

RS-232 Terminator Byte	7-47
Defaults	7-47
Specific Program Parameters.....	7-47
Program Example.....	7-48
RS-232 Communications Options	7-49
Defaults	7-49
Specific Program Parameters.....	7-49
Program Example.....	7-52
Scale Parameters	7-53
Defaults	7-53
Specific Program Parameters.....	7-53
Program Example.....	7-54
Miscellaneous Parameters	7-55
Defaults	7-55
Specific Program Parameters.....	7-55
Program Example.....	7-57
PACESETTER <i>Plus</i> Information	7-59
Mode 1 - Inquiry	7-59
Mode 2 - Real Time.....	7-60
Mode 3 - Normal.....	7-62
Host Access to Tallies.....	7-64
Examples of Host Access to Tallies.....	7-64
Host Reset of Tallies.....	7-67
Special Programming	7-68
Delay Weight Data to IBM Host Terminal	7-68
EAN/JAN/UPC Multi-Symbol Scanning Parameters	7-69
Label Construction	7-69
Single Label Restriction.....	7-69
Transmitting Label Data.....	7-69
Early Beep Disable.....	7-72
Good Read Tone Presets	7-73

Good Weigh Tone When Transmitting Data.....	7-74
Terminal Coupon Interface Parameters.....	7-75
ASCII Code Chart.....	7-77

Chapter 8: Troubleshooting

Fault Identification	8-1
Scanner Troubleshooting Chart.....	8-2
Scale Troubleshooting Chart.....	8-3
Voice Messages Troubleshooting Chart.....	8-5

Appendix A: Programming Worksheets

General	A-1
Purpose.....	A-1
Format	A-1
Shortcuts.....	A-1
Defaults	A-2
Hex Characters	A-2
Program Entry	A-2
Programming Parameter Defaults	A-3
Worksheets.....	A-6

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/NCR/7870 user manual.html](https://the-checkout-tech.com/manuals/NCR/7870%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)