

NCR RealScan 72 (7872)

Release 3.0

User Guide



B005-0000-1179

Issue N

Table of Contents

Chapter 1: Overview

RealScan 72 Features	1-1
Base Models	1-2
Scan Doctor	1-3
Volume Adjust Button	1-4
Not-On-File	1-4
Voice Messages	1-4
Window Maintenance Indicator	1-5
Remote Displays	1-6
Decode Types	1-7
PACESETTER	1-7
Power Supply	1-8
Bi-Optic Scanning	1-10
How Does the Scanner Work?	1-11
Servicing	1-13
Discriminating Among Bar Codes	1-14

Chapter 2: Site Preparation

Customer Responsibilities	2-1
Environment Considerations	2-2
Installation Location	2-3
Checkstand Cutout	2-3
RealScan 72-1xxx/2xxx	2-4
RealScan 72-03xx/05xx/06xx	2-5
RealScan 72-5xxx	2-6
Cable Connections	2-7
Dual Cable Installations	2-8

RealScan 25 Remote Compact Display Dimensions	2-10
Hole Requirements for Cables	2-10
Physical Characteristics	2-11
Service Clearance	2-11
Scanner Weight	2-12
Preparing the Site	2-13
Power Considerations.....	2-15
Power Application.....	2-15
Power Transient Protection.....	2-15
Checkstand Wiring.....	2-16

Chapter 3: Installation

Special Installations.....	3-1
Peripheral Device Installation	3-2
RealScan 32 Hand-Held Scanner	3-2
Program the RealScan 72.....	3-2
Programming the RealScan 32.....	3-3
RealScan 35/36 Hand Held Scanner	3-4
Program the RealScan 72.....	3-4
Programming the RealScan 35/36 Hand Held Scanner.....	3-5
RealScan 37 Hand-Held Scanner	3-5
Program the RealScan 72.....	3-6
Programming the RealScan 37 Hand Held Scanner.....	3-7
Programming the RealScan 37-1000 Hand-Held Scanner ...	3-9
Metrologic MS951	3-10
Program the RealScan 72.....	3-10
Programming the Metrologic MS951.....	3-11
Verify Installation.....	3-13
Symbol Technologies LS4000	3-13
Program the RealScan 72.....	3-13
Programming the Symbol Technologies LS4000.....	3-14

Symbol Technologies LS 4071 Wireless Hand-Held Scanner	3-17
Programming the Symbol Technologies LS 4071.....	3-17
Programming the RealScan 72.....	3-18
Communication Protocol Strapping	3-19
Determine Communication Protocol.....	3-19
Strapping on the Digital Board.....	3-20
Communications Protocol.....	3-21
Scale Type	3-22
Scale Power Frequency	3-22
NCR 2170 Host Terminals	3-22
Setting up the NCR 2170 Terminal	3-22
IBM Communications	3-23
Scale Address for IBM Communications	3-23
Wincor-Nixdorf Beetle Terminal	3-24
Gilbarco Terminal.....	3-25
Wayne Terminal.....	3-26
Flash Latest Firmware.....	3-26

Chapter 4: Operation

Label Orientation.....	4-1
Active Scan Zone.....	4-2
Bar Code Quality.....	4-3
Sample Bar Codes.....	4-4
Multiple Reads	4-5
Good Read Tone	4-6
Changing Volume	4-6
Changing Frequency	4-6
Scale Zero Button.....	4-7
Cleaning Procedure.....	4-8
Scanner Body	4-9

Vertical Scan Window	4-9
Top Plate/Horizontal Scan Window	4-9
Operating Instructions.....	4-10
Not-On-File Error.....	4-10
Scanning Procedure	4-10
Turning the RealScan 72 On and Off	4-11
Scanner/Scale Models	4-11
Scanner Only Models	4-12
Weighing Procedure.....	4-12

Chapter 5: Programming

How to Program the RealScan 72.....	5-1
Creating the Program	5-1
Write the Program	5-1
Enter the Program	5-2
Save the Program.....	5-2
Programming Mode	5-3
Programming Tags	5-5
Abort.....	5-5
Default.....	5-6
End.....	5-6
Hex 0 – Hex F	5-6
Programming Mode	5-7
Save and Reset	5-7
Program Entry Example.....	5-7
Enter All Parameters	5-8
Enter Specific Parameters	5-10
Program Defaults	5-12
Programming Tips	5-15
Parameter Descriptions	5-17
Communications Protocol	5-17

Casio Dual Cable	5-17
IBM 1520 Bar Code Reader.....	5-17
IBM Hand Held Bar Code Reader.....	5-18
IBM Slot Scanner.....	5-18
OCIA NCR Dual Cable.....	5-18
OCIA NCR Long.....	5-19
OCIA NCR Short (Datachecker).....	5-19
OCIA Non-NCR Dual Cable.....	5-20
OCIA Single Cable.....	5-20
RS-232.....	5-20
TEC Dual Cable.....	5-20
Good Read tone.....	5-21
Not-On-File Tone Volume.....	5-21
Tone Frequency (Hertz).....	5-21
Tone Length (Milliseconds).....	5-21
Tone On/Off	5-22
Tone Volume	5-22
Timers	5-22
Lockout Time (Milliseconds)	5-22
Restart Lockout Timer	5-23
Active Time (Minutes)	5-23
Bar Codes-1	5-23
UPC/EAN	5-23
Version D	5-24
Extend UPC-A to EAN-13	5-24
Extend UPC-E to UPC-A	5-24
Periodical Codes	5-24
Periodical Code Extension	5-25
Send Data.....	5-25
Bar Codes-2.....	5-26
Code 39.....	5-26

Minimum Characters Allowed	5-26
Full ASCII	5-26
Check Digit Present	5-27
Transmit Check Digit	5-27
Allow 1-or 2-Character Tags	5-27
Bar Codes-3	5-27
Interleaved 2 of 5	5-28
Bar Code Length	5-28
Value 1 and 2	5-28
Check Digit Present	5-29
Transmit Check Digit	5-29
Bar Codes-4	5-29
Code 128	5-29
Minimum Data Characters Allowed	5-30
UCC 128	5-30
Partial Decoding	5-30
Tone	5-30
Tone Length	5-30
Tone Frequency	5-31
Code 128 Stitch Enable	5-31
Scans Required	5-31
Overlap Characters	5-31
Minimum Segment Size	5-31
Bar Codes-5	5-32
GS1 DataBar Enable	5-32
Scans Required on GS1 DataBar 14	5-32
Scans Required on GS1 DataBar E	5-32
UCC-128 Emulation Mode	5-33
Bar Codes-6	5-33
ISBN-10 and ISBN-13	5-33
ISSN	5-34

Label Identifiers	5-34
Identifier Type.....	5-34
Common Byte 1 and Common Byte 2	5-35
Bar Code Type.....	5-36
Common Byte.....	5-36
Unique Identifier	5-37
RS-232 Parameters-1	5-38
Baud Rate.....	5-38
Parity	5-38
Stop Bits and Character Length.....	5-39
Handshake.....	5-39
RS-232 Parameters-2	5-40
BCC Options.....	5-40
Interface Control.....	5-40
Check Digit.....	5-41
RS-232 Prefix Byte.....	5-41
Prefix Byte.....	5-42
ASCII Code.....	5-42
RS-232 Terminator Byte	5-42
Terminator Byte	5-42
ASCII Code.....	5-43
RS-232 Communications Options.....	5-43
Good Weigh Tone.....	5-43
Normal or Eavesdrop Mode	5-43
Message Delay	5-44
Scanner or Scanner/Scale Format	5-44
Scale Parameters	5-46
Model Number.....	5-46
IBM Address.....	5-46
Miscellaneous Parameters	5-47
Host Tone Control.....	5-47

IBM Retransmit Control	5-47
Enable/Disable Voice Messages.....	5-48
IBM-485 / IBM-USB Tag Data Format	5-49
Dual Cable Interface	5-49
Avery Scale Emulation.....	5-50
PACESETTER Information	5-51
PACESETTER Plus	5-51
Mode 1 – Inquiry	5-51
Mode 2 – Real Time	5-52
Mode 3 – Normal	5-54
Host Access to Tallies.....	5-56
Host Reset of Tallies	5-59
PACESETTER III	5-60
PACESETTER III Correction.....	5-61
PACESETTER III Detection.....	5-61
PACESETTER III Tallies	5-62
Firmware Flashing (for RealScan 72 SA Scanners)	5-63
Obtaining New Firmware.....	5-63
Acquiring and Installing the EasyFlash Software	5-63
Acquiring and Installing the NCR RealScan Flash Tool for Windows	5-65
Firmware Flashing Procedure	5-68
Operating EasyFlash Software.....	5-69
Operating NCR RealScan Flash Tool.....	5-71
Flash Utility Notes	5-73
Checking RealScan 72 Scanner Firmware Level	5-73
EasyFlash Firmware Flash Troubleshooting Guide.....	5-76
NCR Flash Tool Firmware Flash Troubleshooting Guide	5-80
Programming Worksheets	5-81
Communications Protocol	5-82
Single ASIC.....	5-82

Super ASIC	5-83
Good Read Tone.....	5-84
Timers	5-85
Single ASIC.....	5-85
Super ASIC	5-86
Bar Codes-1.....	5-87
Single ASIC.....	5-87
Super ASIC	5-88
Bar Codes-2.....	5-89
Bar Codes-3.....	5-90
Bar Codes-4.....	5-91
Bar Codes-5.....	5-92
Bar Codes-6.....	5-93
Label Identifiers	5-94
Number System Character	5-95
RS-232 Parameters-1	5-96
RS-232 Parameters-2	5-97
Single ASIC.....	5-97
Super ASIC	5-98
RS-232 Prefix Byte.....	5-99
RS-232 Terminator Byte	5-100
RS-232 Communications Options.....	5-101
Scale Parameters	5-101
Miscellaneous Parameters	5-102
Single ASIC.....	5-102
Super ASIC	5-103
Code 128 Tone Length	5-104
Code 128 Tone Frequency	5-104
Code 128 Tone.....	5-105
Code 128 Minimum and Maximum Tag Length.....	5-105
Code 39 Tone Length	5-106

Code 128 Stitch.....	5-106
Code 39 Tone Frequency	5-107
Code 39 Tone.....	5-107
Code 39 Quiet Zone.....	5-107
Code 39 InterCharacter Gap Check	5-108
Code 39 Halves	5-108
Code 39 Stitch.....	5-108
Code 39 CD Length1	5-109
Code 39 CD Length2	5-109
Interleaved 2 of 5 Tone Length.....	5-110
Interleaved 2 of 5 Tone Frequency	5-110
Interleaved 2 of 5 Tone.....	5-111
Interleaved 2 of 5 CD Length1	5-111
Interleaved 2 of 5 CD Length2.....	5-111
GS1 DataBar Tone Length	5-112
GS1 DataBar Tone Frequency	5-112
GS1 DataBar Tone.....	5-113
GS1 DataBar-E AI 93 to Code 39 Tag Data Conversion ..	5-113
GS1 DataBar-E AI 94 to UCC-128 Tag Data Conversion	5-113
GS1 DataBar-E AI 94 to Code-128 Tag Data Conversion	5-113
GS1 DataBar-E AI 95 to Interleaved 2 of 5 Tag Data Conversion.....	5-114
Number of Coupon Scans Required	5-114
Number of UPC/EAN Scans Required.....	5-115
Number of Code 39 Scans Required	5-115
Number of Interleaved 2 of 5 Scans Required.....	5-115
Number of Code 128 Scans Required	5-116
Number of Code 39 Overlaps Required.....	5-116
Number of Interleaved 2 of 5 Overlaps Required.....	5-116
Number of Minimum Code 39 Characters in Code 39 Partial	5-117

Number of Code 128 Overlaps Required.....	5-117
Number of Minimum Interleaved 2 of 5 Characters in Interleaved 2 of 5 Partial.....	5-117
Number of Minimum Code 128 Characters in Code 128 Partial	5-118
Command-type Disable	5-118
Ignore RS-232 Commands from POS.....	5-118
GS1 DataBar Coupon Support.....	5-118
GS1 DataBar AI 8110 coupons	5-119
EAN-13 98 coupons	5-119
EAN-13 99 coupons	5-119
Dual Cable Interface	5-120
Single ASIC.....	5-120
Special Programming.....	5-121
Speak the Programmed Bar Codes.....	5-121
Speak the Serial Number	5-121
Good Read Tone Presets	5-122
Programming Multi-Symbol Scanning.....	5-123
JAN Magazine Code.....	5-124
GS1 DataBar.....	5-124
Enable/Disable GS1 DataBar.....	5-124
Send GS1 DataBar 14 as EAN-13 Data.....	5-125
ASCII Code Chart.....	5-126

Chapter 6: Troubleshooting

Error Codes	6-1
Scanner Problems	6-3
Scale Problems	6-4

Appendix A: Additional Scale-related Diagnostic Functions

Appendix B: Scale Calibration Procedures

Appendix C: Technical Support

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*