

DS6707 Digital Imager Scanner

Product Reference Guide




Table of Contents

Revision History	iii
------------------------	-----

About This Guide

Introduction	xv
Configurations	xv
Chapter Descriptions	xv
Notational Conventions	xvi
Related Documents	xvii
Service Information	xvii
Symbol Global Interaction Center	xvii

Chapter 1: Getting Started

Introduction	1-1
Supported Interfaces	1-2
Unpacking	1-2
Setting Up the Digital Imager Scanner	1-3
Installing the Interface Cable	1-3
Removing the Interface Cable	1-3
Connecting Power (if required)	1-4
Configuring the Digital Imager Scanner	1-4
Mounting the Digital Imager Scanner	1-4
Desk Mount	1-4
Wall Mount	1-5

Chapter 2: Scanning

Introduction	2-1
Beeper Definitions	2-2
LED Definitions	2-4
Scanning in Hand-Held Mode	2-4
Scanning with the Digital Imager Scanner	2-4
Aiming	2-5
Scanning in Hands-Free Mode	2-6
Decode Zones	2-7
DS6707 Digital Imager Scanner Standard Range	2-7
DS6707 Digital Imager Scanner Document Capture	2-8

Chapter 3: Maintenance & Technical Specifications

Introduction 3-1
 Maintenance 3-1
 Troubleshooting 3-2
 Technical Specifications 3-4
 Digital Imager Scanner Signal Descriptions 3-7
 Introduction 4-1

Chapter 4: User Preferences & Miscellaneous Digital Imager Scanner Options

Scanning Sequence Examples 4-2
 Errors While Scanning 4-2
 User Preferences and Miscellaneous Options - Parameter Defaults 4-2
 User Preferences 4-4
 Set Default Parameter 4-4
 Parameter Scanning 4-4
 Beeper Tone 4-5
 Beeper Volume 4-6
 Power Mode 4-6
 Time Delay to Low Power Mode 4-7
 Trigger Mode 4-8
 Picklist Mode 4-9
 Decode Session Timeout 4-10
 Timeout Between Decodes, Same Symbol 4-10
 Decoding Illumination 4-11
 Decode Aiming Pattern 4-12
 Miscellaneous Scanner Parameters 4-13
 Transmit Code ID Character 4-13
 Prefix/Suffix Values 4-13
 Scan Data Transmission Format 4-15
 FN1 Substitution Values 4-16
 Transmit “No Read” Message 4-17

Chapter 5: Imager Preferences

Introduction 5-1
 Scanning Sequence Examples 5-1
 Errors While Scanning 5-2
 Imaging Preferences Parameter Defaults 5-2
 Imaging Preferences 5-4
 Operational Modes 5-4
 Decode Mode 5-4
 Snapshot Mode 5-4
 Video Mode 5-5
 Image Capture Autoexposure 5-5
 Image Capture Illumination 5-6
 Fixed Exposure 5-6
 Fixed Gain 5-7
 Gain / Exposure Priority for Snapshot Mode 5-7

Snapshot Mode Timeout	5-8
Snapshot Aiming Pattern	5-9
Image Cropping	5-9
Crop to Pixel Addresses	5-10
Image Size (Number of Pixels)	5-11
Image Brightness (Target White)	5-12
JPEG Image Options	5-12
JPEG Target File Size	5-13
JPEG Quality and Size Value	5-13
Image Enhancement	5-14
Image File Format Selector	5-15
Bits Per Pixel	5-16
Signature Capture	5-17
Output File Format	5-17
Signature Capture File Format Selector	5-18
Signature Capture Bits Per Pixel	5-19
Signature Capture Width	5-20
Signature Capture Height	5-20
Signature Capture JPEG Quality	5-20
Video View Finder	5-21
Target Video Frame Size	5-21
Video View Finder Image Size	5-22

Chapter 6: SSI Interface

Introduction	6-1
Connecting Using Simple Serial Interface	6-2
Simple Serial Interface Default Parameters	6-3
SSI Host Parameters	6-4
Baud Rate	6-4
Parity	6-6
Check Parity	6-7
Software Handshaking	6-7
Host RTS Line State	6-8
Decode Data Packet Format	6-8
Stop Bit Select	6-9
Host Serial Response Time-out	6-10
Host Character Time-out	6-11
Multipacket Option	6-12
Interpacket Delay	6-13
Event Reporting	6-14
Decode Event	6-14
Boot Up Event	6-15
Parameter Event	6-15

Chapter 7: USB Interface

Introduction	7-1
Connecting a USB Interface	7-2
USB Parameter Defaults	7-3
USB Host Parameters	7-4
USB Device Type	7-4
Symbol Native API (SNAPI) Status Handshaking	7-5
USB Country Keyboard Types (Country Codes)	7-6
USB Keystroke Delay	7-8
USB CAPS Lock Override	7-8
USB Ignore Unknown Characters	7-9
Emulate Keypad	7-9
Emulate Keypad with Leading Zero	7-10
USB Keyboard FN 1 Substitution	7-10
Function Key Mapping	7-11
Simulated Caps Lock	7-11
Convert Case	7-12
ASCII Character Set for USB	7-12

Chapter 8: RS-232 Interface

Introduction	8-1
Connecting an RS-232 Interface	8-2
RS-232 Parameter Defaults	8-3
RS-232 Host Parameters	8-4
RS-232 Host Types	8-6
Baud Rate	8-7
Parity	8-9
Stop Bit Select	8-10
Data Bits	8-10
Check Receive Errors	8-11
Hardware Handshaking	8-11
Software Handshaking	8-13
Host Serial Response Time-out	8-15
RTS Line State	8-16
Beep on <BEL>	8-16
Intercharacter Delay	8-17
Nixdorf Beep/LED Options	8-18
Ignore Unknown Characters	8-18
ASCII Character Set for RS-232	8-19

Chapter 9: 123Scan

Introduction	9-1
123Scan Parameter	9-2

Chapter 10: Symbolologies

Introduction	10-1
Scanning Sequence Examples	10-1
Errors While Scanning	10-2
Symbology Parameter Defaults	10-2
UPC/EAN	10-6
Enable/Disable UPC-A	10-6
Enable/Disable UPC-E	10-6
Enable/Disable UPC-E1	10-7
Enable/Disable EAN-8/JAN-8	10-7
Enable/Disable EAN-13/JAN-13	10-8
Enable/Disable Bookland EAN	10-8
Decode UPC/EAN/JAN Supplementals	10-9
UPC/EAN/JAN Supplemental Redundancy	10-10
Transmit UPC-A Check Digit	10-11
Transmit UPC-E Check Digit	10-11
Transmit UPC-E1 Check Digit	10-12
UPC-A Preamble	10-12
UPC-E Preamble	10-13
UPC-E1 Preamble	10-14
Convert UPC-E to UPC-A	10-14
Convert UPC-E1 to UPC-A	10-15
EAN-8/JAN-8 Extend	10-15
UCC Coupon Extended Code	10-16
Code 128	10-17
Enable/Disable Code 128	10-17
Enable/Disable UCC/EAN-128	10-17
Enable/Disable ISBT 128	10-18
Code 39	10-19
Enable/Disable Code 39	10-19
Enable/Disable Trioptic Code 39	10-19
Convert Code 39 to Code 32	10-20
Code 32 Prefix	10-20
Set Lengths for Code 39	10-21
Code 39 Check Digit Verification	10-22
Transmit Code 39 Check Digit	10-23
Code 39 Full ASCII Conversion	10-23
Code 39 Buffering (Scan & Store)	10-24
Buffer Data	10-24
Clear Transmission Buffer	10-25
Transmit Buffer	10-25
Overfilling Transmission Buffer	10-26
Attempt to Transmit an Empty Buffer	10-26
Code 93	10-27
Enable/Disable Code 93	10-27
Set Lengths for Code 93	10-27
Code 11	10-29
Code 11	10-29
Set Lengths for Code 11	10-29

Code 11 Check Digit Verification	10-30
Transmit Code 11 Check Digits	10-31
Interleaved 2 of 5 (ITF)	10-32
Enable/Disable Interleaved 2 of 5	10-32
Set Lengths for Interleaved 2 of 5	10-32
I 2 of 5 Check Digit Verification	10-34
Transmit I 2 of 5 Check Digit	10-34
Convert I 2 of 5 to EAN-13	10-35
Discrete 2 of 5 (DTF)	10-36
Enable/Disable Discrete 2 of 5	10-36
Set Lengths for Discrete 2 of 5	10-36
Codabar (NW - 7)	10-38
Enable/Disable Codabar	10-38
Set Lengths for Codabar	10-38
CLSI Editing	10-40
NOTIS Editing	10-40
MSI	10-41
Enable/Disable MSI	10-41
Set Lengths for MSI	10-41
MSI Check Digits	10-42
Transmit MSI Check Digit(s)	10-43
MSI Check Digit Algorithm	10-43
Postal Codes	10-44
US Postnet	10-44
US Planet	10-44
UK Postal	10-45
Transmit UK Postal Check Digit	10-45
Japan Postal	10-46
Australian Postal	10-46
Dutch Postal	10-47
Transmit US Postal Check Digit	10-47
RSS (Reduced Space Symbology)	10-48
RSS-14	10-48
RSS Limited	10-48
RSS Expanded	10-49
Convert RSS to UPC/EAN	10-49
Composite	10-50
Composite CC-C	10-50
Composite CC-A/B	10-50
Composite TLC-39	10-51
UPC Composite Mode	10-51
Composite Beep Mode	10-52
UCC/EAN Code 128 Emulation Mode for UCC/EAN Composite Codes	10-52
2D Symbologies	10-53
Enable/Disable PDF417	10-53
Enable/Disable MicroPDF417	10-53
Code 128 Emulation	10-54
Data Matrix	10-55
Maxicode	10-55

QR Code	10-56
Redundancy Level	10-57
Redundancy Level 1	10-57
Redundancy Level 2	10-57
Redundancy Level 3	10-57
Redundancy Level 4	10-58
Security Level	10-59
Intercharacter Gap Size	10-60
Report Version	10-61
Macro PDF Features	10-61
Flush Macro Buffer	10-61
Abort Macro PDF Entry	10-61

Chapter 11: Advanced Data Formatting

Introduction	11-1
Rules: Criteria Linked to Actions	11-1
Using ADF Bar Codes	11-2
ADF Bar Code Menu Example	11-2
Rule 1: The Code 128 Scanning Rule	11-3
Rule 2: The UPC Scanning Rule	11-3
Alternate Rule Sets	11-3
Rules Hierarchy (in Bar Codes)	11-4
Default Rules	11-5
Special Commands	11-5
Pause Duration	11-5
Begin New Rule	11-5
Save Rule	11-6
Erase	11-6
Quit Entering Rules	11-6
Disable Rule Set	11-7
Criteria	11-8
Code Types	11-8
Code Lengths	11-14
Message Containing A Specific Data String	11-18
Specific String at Start	11-18
Specific String, Any Location	11-19
Any Message OK	11-19
Numeric Keypad	11-20
Rule Belongs To Set	11-22
Actions	11-23
Send Data	11-23
Setup Field(s)	11-26
Move Cursor	11-27
Send Pause	11-27
Skip Ahead	11-28
Skip Back	11-29
Send Preset Value	11-31
Modify Data	11-31

Remove All Spaces	11-31
Crunch All Spaces	11-31
Stop Space Removal	11-32
Remove Leading Zeros	11-32
Stop Zero Removal	11-32
Pad Data with Spaces	11-33
Pad Data with Zeros	11-37
Beeps	11-42
Send Keystroke (Control Characters and Keyboard Characters)	11-42
Control Characters	11-42
Keyboard Characters	11-47
Send ALT Characters	11-61
Send Keypad Characters	11-66
Send Function Key	11-71
Send Right Control Key	11-78
Send Graphic User Interface (GUI) Characters	11-79
Turn On/Off Rule Sets	11-84
Alphanumeric Keyboard	11-86

Appendix A: Standard Default Parameters

Appendix B: Programming Reference

Symbol Code Identifiers	B-1
AIM Code Identifiers	B-3

Appendix C: Sample Bar Codes

Code 39	C-1
UPC/EAN	C-1
UPC-A, 100%	C-1
EAN-13, 100%	C-2
Code 128	C-2
Interleaved 2 of 5	C-2
RSS 14	C-3
PDF417	C-3
Data Matrix	C-3
Maxicode	C-4
QR Code	C-4
US Postnet	C-4
UK Postal	C-5

Appendix D: Numeric Bar Codes

Numeric Bar Codes D-1
Cancel D-2

Appendix E: ASCII Character Sets

Glossary

Index

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Symbol/DS6707 Product Reference Guide manu](https://the-checkout-tech.com/manuals/Symbol/DS6707%20Product%20Reference%20Guide%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)