




Product Reference Guide



Contents

About This Guide


Introductionxi
Chapter Descriptionsxi
Notational Conventions	xiii
Related Publications	xiii
Service Information	xiii
Symbol Support Center	xiv

Chapter 1. Getting Started

Introduction	1-1
Unpacking Your Scanner	1-2
Setting Up the Scanner	1-3
Installing the Interface Cable	1-3
Connecting Power (if required)	1-4
Synapse Interface	1-4
Connecting a Synapse Cable Interface	1-6
Configuring Your Scanner	1-6
Removing the Interface Cable	1-7

Chapter 2. Scanning

Introduction	2-1
Scanning in Single-Line Mode	2-2
Scanning in Omni Mode	2-3
Beeper Definitions	2-7
Selecting Beeper Volume using Trigger	2-8
LED Definitions	2-9
Aiming	2-10
Decode Zone	2-11
Integrated Electronic Article Surveillance (EAS)	2-12



Deactivation Antenna for Checkpoint EAS Systems	2-12
EAS Deactivation Range	2-12
LS 9208 Host Interface Cables and EAS.	2-13
Different Checkpoint EAS Models	2-13
Checkpoint Contact Information.	2-13
Mounting Template	2-15

Chapter 3. Maintenance and Technical Specifications

Introduction	3-1
Maintenance	3-1
Troubleshooting	3-2
Technical Specifications	3-4
Scanner Signal Descriptions	3-7

Chapter 4. User Preferences

Introduction	4-1
Scanning Sequence Examples	4-2
Errors While Scanning	4-2
User Preferences Default Parameters	4-3
User Preferences	4-5
Set Default Parameter	4-5
Beeper Tone	4-6
Beeper Volume	4-7
Volume Change Trigger Delay.	4-8
Laser On Time	4-9
Beep After Good Decode.	4-10
Low Power Blink	4-11
Scan Pattern Mode	4-12
Single-Line Aim Duration	4-13
Timeout Between Decodes	4-15
Time Delay to Low Power Mode	4-16
Linear UPC/EAN Decode.	4-18

Chapter 5. Keyboard Wedge Interface

Introduction	5-1
Connecting a Keyboard Wedge Interface	5-2
Keyboard Wedge Default Parameters	5-3
Keyboard Wedge Host Types	5-4
Keyboard Wedge Host Types	5-4
Keyboard Wedge Country Types (Country Codes)	5-6
Ignore Unknown Characters	5-10


Keystroke Delay	5-11
Intra-Keystroke Delay	5-12
Alternate Numeric Keypad Emulation	5-13
Caps Lock On	5-14
Caps Lock Override	5-15
Convert Wedge Data	5-16
Function Key Mapping	5-17
FN1 Substitution	5-18
Send Make Break	5-19
Keyboard Maps	5-20
ASCII Character Set	5-23

Chapter 6. RS-232 Interface

Introduction	6-1
Connecting an RS-232 Interface	6-3
RS-232 Default Parameters	6-3
RS-232 Host Parameters	6-5
RS-232 Host Types	6-7
Baud Rate	6-10
Parity	6-12
Check Receive Errors	6-14
Hardware Handshaking	6-15
Software Handshaking	6-18
Host Serial Response Time-out	6-21
RTS Line State	6-23
Stop Bit Select	6-24
Data Bits	6-25
Beep on <BEL>	6-26
Intercharacter Delay	6-27
Nixdorf Beep/LED Options	6-29
Ignore Unknown Characters	6-30
ASCII / Character Set	6-31

Chapter 7. USB Interface

Introduction	7-1
Connecting a USB Interface	7-2
USB Default Parameters	7-4
USB Host Parameters	7-5
USB Device Type	7-5
USB Country Keyboard Types (Country Codes)	7-6
USB Keystroke Delay	7-10
USB CAPS Lock Override	7-11



USB Ignore Unknown Characters	7-12
Emulate Keypad	7-13
USB Keyboard FN1 Substitution	7-14
Function Key Mapping	7-15
Simulated Caps Lock	7-16
Convert Case	7-17
ASCII Character Set	7-18

Chapter 8. IBM 468X/469X Interface

Introduction	8-1
Connecting to an IBM 468X/469X Host	8-2
IBM Default Parameters	8-3
IBM 468X/469X Host Parameters	8-4
Port Address	8-4
Convert Unknown to Code 39	8-6

Chapter 9. Wand Emulation Interface

Introduction	9-1
Connecting Using Wand Emulation	9-2
Wand Emulation Default Parameters	9-3
Wand Emulation Host Parameters	9-4
Wand Emulation Host Types	9-4
Leading Margin (Quiet Zone)	9-5
Polarity	9-6
Ignore Unknown Characters	9-7
Convert All Bar Codes to Code 39	9-8
Convert Code 39 to Full ASCII	9-9


Chapter 10. 123Scan

Introduction	10-1
Communication With the 123Scan PC Based Configuration Tool	10-1
123Scan Parameter	10-2

Chapter 11. Symbologies

Introduction	11-1
Scanning Sequence Examples	11-2
Errors While Scanning	11-2
Symbology Default Parameters	11-3
UPC/EAN	11-8
Enable/Disable UPC-A/UPC-E	11-8

Enable/Disable UPC-E1	11-9
Enable/Disable EAN-13/JAN-13/EAN-8/JAN-8	11-10
Enable/Disable Bookland EAN	11-11
Decode UPC/EAN Supplementals	11-12
UPC/EAN Supplemental Redundancy	11-15
Transmit UPC-A/UPC-E/UPC-E1 Check Digit	11-16
UPC-A Preamble	11-18
UPC-E Preamble	11-19
UPC-E1 Preamble	11-20
Convert UPC-E to UPC-A	11-21
Convert UPC-E1 to UPC-A	11-22
EAN Zero Extend	11-23
UCC Coupon Extended Code	11-24
Code 128	11-25
Enable/Disable Code 128	11-25
Enable/Disable UCC/EAN-128	11-26
Enable/Disable ISBT 128	11-27
Code 128 Decode Performance	11-28
Code 128 Decode Performance Level	11-29
Code 39	11-30
Enable/Disable Code 39	11-30
Enable/Disable Trioptic Code 39	11-31
Convert Code 39 to Code 32	11-32
Code 32 Prefix	11-33
Set Lengths for Code 39	11-34
Code 39 Check Digit Verification	11-36
Transmit Code 39 Check Digit	11-37
Enable/Disable Code 39 Full ASCII	11-38
Code 39 Buffering (Scan & Store)	11-39
Code 39 Decode Performance	11-43
Code 39 Decode Performance Level	11-44
Code 93	11-45
Enable/Disable Code 93	11-45
Set Lengths for Code 93	11-46
Code 11	11-48
Code 11	11-48
Set Lengths for Code 11	11-49
Code 11 Check Digit Verification	11-51
Transmit Code 11 Check Digits	11-52
Interleaved 2 of 5 (ITF)	11-53
Enable/Disable Interleaved 2 of 5	11-53
Set Lengths for Interleaved 2 of 5	11-54
I 2 of 5 Check Digit Verification	11-56
Transmit I 2 of 5 Check Digit	11-57



Convert 1 2 of 5 to EAN-13	11-58
Discrete 2 of 5 (DTF)	11-59
Enable/Disable Discrete 2 of 5	11-59
Set Lengths for Discrete 2 of 5	11-60
Chinese 2 of 5	11-62
Enable/Disable Chinese 2 of 5	11-62
Codabar (NW - 7)	11-63
Enable/Disable Codabar	11-63
Set Lengths for Codabar	11-64
CLSI Editing	11-66
NOTIS Editing	11-67
MSI	11-68
Enable/Disable MSI	11-68
Set Lengths for MSI	11-69
MSI Check Digits	11-71
Transmit MSI Check Digit(s)	11-72
MSI Check Digit Algorithm	11-73
RSS (Reduced Space Symbology)	11-74
RSS 14	11-74
RSS Limited	11-75
RSS Expanded	11-76
Convert RSS to UPC/EAN	11-77
Symbology - Specific Security Levels	11-80
Redundancy Level	11-80
Security Level	11-83
Symbology - Intercharacter Gap	11-85

Chapter 12. Miscellaneous Scanner Options

Introduction	12-1
Scanning Sequence Examples	12-2
Errors While Scanning	12-2
Miscellaneous Default Parameters	12-3
Miscellaneous Scanner Parameters	12-4
Transmit Code ID Character	12-4
Prefix/Suffix Values	12-5
FN1 Substitution Values	12-8
Scan Data Options	12-9
Transmit "No Read" Message	12-12


Chapter 13. Advanced Data Formatting

Introduction	13-1
Rules: Criteria Linked to Actions	13-1
Using ADF Bar Codes	13-2
ADF Bar Code Menu Example	13-2
Rule 1: The Code 128 Scanning Rule	13-3
Rule 2: The UPC Scanning Rule	13-4
Alternate Rule Sets	13-4
Rules Hierarchy (in Bar Codes)	13-5
Default Rules	13-6
Special Commands	13-7
Pause Duration	13-7
Begin New Rule	13-7
Save Rule	13-8
Erase	13-8
Quit Entering Rules	13-9
Disable Rule Set	13-10
Criteria	13-12
Code Types	13-12
Code Lengths	13-20
Message Containing A Specific Data String	13-30
Actions	13-34
Send Data	13-34
Setup Field(s)	13-42
Modify Data	13-53
Pad Data with Zeros	13-66
Beeps	13-76
Send Keystroke (Control Characters and Keyboard Characters)	13-77
Send Right Control Key	13-162
Send Graphic User Interface Characters	13-163
Turn On/Off Rule Sets	13-175
Alphanumeric Keyboard	13-178

Appendix A. Standard Default Parameters

Appendix B. Programming Reference

Symbol Code Identifiers	B-1
AIM Code Identifiers	B-3



Appendix C. Sample Bar Codes

Code 39C-1
UPC/EANC-1
UPC-A, 100 %C-1
EAN-13, 100 %C-2
Code 128C-2
Interleaved 2 of 5C-2
RSS 14C-3

Appendix D. Numeric Bar Codes

0, 1D-1
2, 3, 4D-2
5, 6, 7D-3
8, 9D-4
CancelD-5

Glossary

Index

Feedback

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/Symbol/LS9208> Product Reference Guide manu

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)