

# ***SE-955***

## *Integration Guide*

# Contents

## About This Guide

Chapter Descriptions .....	xii
Notational Conventions .....	xii
Service Information .....	xii
Symbol Support Center .....	xiii

## Chapter 1. Getting Started

Overview .....	1-3
Theory of Operation .....	1-3
Scan Engine .....	1-3
Microprocessor .....	1-4
Simple Serial Interface (SSI) .....	1-5
Power Management .....	1-5
Electrical Interface .....	1-7
Beeper Definitions .....	1-9

## Chapter 2. Installation

Introduction .....	2-3
Grounding .....	2-3
ESD .....	2-3
Environment .....	2-3
Mounting .....	2-4
Installing the SE-955 .....	2-5
Optical .....	2-6

Housing Design	2-6
Wavefront Distortion	2-6
Collection Beam Geometry	2-7
Laser Clear Aperture	2-7
Collection Clear Aperture	2-8
Exit Window Materials	2-8
Color	2-9
Surface Quality	2-9
Commercially Available Coatings	2-9
Location and Positioning	2-10
Symbol Position with Respect to a Fixed-Mount Scan Engine	2-11
Exit Window Characteristics	2-12
Accessories	2-15
Flex Cables	2-15
Scan Engine Developer's Kit	2-17
Regulatory Requirements	2-18

### Chapter 3. Replacing Existing Engines

General Information	3-3
Replacing an SE-824 with the SE-955 Scan Engine	3-3
Mounting	3-3
Electrical	3-3
Optical	3-4
Regulatory	3-4
Replacing an SE-923 with the SE-955 Scan Engine	3-5
Mounting	3-5
Electrical	3-5
Optical	3-6
Regulatory	3-6
Replacing an SE-1223WA with the SE-955 Scan Engine	3-7
Mounting	3-7
Electrical	3-7
Optical	3-8
Regulatory	3-8

### Chapter 4. SE-955-I000W/E000W Specifications

Overview	4-3
Technical Specifications	4-3
Decode Zone	4-6

## Chapter 5. SE-955-I005W Specifications

Overview .....	5-3
Technical Specifications .....	5-3
Decode Zone .....	5-6

## Chapter 6. Regulatory Requirements

Regulatory Requirements .....	6-2
Required Documentation for Class 1 Laser Products .....	6-2
Required Documentation for Class 2 Laser Products .....	6-2
Required Documentation for all End Products .....	6-3
Required Labelling for Class 1 End Products .....	6-4
Required Labelling for Class 2 End Products .....	6-5
RoHS Compliance .....	7

## Chapter 7. Application Notes

Overview .....	7-3
AC Electrical Characteristics .....	7-3
Timing Waveforms .....	7-4
Explanation Of The AC Symbols .....	7-4

## Chapter 8. Parameter Menus

Introduction .....	8-5
Operational Parameters .....	8-5
Set Default Parameter .....	8-10
Default Parameters .....	8-10
Beeper Volume .....	8-11
Beeper Tone .....	8-12
Beeper Frequency Adjustment .....	8-12
Laser On Time .....	8-13
Aim Duration .....	8-13
Scan Angle .....	8-14
Power Mode .....	8-14
Triggering Modes .....	8-16
Time-out Between Same Symbol .....	8-17
Beep After Good Decode .....	8-17
Transmit "No Read" Message .....	8-18
Parameter Scanning .....	8-18
Linear Code Type Security Level .....	8-19
Bi-directional Redundancy .....	8-20
UPC/EAN .....	8-21
Enable/Disable UPC-A .....	8-21
Enable/Disable UPC-E .....	8-21
Enable/Disable UPC-E1 .....	8-22
Enable/Disable EAN-8 .....	8-22
Enable/Disable EAN-13 .....	8-23
Enable/Disable Bookland EAN .....	8-23
Decode UPC/EAN Supplementals .....	8-24

Decode UPC/EAN Supplementals (continued)	8-25
Decode UPC/EAN Supplemental Redundancy	8-25
Transmit UPC-A Check Digit	8-26
Transmit UPC-E Check Digit	8-26
Transmit UPC-E1 Check Digit	8-27
UPC-A Preamble	8-28
UPC-E Preamble	8-29
UPC-E1 Preamble	8-30
Convert UPC-E to UPC-A	8-31
Convert UPC-E1 to UPC-A	8-31
EAN Zero Extend	8-32
Convert EAN-8 to EAN-13 Type	8-32
UPC/EAN Security Level	8-33
UCC Coupon Extended Code	8-34
Code 128	8-35
Enable/Disable Code 128	8-35
Enable/Disable UCC/EAN-128	8-35
Enable/Disable ISBT 128	8-36
Lengths for Code 128	8-36
Code 39	8-37
Enable/Disable Code 39	8-37
Enable/Disable Trioptic Code 39	8-37
Convert Code 39 to Code 32 (Italian Pharma Code)	8-38
Code 32 Prefix	8-38
Set Lengths for Code 39	8-39
Code 39 Check Digit Verification	8-40
Transmit Code 39 Check Digit	8-40
Enable/Disable Code 39 Full ASCII	8-41
Code 93	8-42
Enable/Disable Code 93	8-42
Set Lengths for Code 93	8-43
Code 11	8-44
Enable/Disable Code 11	8-44
Set Lengths for Code 11	8-44
Code 11 Check Digit Verification	8-46
Transmit Code 11 Check Digits	8-46
Interleaved 2 of 5	8-48
Enable/Disable Interleaved 2 of 5	8-48
Set Lengths for Interleaved 2 of 5	8-49
I 2 of 5 Check Digit Verification	8-50
Transmit I 2 of 5 Check Digit	8-51
Convert I 2 of 5 to EAN-13	8-51
Discrete 2 of 5	8-52
Enable/Disable Discrete 2 of 5	8-52
Set Lengths for Discrete 2 of 5	8-53
Chinese 2 of 5	8-54
Enable/Disable Chinese 2 of 5	8-54

Codabar .....	8-55
Enable/Disable Codabar .....	8-55
Set Lengths for Codabar .....	8-56
CLSI Editing .....	8-57
NOTIS Editing .....	8-57
MSI .....	8-58
Enable/Disable MSI .....	8-58
Set Lengths for MSI .....	8-59
MSI Check Digits .....	8-60
Transmit MSI Check Digit .....	8-60
MSI Check Digit Algorithm .....	8-61
RSS .....	8-62
Enable/Disable RSS-14 .....	8-62
Enable/Disable RSS-Limited .....	8-62
Enable/Disable RSS-Expanded .....	8-63
Transmit Code ID Character .....	8-64
Prefix/Suffix Values .....	8-65
Scan Data Transmission Format .....	8-66
Scan Data Transmission Format (continued) .....	8-67
Serial Parameters .....	8-68
Baud Rate .....	8-68
Parity .....	8-70
Software Handshaking .....	8-71
Decode Data Packet Format .....	8-72
Host Serial Response Time-out .....	8-72
Stop Bit Select .....	8-73
Intercharacter Delay .....	8-73
Host Character Time-out .....	8-73
Event Reporting .....	8-74
Decode Event .....	8-74
Boot Up Event .....	8-75
Parameter Event .....	8-75
Numeric Bar Codes .....	8-76
Cancel .....	8-77

## Chapter 9. Simple Serial Interface

Introduction.....	9- 3
Communications.....	9-3
SSI Message Formats.....	9-5
AIM_OFF.....	9-5
AIM_ON.....	9-6
BEEP.....	9-7
CMD_ACK.....	9-9
CMD_NAK.....	9-10
DECODE_DATA.....	9-12
EVENT.....	9-14
LED_OFF.....	9-15
LED_ON.....	9-16
PARAM_DEFAULTS.....	9-17
PARAM_REQUEST.....	9-18
PARAM_SEND.....	9-20
REPLY_REVISION.....	9-22
REQUEST_REVISION.....	9-24
SCAN_DISABLE.....	9-25
SCAN_ENABLE.....	9-26
SLEEP.....	9-27
START_DECODE.....	9-28
STOP_DECODE.....	9-29
WAKEUP.....	9-30
SSI Transactions.....	9-31
General data transactions.....	9-31
Transfer of Decode Data.....	9-31
Communication Summary.....	9-33
RTS/CTS Lines.....	9-33
ACK/NAK Option.....	9-33
Number of Data Bits.....	9-33
Serial Response Time-out.....	9-33
Retries.....	9-33
Baud Rate, Stop Bits, Parity, Response Time-out, ACK/NAK Handshake.....	9-33
Errors.....	9-33
SSI Communication Notes.....	9-33

## Appendix A. Serial Interface Specification

Purpose.....	A- 3
Terms and Definitions.....	A-3
Systems.....	A-3
Inactive.....	A-3
The Decoder and the Host.....	A-3
A Character.....	A-3
Data.....	A-3
Tolerances.....	A-3

Common Attributes ..... A-3  
    The Decoder ..... A-4  
    The Host ..... A-6  
Transaction Examples ..... A-7

**Appendix B. Miscellaneous Code Information**

Introduction ..... B- 3  
UCC/EAN-128 ..... B-3  
AIM Code Identifiers ..... B-5  
Setting Code Lengths Via Serial Commands ..... B-8  
Setting Prefixes and Suffixes Via Serial Commands ..... B-9

**Glossary**



This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Symbol/SE-955 Integration guide manual.html](https://the-checkout-tech.com/manuals/Symbol/SE-955%20Integration%20guide%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)