


# SHARP SERVICE MANUAL

CODE : 00ZDP730SM/-E



## SERIAL DOT MATRIX PRINTER

### MODEL DP-730

#### CONTENTS

Section 1 Using and Maintaining the Printer	1
Section 2 Specifications and Principle Operation	2
Section 3 Disassembly and Re-assembly	11
Section 4 Troubleshooting	28
Section 5 Timing Chart	35
Parts Lists : (K1-0B6778RCZZ)	

This document has been published to be used for after sales service only.  
The contents are subject to change without notice.

SHARP CORPORATION



## Foreword

This manual describes the principle of operation and the maintenance procedure for DP730 Series Citizen Dot Matrix Printers. It is intended for maintenance technicians in the field.

## Features

The DP730 series printers are station printers that are provided with a 45 mm × 2 printing function. These printers have been developed for POS/ECR use. They have the following features.

- \* A high performance 9-pin head is provided, realizing a high printing speed of 3.0 lines/second and high print quality.
- \* The printer is compact, light and low priced. This has been realized as a result of rational mechanical design.
- \* A clamshell mechanism (opening and closing mechanism of the paper guide) is employed, resulting in improved paper loading performance and maintainability.
- \* A pull type paper feed mechanism is employed for minimizing paper jams.
- \* A wide range of option mechanisms is available.

(Stamp, auto cutter, take-up unit, paper feed unit, validation sensor, receipt/journal near end sensor.)

# Table of Contents

---

Section 1	Using and Maintaining the Printer .....	1
Section 2	Specifications and Principle of Operation .....	2
2-1	General Specifications .....	2
2-2	Outline of Mechanisms .....	4
2-3	Mechanisms and Principle of Operation .....	4
2-3-1	Power transmission mechanism .....	4
2-3-2	Sensor mechanism .....	4
2-3-3	Print head mechanism .....	5
2-3-4	Paper feed mechanism .....	6
2-3-5	Ribbon cassette mechanism .....	6
2-3-6	Paper take-up mechanism .....	7
2-3-7	Stamp mechanism .....	8
2-3-8	Auto cutter mechanism (option) .....	8
2-4	External Connectors .....	9
2-4-1	Terminal layout .....	9
2-4-2	Terminal function .....	9
2-4-3	Terminal circuit diagram .....	10
Section 3	Disassembly and Re-assembly .....	11
3-1	List of Tools and Measuring Instruments .....	11
3-2	Disassembly Procedure .....	11
3-3	Assembly Procedure .....	11
3-4	Adjustment Procedure .....	23
3-4-1	Printing speed adjustment .....	23
3-4-2	Platen/head gap adjustment .....	24
3-4-3	Bi-directional printing error adjustment .....	24
3-4-4	RP/HP waveform confirmation .....	25
3-4-5	Validation sensor adjustment .....	25
3-4-6	Paper near end sensor adjustment .....	25
3-5	Replacing the Head Assembly .....	26
3-5-1	Removal procedure .....	26
3-5-2	Assembly procedure .....	27
Section 4	Troubleshooting .....	29
4-1	Repair Procedure .....	29
4-2	Repair Guide .....	29
Section 5	Timing Chart .....	35
Parts Lists		

---

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](#)