

***TM-T88IV***

**Technical reference  
guide**

English

410528700

**EPSON**

---

# Contents

## Chapter 1 **Product Overview**

Features .....	1-1
Product Structure .....	1-2
Model .....	1-2
Accessories.....	1-2
Options.....	1-2
Consumable products .....	1-2
TM-T88IV Basic Specification Table .....	1-3
Part Names and Basic Operation .....	1-3
Part Names .....	1-3
Control Panel.....	1-4
Power Switch.....	1-5
Connectors.....	1-5
Handling the Printer .....	1-5
Installing and Replacing Roll Paper .....	1-6
Removing Jammed Paper .....	1-7
Cleaning the Thermal Head .....	1-8
Power Switch Cover.....	1-9
Connector Cover.....	1-9
Shipping Procedures .....	1-10

## Chapter 2 **Setup**

Installing the Printer.....	2-2
Precautions for Horizontal Installation.....	2-2
Precautions for Wall Installation .....	2-2
Setting the DIP Switches .....	2-2
DIP Switch Positions and Steps for Changing DIP Switch Settings .....	2-2
DIP Switch Functions.....	2-3
Customized value.....	2-6
Adjusting the Roll Paper Near-End Detector.....	2-6
Connecting the Printer to the Host Computer .....	2-8
Serial Interface Connection .....	2-8
Parallel Interface Connection .....	2-10
USB Interface Connection .....	2-11
Ethernet Interface Connection .....	2-13
Wireless LAN Interface Connection .....	2-15
Connecting Power Supply Unit and Cash Drawer .....	2-15
Connecting the Power Supply Unit.....	2-15
Connecting the Drawer Kick-out Cable .....	2-16
Installing the Driver.....	2-16

### Chapter 3 **Application Development Information**

Introducing the Control Methods .....	3-1
Windows Driver (EPSON Advanced Printer Driver) .....	3-1
EPSON OPOS ADK .....	3-3
ESC/POS Commands .....	3-6
Various Utilities .....	3-6
Switches and Buttons .....	3-6
FEED Button .....	3-7
Panel LEDs and Error Status .....	3-7
(POWER) LED .....	3-7
PAPER OUT LED .....	3-7
Error LED .....	3-8
Sensors .....	3-10
Paper Sensors .....	3-10
Printer Cover Sensor .....	3-10
Offline .....	3-11
Busy State .....	3-11
NVRAM (Non-volatile Memory) .....	3-12
Bar Code Printing .....	3-12
Notes on Printing 2-Dimensional Code .....	3-13
Two-color printing .....	3-13
Operating Mode (Switch Panel Operation) .....	3-13
Self-test Mode .....	3-13
FAQ List .....	3-14
Q: Why has my print data dropped out? .....	3-14
Q: Why does the drawer kick-out not operate properly? .....	3-14
Q: I cannot print part of Page 0 in Visual Basic. Why? .....	3-15

### Chapter 4 **ESC/POS Command-related Information**

NV Memory (Non-volatile Memory) .....	4-1
Using NV Memory .....	4-1
Printer Status .....	4-2
Precautions When the Printer Is Offline .....	4-2
Outputting Hex Dumps .....	4-2

### Chapter 5 **Product Specifications**

Product Specifications (TM-T88IV) .....	5-1
Print Specifications (TM-T88IV) .....	5-2
Character Specifications (TM-T88IV) .....	5-3
Paper Specifications (TM-T88IV) .....	5-3
Printable Area (TM-T88IV) .....	5-4
Print Position versus Cutter Position (TM-88IV) .....	5-5
Overview of External Dimensions (TM-T88IV) .....	5-6
External Dimensions .....	5-6
Operating Specifications (TM-T88IV) .....	5-7

### Appendix A **Interfaces and Connectors**

RS-232 Serial Interface .....	A-1
Interface Board Specifications (RS-232-compliant) .....	A-1
Functions of each Connector Pin .....	A-2
XON/XOFF .....	A-2
Code .....	A-3
IEEE 1284 Parallel Interface .....	A-3
Modes .....	A-3
Interface Signals .....	A-5

**Appendix B Options and Consumables**

Roll Paper.....	B-1
Power Supply .....	B-1
PS-180.....	B-1

**Appendix C Character Code Tables**

Page 0 (PC437: USA, Standard Europe) .....	C-1
Page 1 (Katakana).....	C-2
Page 2 (PC850: Multilingual) .....	C-3
Page 3 (PC860: Portuguese).....	C-4
Page 4 (PC863: Canadian-French) .....	C-5
Page 5 (PC865: Nordic) .....	C-6
Page 16 (WPC1252).....	C-7
Page 17 (PC866: Cyrillic #2).....	C-8
Page 18 (PC852: Latin2) .....	C-9
Page 19 (PC858: Euro) .....	C-10
Page 255 (Blank Page) .....	C-11
International Character Set .....	C-12

**Appendix D TM-T88IV/TM-88III Comparison Table**

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)