

HV-G series HW-G series

INSTRUCTION MANUAL

Digital Platform Scale

HV-15KGL HV-15KGV

HV-60KGL HV-60KGV

HV-200KGL HV-200KGV

HW-10KGL HW-10KGV

HW-60KGL HW-60KGV

HW-100KGL HW-100KGV

HW-200KGL HW-200KGV

HW-300KGL4 HW-300KGV4

HW-600KGL4 HW-600KGV4

HW-600KGL3 HW-600KGV3

HW-1200KGL3 HW-1200KGV3



A&D Company, Limited



Contents

1.	Compliance	3
1.1.	Compliance with FCC rules.....	3
2.	Outline and Features	4
3.	Unpacking	5
3.1.	Accessories and Options List.....	7
4.	Precautions.....	9
4.1.	Installing the Scale	9
4.2.	Operating the Scale	9
4.3.	Storing the Scale	9
5.	Installing the Scale.....	10
5.1.	Setting up the Scale	10
5.1.1.	Procedure A.....	10
5.1.2.	Procedure B.....	11
5.1.3.	Procedure C.....	12
5.2.	Installing the Batteries for Type L	13
5.3.	Removing the Pole	14
5.3.1.	Procedure A.....	14
5.3.2.	Procedure B	15
5.4.	Grounding the scale	16
6.	Description of Each Part	17
6.1.	Display and Symbols	19
6.2.	Keys	21
7.	Basic Operation	23
7.1.	Turning the Scale on/off and Weighing	23
7.1.1.	Type V or Type L with AC Adapter	23
7.1.2.	Type L with Batteries	24
7.2.	Tare (And Net Display).....	25
7.2.1.	Tare Input by Weighing.....	25
7.2.2.	Digital Input (Preset Tare).....	25
7.3.	Weighing Range for the HV-G Series.....	26
7.4.	Mode Key (Changing Unit and Mode).....	27
8.	Counting Mode.....	29
8.1.	Storing a Unit Mass	29
8.2.	Counting the Number of Articles	30
9.	Percentage Mode.....	31
9.1.	Storing a 100% Mass	31
9.2.	Reading the Percentage	32
10.	Accumulation Function	33
10.1.	Preparation (Setting Parameters)	34
10.2.	Operation and Performance (Examples).....	35

11.	Upper/Lower Comparator Function.....	36
11.1.	Preparation (Setting Parameters)	37
11.2.	Operation and Performance (Examples).....	39
12.	Full/Dribble Batch Function.....	40
12.1.	Preparation (Setting Parameters)	42
13.	Simple Batch Function.....	44
13.1.	Preparation (Setting Parameters)	45
13.2.	Operation and Performance (Examples).....	46
14.	Calibration (Adjusting the Scale).....	47
14.1.	Gravity Acceleration Table.....	48
14.2.	Complete Calibration Procedure	49
14.2.1.	Gravity Acceleration Correction	49
14.2.2.	Preparation	49
14.2.3.	Calibration of the Zero Point	50
14.2.4.	Span Calibration	50
15.	Function Table	51
15.1.	Parameter Setting Procedure.....	51
15.2.	Parameter List.....	52
16.	RS-232C Serial Interface	56
16.1.	Data Format	57
16.2.	Stream Mode.....	59
16.2.1.	Preparation and Performance (Examples).....	59
16.3.	Command Mode	60
16.3.1.	Command List.....	60
16.3.2.	Example of Setting Parameters	63
17.	Options	64
17.1.	Extension Load Cell Cable (OP-02)	64
17.2.	RS-232C/ Relay Output/ Buzzer (OP-03)	66
17.3.	RS-422/ RS-485 / Relay Output (OP-04)	68
17.3.1.	Communication Format.....	71
17.3.2.	Command List.....	71
17.4.	Built-in Printer for Type V (OP-06)	74
18.	Specifications	76
19.	Maintenance	81
19.1.	Check Points Before Calling Maintenance Service	81
19.1.1.	Repair	81

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/AnD/HV-G and HW-G Series instruction manual>.

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)