



# DL-N SERVICE MANUAL

## < Table of Contents >

<b>1. Introduction .....</b>	<b>4</b>
1.1. Preface.....	4
1.2. Precaution.....	4
1.3. Specifications .....	5
1.3.1. DLN Specifications.....	5
1.4. Key.....	5
1.5. Sealing Method.....	6
<b>2. Calibration .....</b>	<b>7</b>
2.1. General Calibration .....	7
2.1.1. C4 Setting .....	8
2.1.1.1. C4-1 Setting .....	8
2.1.1.2. C4-2 Setting .....	8
2.1.1.3. C4-3 Setting .....	8
2.1.1.4. C4-4 Setting .....	9
2.1.1.4. C4-5 Setting .....	9
2.1.1.6. C4-6 Setting .....	9
2.1.2. SPAN Calibration Setting (C-3) .....	10
2.1.3. Percent SPAN Calibration Setting (C-7).....	10
2.1.4. Gravity Constant Value Setting (C-9) .....	10
2.1.5. Displaying Real A/D Value (C-5).....	11
2.1.6. How to confirm SPAN calibrated A/D value (C-1).....	11
2.1.7. To delete the linearity calibration value(C-6) .....	11
2.1.8. Back to the normal weighing mode (C-0).....	12
2.1.9. Calibration Block Diagram .....	13
<b>3. The Schematics and Diagram .....</b>	<b>14</b>
3.1. System Block Diagram .....	14
3.2. Circuit Diagram.....	15
3.2.1. Main.....	15
3.2.2. A/D.....	16
3.2.3. POWER.....	17
3.2.4. CALIBRATION .....	18
<b>4. Exploded View .....</b>	<b>19</b>
<b>5. Part Location .....</b>	<b>20</b>
5.1. Main PCB .....	20

<b>5.2. ANALOG PCB .....</b>	<b>21</b>
<b>6. Error Messages &amp; Solution .....</b>	<b>22</b>
<b>6.1. Beep: Re-zero .....</b>	<b>22</b>
<b>6.2. Err: Initial Zero.....</b>	<b>22</b>
<b>6.3. Init: Failure of Analog Module .....</b>	<b>22</b>
<b>6.4. UNSTA: A/D Value Unstable .....</b>	<b>22</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/DL-N service and calibration manual.html](https://the-checkout-tech.com/manuals/CAS/DL-N%20service%20and%20calibration%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)