



ER SERVICE MANUAL

< Table of Contents >

| | | |
|-----------------|--|-----------|
| 1. | Introduction..... | 5 |
| 1.1. | Preface..... | 5 |
| 1.2. | Precaution..... | 5 |
| 1.3. | Specification | 6 |
| 1.3.1. | Kilogram (kg) Version | 6 |
| 1.3.2. | Pound (lb) Version | 7 |
| 1.4. | LCD Version | 8 |
| 1.5. | VFD Version..... | 8 |
| 1.6. | LED Version | 8 |
| 1.7. | Dimension | 9 |
| 1.8. | Sealing Method..... | 10 |
| 2. | Calibration..... | 12 |
| 2.1. | General Calibration..... | 12 |
| 2.1.1. | C4 Setting..... | 13 |
| 2.1.1.1. | C4-1 Setting..... | 13 |
| 2.1.1.2. | C4-2 Setting..... | 13 |
| 2.1.1.3. | C4-3 Setting..... | 13 |
| 2.1.1.4. | C4-4 Setting..... | 14 |
| 2.1.1.5. | C4-5 Setting..... | 14 |
| 2.1.2. | SPAN Calibration Setting (C-3)..... | 15 |
| 2.1.3. | Gravity Constant Value Setting (C-9)..... | 15 |
| 2.1.4. | Calibration factor Setting (C-10) | 16 |
| 2.1.5. | Displaying Real A/D Value (C-5)..... | 16 |
| 2.1.6. | Input Function Key Code (C-6) | 17 |
| 2.1.7. | Percent Calibration (C-7)..... | 18 |
| 2.1.8. | Battery Calibration (C-8)..... | 18 |
| 3. | The Schematics and Diagram..... | 19 |
| 3.1. | System Block Diagram..... | 19 |
| 3.2. | Circuit Diagram..... | 20 |
| 3.2.1. | LCD Version..... | 20 |
| 3.2.1.1. | Main | 20 |
| 3.2.1.2. | Power part..... | 21 |
| 3.2.1.3. | Display Part | 22 |
| 3.2.1.4. | Key Part..... | 23 |
| 3.2.1.5. | Pole front display Part..... | 24 |

| | | |
|-------------------------|---|----|
| 3.2.1.6. | Pole rear display Part..... | 25 |
| 3.2.1.7. | Front display Part | 26 |
| 3.2.1.8. | Rear display Part | 27 |
| 3.2.1.9. | RS232 Part..... | 28 |
| 3.2.2. | LED Version | 29 |
| 3.2.2.1. | Main | 29 |
| 3.2.2.2. | Power part..... | 30 |
| 3.2.2.3. | Key Part..... | 31 |
| 3.2.2.4. | Pole front display Part..... | 32 |
| 3.2.2.5. | Pole rear display Part..... | 33 |
| 3.2.2.6. | Front display Part | 34 |
| 3.2.2.7. | Rear display Part | 35 |
| 3.2.2.8. | RS232 Part..... | 36 |
| 3.2.3. | VFD Version..... | 37 |
| 3.2.3.1. | Main | 37 |
| 3.2.3.2. | Power part..... | 38 |
| 3.2.3.3. | Key Part..... | 39 |
| 3.2.3.4. | Pole front display Part..... | 40 |
| 3.2.3.5. | Pole rear display Part..... | 41 |
| 3.2.3.6. | Front display Part | 42 |
| 3.2.3.7. | Rear display Part | 43 |
| 3.2.3.8. | RS232 Part..... | 44 |
| 4. | Exploded View..... | 45 |
| 5. | Load Cell drawing..... | 47 |
| 6. | Part Location..... | 48 |
| 6.1. | LCD Version | 48 |
| 6.1.1.1. | Main PCB Part Location | 48 |
| LCD MAIN | | 48 |
| 6.1.1.2. | FRONT DISPLAY PCB Part Location..... | 49 |
| LCD FRONT DISPLAY | | 49 |
| 6.1.1.3. | REAR DISPLAY PCB Part Location | 50 |
| LCD REAR DISPLAY | | 50 |
| 6.1.1.4. | POLE DISPLAY PCB Part Location | 51 |
| LCD FRONT DISPLAY | | 51 |
| LCD REAR DISPLAY | | 52 |
| 6.1.2. | VFD Version..... | 53 |
| 6.1.2.1. | Main PCB Part Location | 53 |
| VFD MAIN | | 53 |
| 6.1.2.2. | VFD FRONT DISPLAY PCB Part Location | 54 |

| | |
|--|-----------|
| VFD FRONT DISPLAY | 54 |
| 6.1.2.3. VFD REAR DISPLAY PCB Part Location | 55 |
| VFD REAR DISPLAY | 55 |
| 6.1.2.4. POLE DISPLAY PCB Part Location | 56 |
| VFD POLE DISPLAY TYPE #1 | 56 |
| VFD POLE DISPLAY TYPE #2 | 57 |
| 6.1.3. LED Version | 58 |
| 6.1.3.1. Main PCB Part Location | 58 |
| 6.1.3.2. FRONT DISPLAY PCB Part Location | 59 |
| 6.1.3.3. REAR DISPLAY PCB Part Location | 60 |
| 6.1.4. COMMON PCB | 61 |
| 6.1.4.1. RS-232 MODULE PCB Part Location | 61 |
| RS-232 PCB (TOP) | 61 |
| RS-232 PCB (BOTTOM) | 61 |
| 6.1.4.2. KEY PCB Part Location (Pb) | 62 |
| KEY PCB | 62 |
| 7. Error Messages & Solution | 63 |
| 8. Part List | 64 |

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/ER and ER PLUS Service manual.html](https://the-checkout-tech.com/manuals/CAS/ER%20and%20ER%20PLUS%20Service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)