



DC-200/300

Counting Scale

Version 1.37

Service Manual



1.0 Overview	2
1.1 DC-200/300 Specifications	2
1.2 Keyboard and Display	3
1.2.1 Annunicators	4
1.2.2 Key Functions	4
1.3 Interface Ports	7
1.4 Capacities and Resolutions	7
2.0 Installation	8
2.1 Unpacking	8
2.2 Repacking	9
2.3 Setting Up	9
2.4 Powering Up the DC-200/300	9
2.5 Initialize Scale Specifications	10
2.6 Start-Up Screens	11
2.7 Calibration (Span Adjustment)	12
2.8 Setting Time and Date	15
2.9 Configuration Settings	15
2.9.1 Configuring Specification 141 and 142 Settings from the Scale Keyboard	15
2.9.2 Configuring Spec 141 and 142 Settings Using the Spec Upload Utility	27
2.10 Modes of Operation	36
3.0 Maintenance	37
3.1 Hardware Testing	37
3.1.1 RAM and Communications Port Testing	37
3.1.2 Internal Test Count	41
3.1.3 Span Switch Status Test	41
3.1.4 Voltage Checkpoints	41
3.2 Internal Printer Tests and Adjustments (DC-300 only)	42
3.2.1 Checking or Rezeroing the Thermal Head Usage Counter	42
3.2.2 Adjusting the Printer Label Gap Sensor	43
3.2.3 Adjusting the Printing Position	45
3.3 Clearing the Scale Memory	45
3.4 Technical Drawings	47
3.4.1 DC-300 Exploded View	47
3.4.2 DC-300 Block Diagram	48
3.4.3 DC-200 Block Diagram	49
4.0 Assembly/Disassembly of the DC-200/300	50
4.1 Removing the Main Cover	50
4.2 Disconnecting the Display Board	51
4.3 Disconnecting the Keyboard Circuit Board	52
4.4 Removing the Interface Main Board	53
4.5 Removing the Printer Drawer Block (DC-300 only)	54
4.6 Removing the Thermal Print Head (DC-300 only)	55
5.0 Network and Interfaces: External Printers	57
5.1 Connecting an External Printer to the Scale	57
5.1.1 Spec Settings for External Printers	57
5.1.2 Connecting the Printer to the RS-232C Port	58
5.2 Eltron Printers	59
5.2.1 Set the Computer Serial Port	59
5.2.2 Designing a Label	60
5.2.3 Saving the Label Format You Have Made	64

5.2.4 Downloading the Label Format From the Computer to the Eltron Printer	67
5.2.5 Predesigned Label Formats for Eltron Printers	68
5.2.6 Testing to See What Label Format or Graphic is in the Eltron Printer's Memory	73
5.2.7 Printing to the Eltron Printer from the DC-200/300 Scale	75
5.3 Epson Printers	76
6.0 Network and Interfaces: Connection to a PC	77
6.1 Ethernet Connection	77
6.1.1 Checking the Scale's IP Address.....	77
6.1.2 Machine Setup Utility.....	77
6.1.3 Changing the IP Address Directly on the Scale	78
6.1.4 Ethernet Cable Connection Between the Scale and the Computer	79
6.1.5 Setting the Computer's Network Communication	79
6.1.6 Entering the Data Transfer Mode on the Scale.....	81
6.1.7 Exiting The Data Transfer Mode on the Scale	82
6.1.8 Pinging the Scale to Test the Ethernet Connection	83
6.2 RS-232 Connection	84
6.2.1 Spec Settings for RS-232C Connection to a PC	84
6.2.2 Connecting the PC to the RS-232C Port	85
6.2.3 Configuring Communication Between the Scale and the Computer	86
6.2.4 Setting HyperTerminal to Capture Data Coming From the Scale.....	86
6.2.5 Sending Data from the Scale to HyperTerminal	87
6.2.6 Scale Data Header Codes	87
6.2.7 Requesting Data From the Scale Using HyperTerminal	88
7.0 Network and Interfaces: Scanners, Keyboards, Balances.....	89
7.1 Connecting an IBM Keyboard	89
7.2 Connecting a Barcode Scanner	90
7.2.1 Header Codes.....	90
7.2.2 Z Commands via Barcodes	91
7.2.3 Configuring the RS-232C Port for a Scanner	91
7.2.4 Connecting the Scanner to the RS-232C Port	92
7.2.5 Configuring the Keyboard Port for a Scanner	92
7.2.6 Programming the QSC-6000 Plus Quickscan RS-232C Scanner	93
7.2.7 Programming the QuickScan Keyboard Wedge Scanner.....	98
7.3 Connecting a Force Balance	99
7.3.1 Spec Settings for Force Balance	99
7.3.2 Connecting the Force Balance to the RS-232C Port	100
8.0 Firmware Upgrade	101
8.1 Determining Your Current Firmware Version Number	101
8.2 Installing the WinDload Software	101
8.3 Setting Up the WinDload Software	104
8.4 Connecting the DC-200/300 Scale to the Computer	108
8.5 Downloading Firmware to the Scale	109
9.0 Appendix	112
9.1 DC-200/300 Error Message List	112
9.2 Appendix - Rezero Functions	114
9.3 Character Code Tables	116
9.3.1 ASCII Code	116
9.3.2 Teraoka Codes	118

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*