



Service Manual for DS-781/782(RS)

Edition	Month	Year
1st	Sep.	2008
2nd		
3rd		
4th		
5th		

SHANGHAI TERAOKA ELECTRONIC CO., LTD.

Ting Lin Industrial Development Zone, Jin Shan District, Shanghai P. R. China 201505
Tel: +86-21-5723-4888 Fax: +86-21-5723-4090 Web: www.digi-scale.com

Contents

1. General Layout	5
1.1. Bench Type	5
1.2. Pole Type	6
2. Purpose	7
3. Features	7
4. Operating Conditions.....	8
5. Analog Specification	8
6. Capacity/Minimum Graduation/Tare range	8
6.1. Single Interval	8
6.2. Multi-Interval	8
7. Display and Indicators	9
7.1. Display Specifications.....	9
7.2. <i>Indicators</i>	9
8. Dimensions.....	9
9. External Connectors	9
10. Main Components	9
11. Existing parts to be used	9
12. Keysheet Layout.....	9
13. Key Functions.....	10
13.1. Type A (11 Preset keys)	10
13.2. Type B (15 Preset keys)	10
14. Block Diagram of Electrical Connection.....	11
15. Physical layout of Electrical Connection.....	13
16. Hardware Description.....	14
16.1. Microcomputer	14
16.2. Pin Assignment	15
17. <i>Maintenance Mode</i>	16
17.1. <i>SPAN Switch and Software Version Check</i>	16
17.2. <i>SPAN Adjustment</i>	16
17.2.1. <i>Full capacity weight for SPAN Adjustment</i>	16
17.2.2. <i>Proportion of capacity weight for SPAN Adjustment</i>	17
17.3. <i>Escape from Maintenance mode</i>	17
17.4. <i>Specification Setting</i>	18
17.4.1. <i>Specification Enter (141)</i>	18
17.4.2. <i>Specification Enter (142)</i>	18
17.5. <i>Internal Count & A/D Count Display</i>	19
17.6. <i>Tax Setting</i>	19
17.7. <i>Operational Specification List</i>	19
18. <i>Operations In Weighing Mode</i>	25
18.1. <i>ON/OFF</i>	25
18.2. <i>Tare Subtraction</i>	25
18.2.1. <i>One Touch Tare Subtraction</i>	25
18.2.2. <i>Digital Tare Subtraction</i>	25
18.3. <i>Plural Operation</i>	26
18.3.1. <i>Standard Version</i>	26
18.3.2. <i>Japan Type A Version</i>	26

<i>18.3.3. Japan Type B Version</i>	26
18.4. Multiplication Operation	27
18.4.1. Standard Version	27
18.4.2. Japan Type A Version	27
18.4.3. Japan Type B Version	27
18.5. AMT/TEND Key Operation	28
18.5.1. Method A (Direct entry method: SPEC30.1 = 1)	28
18.5.2. Method B (Indirect entry method: SPEC30.1 = 0)	28
18.6. Correction Of Past Sales Data	28
18.7. Price Base Change By 100g/kg Key	29
18.8. Auto Zero Operation	29
18.9. kg and lb conversion by UNIT Key	29
18.10. kg, decimal lb and kati conversion by UNIT Key	30
18.11. Currency Conversion by EURO Key	30
18.11.1. Currency Conversion Operation Method 1 (SPEC4.32 = 01)	30
18.11.2. Currency Conversion Operation Method 2 (SPEC4.32 = 10)	30
19. Operations of Mode Set Key	31
19.1. Mode Change Using Mode Set Key	31
19.2. PLU Setting	31
19.3. Preset Key Setting	31
19.3.1. Preset Key Setting when PLU function is allowed.	31
19.3.2. Preset Key Setting when PLU function is inhibited.	32
19.4. Conversion Rate Setting	32
19.5. Invert Currency Conversion Function	32
19.6. Cancel Currency Conversion Function	33
20. RS-232C Interface	33
20.1. Specification	33
20.2. Pin Assignment	33
20.3. Control Code and Characters	33
20.4. Data Format	35
20.5 Communication Method	36
20.5.1 Type A (Standard Stream)	37
20.5.2 Type W (Standard Manual)	38
20.5.3 Type B (Standard Command)	39
21. Error Message List	39

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net