



2200
2200B
2200CW

INSTRUCTION MANUAL

DORAN SCALES, INC.
1315 PARAMOUNT PKWY.
BATAVIA, IL 60510
1-800-262-6844
FAX: (630) 879-0073
<http://www.doranscales.com>
MANUAL REVISION: 10.0
MAN0253 1/6/2011
Software: DSW0141 Rev 1.3



Table of Contents

Introduction	8
Unpacking Your Scale.....	9
Electrical Connections.....	9
Scale Operation	10
Fig. 1: Model 2200 Front Panel Layout	10
Fig. 2: Model 2200B Front Panel Layout.....	10
Fig. 3: Model 2200CW Front Panel Layout	11
LED Annunciators	12
Power Up and Power Down	13
Software Part Number and Revision Level.....	13
ZERO Displayed Weight	13
Push Button Tare	14
Digital Tare Entry.....	14
Tare Recall.....	14
Clear Stored Tare Value.....	14
Barcode Entry of Tare Value	15
Toggle Gross and Net Modes	15
Toggle Displayed Weight Units	15
Data String Output to Printer or Other Device	15
Communications Menu.....	16
Password Protected Setpoint, Preact, (Tare and Check Limit 2200CW) Values.....	16
Display Setpoint Values	16
Change Setpoint Values.....	17
Barcode Entry of Setpoint Values.....	17
Display Preact Values	17
Change Preact Values	18
Barcode Entry of Preact Values	18
Over, Under and Accept Checkweighing Operation (2200CW).....	18
Five Band Checkweighing Operation (2200CW optional configuration).....	18
Display Check Limit Values (2200CW).....	19
Change Check Limit Values (2200CW).....	19
Barcode Entry of Check Limit Values (2200CW).....	19
Display Accumulator and Counter Values	20
Clear Accumulator and Counter	20
Accumulator and Counter Data String Output to Printer or Other Device.....	20
Accumulator and Counter Operation.....	20
Product Size Menu (2200CW).....	21
Product ID number (2200CW, one product setting).....	21
Product ID number (2200CW, 250 product setting).....	21
Product ID Fields (2200CW, 250 product setting)	21
Check Way Software (optional).....	21
QC Weigh Software (optional).....	21
Entering a New Product ID number (2200CW, 250 product setting)	21
Recall Existing Product ID (2200CW, 250 product setting)	22
Delete Product ID (2200CW, 250 product setting)	22
Product ID Field Password Protection (2200CW, 250 product setting)	22
Barcode Entry to recall Product ID Field (2200CW, 250 product setting).....	23

Display Product ID Values (2200 series, one product setting)	23
Keypad Entry of Product ID Values (2200 series, one product setting).....	23
Barcode Entry of Product ID Values.....	24
Display Data Field Values	24
Keypad Entry of Data Field Values.....	24
Barcode Entry of Data Field Values	24
Setting Time and Date.....	25
User ID login	25
Barcode Entry of User ID Values.....	26
User ID Logout.....	26
Battery Operation	27
Installation Guide	28
Fig. 6: Load Cell connections	28
Removing the Rear Panel	28
Replacing the Rear Panel	28
Load Cell and Power Connections	28
Multiple Load Cell Connections.....	29
RS232 and Remote Switch Connections	29
Fig. 7: Serial, Remote Switch and power Connections.....	29
Calibration Mode	30
Power-up Front Panel Setup Mode Access.....	30
Front Panel Setup Mode Access.....	30
Switch Setup Mode Access.....	30
Exiting the Setup Mode	30
Select Scale Resolution	31
Zero and Span Calibration	31
A/D Range Troubleshooting.....	33
Table 1: Calibration requirements in raw counts	33
Parameter Setup Mode.....	34
Power-up Front Panel Setup Mode Access.....	34
Front Panel Setup Mode Access.....	34
Switch Setup Mode Access.....	34
Exiting the Setup Mode	34
Stepping Through Menu Parameters	35
Changing Parameter Settings	35
Parameter Review of Calibration and Setup Values	35
Legal for Trade Restrictions	35
Calibration and Audit Counters	36
Resetting the scale parameters:.....	36
Parameter Configuration	37
Capacity Setup Menu	38
Count By Setup Menu	38
Calibration Menu	38
Digital Filter Setup Menu	39
Automatic Zero Tracking Setup Menu	39
Motion Aperture Setup Menu.....	39
Start Up Zero Setup Menu	40
Tare Entry Menu.....	40

Latching Zero Request Setup Menu.....	40
Latching Print Request Setup Menu.....	40
Printer Data Output Setup Menu	41
Output Formats, Port 1	42
Output Formats, Port 2.....	42
Baud Rate Setup Menu	43
Handshaking Setup Menu	43
Bluetooth Menu (Bluetooth option only)	43
Scale Address (Scale ID number)	44
Serial Input Data Strip Prefix and Postfix for Barcode Scanner (Port 2).....	44
Units Conversion Setup Menu.....	45
Start Up Units Selection Menu	45
Push-button Function Setup Menu	46
Operating Mode Setup Menu	48
Alarm Countdown timer (oP = ALt only)	48
Unit On Timer (Battery option only)	48
Product Size Menu (2200CW).....	49
Checkweighing Operation Menu (2200CW)	49
Setpoint and Preact Operation Menu	50
Threshold Level Menu.....	51
Default all Scale Parameter settings	51
ISP Mode	51
Test Mode Menu	52
Calibration and Parameter Menu Exit.....	53
Batch Commands (2200B).....	54
Default Batch Sequence.....	57
Batch Configuration.....	57
Learning Preact.....	58
Fig. 8: Learning Preact Formula	58
Learning Preact Batch sequence example.....	58
Learning Preact Configuration.....	58
Data Communications.....	59
Standard Print String Formats	59
Custom Data String Configuration.....	63
Custom Data String Control Characters	64
Remote Setpoint / Preact / Limit Entry and Recall.....	66
Remote Product ID Entry and Recall:.....	66
Remote Product Description Entry and Recall:	67
Remote Tare Entry and Recall:	67
Remote Data Field Entry and Recall:	68
Print Buffer:	68
Table 2: Doran serial protocol	72
Specifications and Interconnect Data	73
Specifications:	73
Table 3: Scale Specifications	73
Interconnect Data:.....	73
Table 4: TB1 Load Cell Connections.....	73
Table 5: P2 Options Connections.....	74
Fig. 10: RS232 Output DB9 Connector (optional)	74

Table 6: Serial Output pin description	74
Table 7: J6 External Supply Connections.....	75
Table 8: J1 Power Connections.....	75
Fig. 11: Installation of EMI / RFI / ESD protection devices.	75
Fig. 12: Jumpers and Connector Locations.....	76
Table 9: Board Jumper Settings.....	76
Fuse Replacement:	77
Table 10: Line Fuse Values.....	77
Fig. 13: F1 Fuse Holder.....	77
4-20mA Analog Output Option.....	78
Introduction	78
Setup.....	78
Fig. 14.1: 4-20mA Analog Option Board.....	78
Operation and Output Signals.....	79
Fig. 14.2: Example of an Active 4-20mA circuit.....	79
Fig. 14.3: Example of a Passive 4-20mA circuit.....	79
RS485 Communications Option.....	80
Fig. 15: Digital Output Board with RS485 Option	81
RS485 SETUP	81
Table 11: RS485 Option Specification.....	82
Table 12: RS485 Termination Resistors.....	83
Fig. 16: RS485 two wire system.....	83
Internal Relay Option	84
Fig. 17: Digital Output TB4 Terminal	84
Fig. 18: Internal Relay Board.....	85
Internal Relay Setup:.....	85
Relay Specifications:.....	85
Table 13: Internal Relay Output Cable Color Code	86
Step-up Relay Circuit:	86
External Relay Box Option	87
Fig. 20: External Relay Box.....	87
Fig. 21: Knock-out Plugs	88
External Relay Setup:.....	88
Fig. 22: Mechanical Relay Module	88
Table 14: Scale Signal Cable Color Code.....	89
Digital Output Setup:	89
Fig. 23: Digital Output Wire and Jumper locations.....	89
Digital Output Specifications:	89
Wired Ethernet Option	91
Fig. 24: RJ-45 Ethernet connector.....	91
Specifications:	91
Doran Wired Ethernet Configuration Guide	92
Module LED Description.....	94
Wireless 802.11b Ethernet Option	95
Fig. 25: Wireless Ethernet Antenna.....	95
Features and Applications.....	95
Specifications:	96
Doran Wireless Ethernet Configuration Guide	97

Module LED Description.....	100
Doran Wireless 802.11b Ethernet Option.....	101
Factory Configuration Data Sheet.....	101
WPA – Pre-Shared Key.....	102
WPA – Authentication	102
Factory Configuration Data Sheet.....	102
Connecting to a scale through a web page	103
Defaulting Wired and Wireless Ethernet Modules	104
USB Option.....	108
Fig. 26: USB option board.....	108
USB Windows Drivers.....	108
Installation For Windows XP:	108
Removal For Windows XP:	111
Installation For Windows 2000:	112
Removal For Windows 2000:	116
Dimension Software	118
Description:	118
QC Weigh Software	119
Description:	119
Scale Configuration:	119
Operation:	119
Barcode Scanner	121
Fig. 27: QS2500, EXOPT178.....	121
QS2500 Setup Connections.....	121
Fig. 28: QS2500 wiring connections.....	121
QS2500 Scanner Resetting Defaults.....	121
Fig. 29: QS2500 Default Settings Barcode.....	122
QS2500 Scanner Configuration	122
Fig. 30: PS7000, EXOPT177.....	122
PS7000 Setup Connections	122
Fig. 31: PS7000 wiring connections	123
PS7000 Scanner Resetting Defaults.....	123
Fig. 32: PS7000 Default Settings Barcode	123
PS7000 Scanner Configuration.....	123
Fig. 33: Configuration Barcode.....	123
Barcode Scanner Test.....	124
Fig. 34: 123456 Barcode	124
Fig. 35: Barcode Examples	124
Panel Mount Option.....	125
Fig. 36: Enclosure Dimensions.....	125
Fig. 37: Mounting Dimensions.....	126
Bluetooth Option	127
Bluetooth Option	127
Computer Setup	127
Bluetooth USB Dongle	127
Scale Setup.....	127
Jumper Settings	127
Pairing Devices (Scale).....	127

PIN Code.....	127
Dropping Connections.....	127
Printing Bluetooth Module Address	128
Requesting Bluetooth Module Address	128
Display Bluetooth Module Address (Run mode).....	128
Display Bluetooth Module Address (Cal mode).....	128
Detecting Other Bluetooth Addresses (Cal mode).....	128
Testing Bluetooth Module.....	129
Bluetooth Specifications	129
Basic Communications for Modbus.....	130
Troubleshooting	131
General problem resolution:	131
Scale Messages:.....	132
Error Messages:.....	133

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Doran/2200 2200B 2200CW instruction manual.h](https://the-checkout-tech.com/manuals/Doran/2200%202200B%202200CW%20instruction%20manual.h)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)