



Ohaus Corporation
19A Chapin Road
P.O. Box 2033
Pine Brook, NJ 07058-2033 USA
www.ohaus.com

TROOPER SCALE

SERVICE MANUAL

TABLE OF CONTENTS

CHAPTER 1 INTRODUCTION

	Page
1.1 Overview of Controls and Display Functions	1-1
1.2 Introduction	1-2
1.3 Service Facilities	1-2
1.4 Tools and Test Equipment Required	1-3
1.4.1 Special Tools	1-3
1.4.2 Standard Tools and Test Equipment	1-3
1.5 Test Masses Required	1-3
1.6 Specifications	1-4

CHAPTER 2 THEORY OF OPERATION

2.1 Trooper Theory of Operation	2-1
2.2 Loadcell Theory	2-1
2.3 Printed Circuit Board Theory	2-1
2.3.1 Power Supply Circuit	2-1
2.3.2 Power Monitor Circuit	2-1
2.3.3 Microprocessor	2-2
2.3.4 MELSI	2-2
2.3.5 Memory Storage	2-2
2.3.6 LCD Display Information	2-2
2.3.7 Display On/Off	2-2
2.3.8 A/D Converter	2-2
2.3.9 Load Cell Excitation Voltage	2-2
2.3.10 RS232 Operation	2-2

CHAPTER 3 TROUBLESHOOTING

3.1 Troubleshooting	3-1
3.2 Diagnostic Guide	3-1
3.2.1 Diagnosis	3-1
3.3 Error Codes	3-3

CHAPTER 4 MAINTENANCE PROCEDURES

4.1 Preventive Maintenance	4-1
4.1.1 Preventive Maintenance Checklist	4-1
4.2 Testing	4-1
4.2.1 Operational Test	4-1
4.2.1.1 Segment Display Test	4-1
4.2.2 Menu Structure	4-2
4.2.3 Trooper Switch Functions	4-3
4.2.4 Trooper Scale Menu Operation	4-3
4.2.4.1 How to Enter the Menus	4-3
4.2.4.2 How to Select a Specific Menu	4-3
4.2.4.3 How to Enter an Individual Menu	4-4
4.2.4.4 How to Enter an Individual Menu Item	4-4
4.2.4.5 How to Save and Store an Individual Menu Item	4-4

TABLE OF CONTENTS (Cont.)

CHAPTER 4 MAINTENANCE PROCEDURES (Cont.)	Page
4.2.4.6 How to Quit the Menus	4-4
4.2.5 Calibration	4-4
4.2.6 Legal for Trade (LFT) Operation and LFT Sealing	4-9
4.2.7 Performance Tests	4-10
4.2.7.1 Repeatability Test	4-10
4.2.7.2 Off-Center Load Test	4-11
4.2.7.3 Linearity Test	4-11
4.2.8 RS232 Interface Test	4-13
4.2.8.1 Connecting the RS232 Interface	4-13
4.2.9 Print Test	4-14
4.3 Repair Procedures	4-15
4.3.1 Replacing the Keypad Membrane	4-15
4.3.2 Replacing the PC Board	4-16
4.3.3 Replacing the Spider Assembly (Loadcell)	4-18

CHAPTER 5 DRAWINGS AND PARTS LISTS

5.1 Drawings and Parts Lists.....	5-1
5.1.1 Trooper Exploded View	5-2

TABLE OF CONTENTS (Cont.)

LIST OF TABLES

TABLE NO.	TITLE	PAGE NO.
1-1	Trooper Calibration Masses kg	1-3
1-2	Trooper Model Specifications	1-4
1-3	Trooper General Specifications	1-4
3-1	Diagnostic Guide	3-2
3-2	Error Codes	3-3
4-1	Calibration Masses	4-5
4-2	Types of performance Tests	4-10
4-3	Linearity Test Masses	4-11
4-4	RS232 Commands	4-14
5-1	Trooper Parts List	5-3

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
2-1	Trooper Block Diagram	2-3
4-1	Segment Displays	4-1
4-2	Trooper Scale Menu	4-2
4-3	Lock Switch Location	4-9
4-4	Sealing the Scale with a Lead Seal	4-9
4-5	Sealing the Scale with a Paper Seal	4-9
4-6	Off-Center Load Test mass Locations	4-11
4-7	RS232 Interface Pin Connections	4-13
4-8	Connector Locations	4-16
4-9	RS Connector and Loadcell Connector Wiring	4-17
4-10	Trooper Component Locations	4-19
5-1	Exploded View of Trooper Scale	5-2
5-2	Trooper Scale Interconnection Diagram	5-4
5-3	Keypad Wiring Diagram	5-4

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ohaus/Trooper service manual.html](https://the-checkout-tech.com/manuals/ohaus/Trooper%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)