

1203
WEIGHT
TRANSMITTER
Reference
Manual

For use with Software
Versions 1.x

TABLE OF CONTENTS

1. INTRODUCTION	4
1.1. Document Conventions.....	4
2. SPECIFICATIONS	5
3. INSTALLATION	6
3.1. Introduction	6
3.2. Power Supply.....	6
3.3. Load Cell Signals and Scale Build	6
3.4. Cable Shield Connection and Earthing	6
3.5. Load Cell Connection.....	7
3.5.1. 6-Wire Connection	7
3.5.2. 4-Wire Connections.....	8
3.6. Intrinsic Safety	9
3.7. Serial Communication Ports.....	9
3.7.1. Serial 1: RS-232 Port	10
3.7.2. Serial 2: RS-485 Port	10
3.7.3. Multi-Drop Networking.....	11
3.7.4. RS-232 Connection.....	11
3.7.5. RS-485 Connection.....	12
3.8. Input / Output: Setpoints	13
3.9. Input / Output: Inputs	14
3.10. Analog Output.....	15
3.11. LEDs	15
3.12. 1203 Viewer Software	15
4. CONTROLS	16
5. DIGITAL SETUP	17
5.1. Introduction	17
5.2. Basic Weighing Terminology.....	17
5.3. Direct mV/V Operation	18
5.4. Filtering Techniques.....	18
5.4.1. FIR Filter	18
5.4.2. Digital Averaging.....	18
6. CALIBRATION	19
6.1. Introduction	19
6.2. Digital Calibration with Test Weights.....	19
6.2.1. Digital Zero Calibration Routine	19
6.2.2. Digital Span Calibration Routine.....	19
6.3. Digital Direct mV/V Calibration.....	20
6.3.1. Digital Zero Calibration Routine	20
6.3.2. Digital Span Calibration Routine.....	20
6.4. Analog Output Calibration	20
6.4.1. Analog Calibration Routine.....	20
7. SERIAL OUTPUTS	21
7.1. Introduction	21
7.2. Automatic Weight Output	21
7.3. Networking the 1203	21
7.3.1. RS-485 Termination Resistors	21
8. EXTENDED FUNCTIONS	22
8.1. Setpoints.....	22
8.1.1. Introduction	22

8.1.2.	Status Indication.....	22
8.1.3.	Connection	22
8.1.4.	Operation	22
8.1.5.	Example 1: Control Level of Product in 2000kg Tank.....	23
8.1.6.	Example 2: Control Weighing of Product Out of Silo into 100kg Drums	23
8.2.	Remote Input	23
9.	OPTIONS	24
9.1.	Display/Keys	24
9.1.1.	Installation	24
9.1.2.	Setup and Calibration.....	24
10.	COMMANDS.....	25
10.1.	Overview.....	25
10.1.1.	Commands and Queries	25
10.1.2.	Responses	25
10.1.3.	Parameters.....	25
10.1.4.	Termination	25
10.2.	Command Details	26
10.2.1.	ACL: Set Automatic Temperature Calibration On/Off.....	26
10.2.2.	ADR: Set Address	27
10.2.3.	ANL: Set Analog Output.....	28
10.2.4.	ANM: Set Analog Output Maximum and Minimum	29
10.2.5.	ASF: Set Filtering	30
10.2.6.	BDR: Set Baud Rate	31
10.2.7.	COF: Set Output Format	32
10.2.8.	ESR: Query Error Status.....	35
10.2.9.	FCN: Execute A Function.....	36
10.2.10.	HYS: Set Hysteresis.....	37
10.2.11.	IAD: Set Scale Build	38
10.2.12.	IDN: Set Identification.....	39
10.2.13.	LDW: Calibrate Zero Dead Weight.....	40
10.2.14.	LIV: Set Limit Value.....	41
10.2.15.	LWT: Calibrate Span	42
10.2.16.	MSV?: Query Measured Weight Value.....	43
10.2.17.	RBT: Remote Button Settings	44
10.2.18.	RES: Reset	46
10.2.19.	SER: Set Serial Communications Settings.....	47
10.2.20.	STP: Stop Continuous Transfer	48
10.2.21.	Sxx: Select Unit.....	49
10.2.22.	TAR: Tare.....	50
10.2.23.	TDD: Load/Save Setup	51
11.	APPENDIX	52
11.1.	Glossary.....	52
11.2.	List of Figures and Tables.....	52
12.	INDEX	53

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/rinstrum/1203 reference manual.html](https://the-checkout-tech.com/manuals/rinstrum/1203%20reference%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)