

**1203**  
**WEIGHT**  
**TRANSMITTER**  
**Reference**  
**Manual**

**For use with Software**  
**Versions 1.x**

## TABLE OF CONTENTS

<b>1. INTRODUCTION</b> .....	<b>4</b>
1.1. Document Conventions.....	4
<b>2. SPECIFICATIONS</b> .....	<b>5</b>
<b>3. INSTALLATION</b> .....	<b>6</b>
3.1. Introduction .....	6
3.2. Power Supply.....	6
3.3. Load Cell Signals and Scale Build .....	6
3.4. Cable Shield Connection and Earthing .....	6
3.5. Load Cell Connection.....	7
3.5.1. 6-Wire Connection .....	7
3.5.2. 4-Wire Connections.....	8
3.6. Intrinsic Safety .....	9
3.7. Serial Communication Ports.....	9
3.7.1. Serial 1: RS-232 Port .....	10
3.7.2. Serial 2: RS-485 Port .....	10
3.7.3. Multi-Drop Networking.....	11
3.7.4. RS-232 Connection.....	11
3.7.5. RS-485 Connection.....	12
3.8. Input / Output: Setpoints .....	13
3.9. Input / Output: Inputs .....	14
3.10. Analog Output.....	15
3.11. LEDs .....	15
3.12. 1203 Viewer Software .....	15
<b>4. CONTROLS</b> .....	<b>16</b>
<b>5. DIGITAL SETUP</b> .....	<b>17</b>
5.1. Introduction .....	17
5.2. Basic Weighing Terminology.....	17
5.3. Direct mV/V Operation .....	18
5.4. Filtering Techniques.....	18
5.4.1. FIR Filter .....	18
5.4.2. Digital Averaging.....	18
<b>6. CALIBRATION</b> .....	<b>19</b>
6.1. Introduction .....	19
6.2. Digital Calibration with Test Weights.....	19
6.2.1. Digital Zero Calibration Routine .....	19
6.2.2. Digital Span Calibration Routine.....	19
6.3. Digital Direct mV/V Calibration.....	20
6.3.1. Digital Zero Calibration Routine .....	20
6.3.2. Digital Span Calibration Routine.....	20
6.4. Analog Output Calibration .....	20
6.4.1. Analog Calibration Routine.....	20
<b>7. SERIAL OUTPUTS</b> .....	<b>21</b>
7.1. Introduction .....	21
7.2. Automatic Weight Output .....	21
7.3. Networking the 1203 .....	21
7.3.1. RS-485 Termination Resistors .....	21
<b>8. EXTENDED FUNCTIONS</b> .....	<b>22</b>
8.1. Setpoints.....	22
8.1.1. Introduction .....	22

8.1.2.	Status Indication.....	22
8.1.3.	Connection .....	22
8.1.4.	Operation .....	22
8.1.5.	Example 1: Control Level of Product in 2000kg Tank.....	23
8.1.6.	Example 2: Control Weighing of Product Out of Silo into 100kg Drums .....	23
8.2.	Remote Input .....	23
<b>9.</b>	<b>OPTIONS .....</b>	<b>24</b>
9.1.	Display/Keys .....	24
9.1.1.	Installation .....	24
9.1.2.	Setup and Calibration.....	24
<b>10.</b>	<b>COMMANDS.....</b>	<b>25</b>
10.1.	Overview.....	25
10.1.1.	Commands and Queries .....	25
10.1.2.	Responses .....	25
10.1.3.	Parameters.....	25
10.1.4.	Termination .....	25
10.2.	Command Details .....	26
10.2.1.	ACL: Set Automatic Temperature Calibration On/Off.....	26
10.2.2.	ADR: Set Address .....	27
10.2.3.	ANL: Set Analog Output.....	28
10.2.4.	ANM: Set Analog Output Maximum and Minimum .....	29
10.2.5.	ASF: Set Filtering .....	30
10.2.6.	BDR: Set Baud Rate .....	31
10.2.7.	COF: Set Output Format .....	32
10.2.8.	ESR: Query Error Status.....	35
10.2.9.	FCN: Execute A Function.....	36
10.2.10.	HYS: Set Hysteresis.....	37
10.2.11.	IAD: Set Scale Build .....	38
10.2.12.	IDN: Set Identification.....	39
10.2.13.	LDW: Calibrate Zero Dead Weight.....	40
10.2.14.	LIV: Set Limit Value.....	41
10.2.15.	LWT: Calibrate Span .....	42
10.2.16.	MSV?: Query Measured Weight Value.....	43
10.2.17.	RBT: Remote Button Settings .....	44
10.2.18.	RES: Reset .....	46
10.2.19.	SER: Set Serial Communications Settings.....	47
10.2.20.	STP: Stop Continuous Transfer .....	48
10.2.21.	Sxx: Select Unit.....	49
10.2.22.	TAR: Tare.....	50
10.2.23.	TDD: Load/Save Setup .....	51
<b>11.</b>	<b>APPENDIX .....</b>	<b>52</b>
11.1.	Glossary.....	52
11.2.	List of Figures and Tables.....	52
<b>12.</b>	<b>INDEX .....</b>	<b>53</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*