

R300 Series
(R310, R320 and R321)
Digital Indicator
Reference Manual
For use with Software Versions 1.1 and above

Table of Contents

1.	INTRODUCTION	5
1.1.	The Manuals Set	6
1.2.	This Reference Manual	6
1.3.	Document Conventions	6
2.	SPECIFICATIONS	7
3.	OVERVIEW	8
3.1.	R310	8
3.2.	R320 (including R321)	8
4.	INSTALLATION	9
4.1.	Introduction	9
4.2.	Electrical Safety	9
4.3.	R310/R320 Panel Mount Template	9
4.4.	Cable Connections	9
4.5.	DC Power (DC PWR + , DC PWR -)	10
4.6.	Load Cell Connection	10
4.6.1.	Load Cell Signals and Scale Build	10
4.6.2.	4-Wire Connection	10
4.6.3.	6-Wire Connection	11
4.7.	Auxiliary Connections (R320 only)	11
4.7.1.	RS-232 Serial	11
4.7.2.	Remote Input	12
4.7.3.	Outputs	13
4.8.	rin-LINK (Optional)	14
4.9.	Connecting Shields	15
4.9.1.	Cable Shield Connection and Earthing	15
4.10.	Regulatory Sealing Requirements	15
5.	DATA ENTRY	16
5.1.	Editing Annunciators	16
5.2.	Numeric Entry	17
5.3.	Selections and Options	17
6.	BASIC OPERATION	18
6.1.	Display and Controls	18
6.1.1.	Front Panel: Visual Display	18
6.2.	Operation Keys	19
6.2.1.	Primary Function	20
6.2.2.	Editing Function	20
6.3.	Stability Considerations	20
6.4.	POWER Key	20
6.4.1.	Automatic Operation	20
6.5.	ZERO Key	21
6.6.	TARE Key	21
6.7.	GROSS/NET Key	21
6.7.1.	rin-LINK Activation	21
6.8.	PRINT Key (R320 only)	22
6.9.	TEST Key (R310 only)	22
6.10.	FUNCTION Key (R320 only)	22
7.	CONFIGURATION ISSUES	23
7.1.	General Setup Information	23
7.2.	Basic Weighing Terminology	23
7.3.	Filtering Techniques	24
7.4.	Industrial vs OIML and NTEP Modes	25
7.5.	Calibration Counter	25
7.6.	Passcodes	26
7.6.1.	Full Setup Passcode	26
7.6.2.	Safe Setup Passcode	26
7.6.3.	Setup Lock-Out	26
8.	SETUP	27
8.1.	Accessing Setup	27
8.1.1.	R310	27
8.1.2.	R320	27
8.1.3.	Setup Display Prompts	28
8.2.	Exiting Full or Safe Setup	28
8.3.	Groups and Items	28
8.3.1.	GRP (Group)	28

8.3.2.	ITM (Item).....	29
8.4.	Setup Menus	29
8.4.1.	BUILD (Scale Build)	29
8.4.2.	OPTION (Scale Options).....	30
8.4.3.	CAL (Scale Calibration).....	31
8.4.4.	SPEC (Special Settings Menu)	32
8.4.5.	SERIAL (Serial Communications Options) (R320 only)	34
8.4.6.	SET.PTS (Setpoint Settings) (R320 only)	35
8.4.7.	CLOCK (Clock Settings) (R320 only)	36
8.4.8.	TEST (Special Test Functions)	36
8.4.9.	FACTRY (Factory Adjustment Menu)	37
8.4.10.	- End - (Leaving Setup).....	37
9.	CALIBRATION	38
9.1.	Performing a Digital Calibration with Test Weights	38
9.1.1.	ZERO (Zero Calibration Routine).....	39
9.1.2.	SPAN (Span Calibration Routine).....	39
9.2.	Performing a Calibration with Direct mV/V Entry (R320 only)	39
9.2.1.	DIR.ZER (Direct Zero Calibration Entry)	39
9.2.2.	DIR.SPN (Direct Span Calibration Entry)	39
9.3.	Using Linearisation (R320 only)	40
9.3.1.	ED.LIN (Edit Linearisation Points).....	40
9.3.2.	CLR.LIN (Clear Linearisation)	41
10.	SERIAL OUTPUTS (R320 ONLY).....	42
10.1.	Automatic Weight Output	42
10.2.	Master Serial Output	43
11.	SETPOINTS (R320 ONLY).....	44
11.1.	Setpoint Connection	44
11.2.	Setpoint Operation	44
12.	SPECIAL FUNCTIONS (R320 ONLY).....	45
12.1.	Introduction.....	45
12.1.1.	Cleaning	45
12.2.	Key Functions.....	45
12.2.1.	NONE	45
12.2.2.	TEST	45
12.2.3.	COUNT	45
12.2.4.	UNITS.....	46
12.2.5.	HOLD and PEAK HOLD	46
12.2.6.	LIVE.WT	46
12.2.7.	SHOW.T	47
13.	APPENDIX	48
13.1.	R300 Series Dimensions.....	48
13.1.1.	R310 and R320 Dimension Specifications	48
13.1.2.	R321 Dimension Specifications	49
13.2.	Sealing Details	50
13.2.1.	R310 and R320 Sealing (R320 shown).....	50
13.2.2.	R321 Sealing.....	51
13.3.	Setup Menu Quick Reference	52
13.4.	Error Messages	53
13.4.1.	Weighing Errors	53
13.4.2.	Setup and Calibration Errors	53
13.5.	Diagnostic Errors.....	54
13.6.	Glossary Terms.....	55
13.7.	List of Figures.....	55
13.8.	List of Tables	55
14.	INDEX.....	56

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*