

SMART WEIGHING SOLUTIONS



rinstrum

**400 Series
(K411)
Batching Indicator
Reference Manual**

RI00-613-110

Table of Contents

1. INTRODUCTION	5
1.1. Overview	5
1.2. The Manuals Set	6
1.3. Document Conventions	6
1.4. Software Comparison K401-402	6
2. SPECIFICATIONS.....	7
3. INSTALLATION	8
3.1. Introduction	8
3.2. General Warnings	8
3.3. Electrical Safety	8
3.4. Cleaning	8
3.5. Panel Mount Template	8
3.6. Cable Connections	9
3.7. DC Power (DC PWR + , DC PWR –)	9
3.8. Load Cell Connection	9
3.8.1. Load Cell Signals and Scale Build	9
3.8.2. 4-Wire Connection	10
3.8.3. 6-Wire Connection	10
3.9. Auxiliary Connections.....	10
3.9.1. RS-232 Serial	11
3.9.2. RS-485 Serial	11
3.10. Optical Communications	12
3.11. Connecting Shields	13
3.11.1. Cable Shield Connection and Earthing	14
3.12. Regulatory Sealing Requirements	14
3.13. Accessory Module connection (K402 only)	14
4. SETUP MENUS.....	16
4.1. Accessing Setup Menus.....	16
4.1.1. Setup Display Prompts	17
4.2. Exiting Full or Safe Setup.....	17
4.3. Menu Navigation	17
4.4. Changing Data	18
4.5. Numeric Entry	18
4.6. Selections and Options	19
4.7. Strings	19
4.7.1. Normal String Editing	19
4.7.2. Literal String Editing	20
4.7.3. ASCII String Editing	20
5. BASIC OPERATION	21
5.1. User Interface Display and Controls	21
5.1.1. Overview	21
5.1.2. Display	22
5.1.3. Primary Annunciators.....	22
5.1.4. Keypad.....	23
5.2. Operation Keys	24
5.2.1. Power Key.....	24
5.2.2. Zero Key	25
5.2.3. Tare Key	25
5.2.4. Gross/Net Key.....	27
5.2.5. Function Keys	27
5.2.6. Up, Down, OK keys: Products (K402 only)	28
5.2.7. Clock	30
5.2.8. View	31
5.2.9. Report (K402 only).....	31
5.2.10. Total	32
5.2.11. User ID	32
5.2.12. Target (K402 only)	33
5.2.13. Lock	33

5.2.14.	Alibi	34
5.2.15.	Acc (K402 only).....	35
5.2.16.	Stability Considerations	35
6.	CONFIGURATION	36
6.1.	General Setup Information	36
6.2.	Correct Loadcell Selection	36
6.3.	Filtering Techniques.....	36
6.4.	Industrial vs Trade Modes.....	37
6.5.	Calibration Counter	37
6.6.	Passcodes.....	37
6.6.1.	Full Setup Passcode.....	38
6.6.2.	Safe Setup Passcode	38
6.6.3.	Operator Passcode	38
6.6.4.	Setup Lock-Out	38
7.	SETUP MENUS.....	39
7.1.	GEN.OPT (General options)	39
7.1.1.	LANG (Operator language).....	39
7.1.2.	DATE.F (Date format)	39
7.1.3.	PCODE (Security passcodes).....	39
7.1.4.	KEY.LOC (Key Function Access Control).....	40
7.1.5.	DISP (Display options).....	40
7.1.6.	USR.STR (User Defined Strings).....	41
7.1.7.	POWER (Power options)	41
7.1.8.	USR.DEF (Set all non-calibration settings to defaults)	41
7.2.	H.WARE (Hardware Configuration & Test).....	42
7.2.1.	ALLOC (Allocation Report)	42
7.2.2.	LC.HW	42
7.2.3.	SER1.HW, SER2.HW ^(K402 only)	43
7.2.4.	IO.HW (K402 only).....	44
7.2.5.	ANL.HW (K402 only).....	44
7.3.	SCALE (Loadcell options and calibration).....	45
7.3.1.	BUILD (Scale parameters).....	45
7.3.2.	OPTION (Scale options)	46
7.3.3.	CAL (Scale calibration)	47
7.3.4.	QA (QA alarm)	47
7.4.	FUNC (Special functions).....	48
7.4.1.	NUM (Number of special functions)	48
7.4.2.	SFn: TYPE (Function Types)	48
7.4.3.	SFn: KEY (Function Key / Remote Input)	48
7.4.4.	SFn: PRINT (Printing Functions)	49
7.4.5.	SFn: SINGLE (Single Serial Output Functions)	50
7.4.6.	SFn: BLANK (Blanking Functions) (K402 only)	50
7.4.7.	SFn: COUNT, SFn: PIECE (Counting Functions)	50
7.4.8.	SFn: UNITS (Unit Switching Functions).....	51
7.4.9.	SFn: THUMB (Thumbwheel Product Selection) (K402 only)	51
7.4.10.	SFn: REM.KEY (Remote Key Functions) (K402 only)	52
7.5.	SER.NET (Network communications)	52
7.6.	SER.AUT (Automatic transmit)	53
7.6.1.	NUM (Number of Automatic Transmissions) (K402 only)	53
7.6.2.	AUTO.n (Automatic Output Configuration)	53
7.7.	PRINT (Printouts).....	54
7.7.1.	NUM (Number of printouts) (K402 only)	54
7.7.2.	HEADER (Print header)	54
7.7.3.	FOOTER (Print footer)	54
7.7.4.	PAGE (Print page options)	54
7.7.5.	SPACE (Print blank space options)	55
7.7.6.	PRINT.n ... (Printout options)	56
7.8.	SETP (Setpoints) (K402 only)	57
7.8.1.	NUM (Number of setpoints) (K402 only)	57
7.8.2.	SETP1 ... SETP8 (Setpoint options) (K402 only)	58
7.9.	ANL.OUT (Analogue Output) (K402 only).....	59

7.10.	End (Save and exit).....	59
8.	CALIBRATION	60
8.1.	Performing a Digital Calibration with Test Weights	60
8.1.1.	ZERO (Zero Calibration Routine).....	61
8.1.2.	SPAN (Span Calibration Routine).....	61
8.2.	Performing a Calibration with Direct mV/V Entry	62
8.2.1.	DIR.ZER (Direct Zero Calibration Entry).....	62
8.2.2.	DIR.SPN (Direct Span Calibration Entry).....	62
8.3.	Using Linearisation.....	63
8.3.1.	ED.LIN (Edit Linearisation Points)	64
8.3.2.	CLR.LIN (Clear Linearisation).....	64
8.4.	Calibration Errors	65
9.	NETWORK COMMUNICATIONS.....	66
9.1.	Introduction	66
9.2.	Network Protocol	66
9.2.1.	Basic Message Format	66
9.2.2.	Termination	67
9.2.3.	Error Handling	68
9.2.4.	Calibrating an instrument over a network	68
9.2.5.	Examples	69
10.	AUTOMATIC WEIGHT OUTPUT	71
10.1.	Overview	71
10.2.	Auto Weight Format String.....	71
11.	PRINTING.....	72
11.1.	Overview	72
11.2.	Print ID	72
11.3.	K401 Record printouts	72
11.4.	K402 Record printouts	73
11.5.	K401 Docket printouts.....	73
11.6.	K402 Docket printouts.....	73
11.7.	Report printouts (K402 only)	74
12.	SPECIAL FUNCTIONS	75
12.1.	Introduction	75
12.2.	Key Functions	75
12.2.1.	NONE	75
12.2.2.	PRINT	75
12.2.3.	SINGLE	76
12.2.4.	TEST	76
12.2.5.	COUNT	77
12.2.6.	PIECE	78
12.2.7.	UNITS	79
12.2.8.	HOLD	80
12.2.9.	PEAK HOLD	81
12.2.10.	PRD.SEL (K402 only)	83
13.	SETPOINTS (K402 ONLY)	84
13.1.	Overview	84
13.2.	Outputs.....	84
13.3.	Common Settings.....	84
13.4.	Weigh in (OVER) Setpoints and Weigh Out (UNDER) Setpoints	85
13.4.1.	Additional Settings	85
13.5.	Status Based Setpoint Types	86
14.	ANALOGUE OUTPUT (K402 ONLY).....	87
14.1.	Overview	87
14.2.	Configuration of Hardware	87
14.2.1.	Configuration.....	87
14.2.2.	Calibration.....	87
14.2.3.	Testing	87
14.3.	Analogue Weight Transmission	87
15.	APPENDIX 1: DIMENSIONS	88
15.1.	Dimensions	88

15.2.	Legal Sealing Details	89
15.2.1.	Trade Label.....	89
15.2.2.	Lead Seals	90
15.2.3.	Destructible Sticker Seals	91
15.2.4.	Electronic Seal.....	91
16.	APPENDIX 2: PRINT AND AUTOMATIC TRANSMISSION TOKENS	92
16.1.	ASCII codes	92
16.2.	Tokens	93
16.2.1.	Non-paged generic tokens.....	93
16.2.2.	Page tokens	93
16.2.3.	Page 0, 1, 2, 3, 7 tokens: Weight Information.....	94
16.2.4.	Page 4, 5, 6 tokens: Product Information.....	95
16.2.5.	Format tokens.....	96
17.	APPENDIX 3: COMMUNICATIONS REGISTERS	97
18.	APPENDIX 4: SETUP MENU QUICK REFERENCE	104
19.	APPENDIX 5: ERROR MESSAGES	106
19.1.	Overview	106
19.2.	Weighing Errors	106
19.3.	Setup Errors	106
19.4.	Diagnostic Errors.....	107
20.	GLOSSARY	108
20.1.	Glossary of Terms.....	108
20.2.	List of Figures.....	109
20.3.	List of Tables.....	109
21.	INDEX	110

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/rinstrum/R400 reference manual.html](https://the-checkout-tech.com/manuals/rinstrum/R400%20reference%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)