

System Weighing Controller

PR 1713

Installation Manual



Installation manual

9499 053 45710

Edition 3

Dat. 2000808

for PR1713/..

Release: 1.10



●●● sartorius group

GLOBAL Weighing

GWT GLOBAL Weighing Technologies GmbH, P.O.B. 730 370, 22123 Hamburg / Germany Tel:++49-40-67960-303 Fax:++49-40-67960-383

Contents

1 SAFETY HINTS, ELECTRICAL PROTECTION CLASS	1
1.1 APPLICATION OF THE INSTRUMENT.....	1
1.2 INITIAL INSPECTION.....	1
1.3 BEFORE COMMISSIONING	1
1.3.1 Installation	1
1.3.2 Electrostatically sensitive components.....	2
1.3.3 Opening the instrument.....	2
1.3.4 Earthing.....	2
1.3.5 Protective earth.....	2
1.3.6 Power connection PR1713/00.....	2
1.4 REPAIR AND MAINTENANCE	3
1.4.1 Failure and excessive stress.....	3
1.4.2 For special attention.....	3
1.4.3 Fuse.....	3
1.4.4 Soldering work.....	4
1.4.5 Battery replacement.....	4
1.4.6 Disposal	4
1.5 CLEANING	4
2 SYSTEM WEIGHING CONTROLLER PR1713.....	5
2.1 BASIC INSTRUMENT SURVEY	5
2.2 OPTIONS.....	6
2.2.1 Program extensions (optional).....	7
2.2.2 Plug-in cards and modules (optional)	7
2.3 HOUSING	8
3 INSTALLING THE INSTRUMENT AND OPTIONS	9
3.1 MECHANICAL PREPARATION	9
3.2 HARDWARE CONSTRUCTION	9
3.2.1 Installing the options	10
3.2.2 Cable gland and connection	11
3.3 ON THE CONNECTING BOARD.....	12
3.3.1 Load cell cable/ cable junction box.....	12
3.3.2 External PC-AT keyboard.....	13
3.3.3 RS 232 Builtin interface.....	13
3.3.4 PR1713/04 Serial I/O.....	14
3.3.5 PR1713/06 analog output card	18
3.3.6 PR 1713/07 Analog I/O.....	19
3.3.7 Control I/O: PR1713/12 Opto-, PR1713/15 Relay-Output.....	20
3.3.8 PR1713/08 BCD output	22
3.3.9 PR1713/13 DIOS master.....	24
3.3.10 PR1713/14 Ethernet.....	26
3.4 ON MAIN PRINT 2	27
3.4.1 Activating the battery	27
3.4.2 PR1713/05 RAM-extension	27
3.4.3 PR 1721 field bus interface.....	28
3.4.4 Installation of the fieldbus interface.....	28
4 PR1713/00 COMMISSIONING	31
4.1 DATA SAVING/ POWER FAILURE.....	31
4.1.1 Calibration data	31
4.1.2 Configuration data	32
4.1.3 Programming with PR1750.....	32
4.1.4 Cold start.....	32

4.2 DISPLAY ELEMENTS AND CONTROLS ON THE BUILT-IN CONSOLE.....	32
4.2.1 Control signals	33
4.2.2 Language.....	33
4.2.3 Operating concept: Commissioning	33
4.3 MAIN MENU	34
4.3.1 Configuration area Setup.....	34
4.3.2 Boot menu	36
4.4 CALIBRATION, WEIGHINGPOINT PARAMETERS.....	39
4.4.1 Calibration sequence	39
4.4.2 Start messages	39
4.4.3 Set Parameters.....	43
4.4.4 External Wp.....	44
4.5 CONFIGURATION OF NOT WEIGHINGPOINT PARAMETERS	44
4.5.1 Set Clock	44
4.5.2 Serial Ports.....	45
4.5.3 Software parameters	45
4.5.4 Fieldbus Parameter	47
4.5.5 Show Boardnumber.....	47
4.5.6 Licence Setup	48
4.5.7 Print Setupdata.....	48
4.5.8 Refresh Display	48
4.5.9 Show Version.....	48
4.5.10 Reboot	48
4.6 CONFIG PROGRAM (SET-UP MENU).....	49
4.6.1 Production report parameters.....	49
4.6.2 Layout of printed reports	49
4.6.3 Batch parameters.....	49
4.6.4 Limit values	50
4.6.5 Printer interface	51
4.6.6 Digital I/O Coding.....	52
4.7 ENTER FIX-TARE WEIGHTS	52
4.8 COUNT FACTORS	52
5 COMMISSIONING WITH TERMINAL	53
5.1 SYSTEM CONSOLE: CONNECTING MENU STRUCTURE.....	53
5.1.1 Connecting PR1713-PC.....	53
5.1.2 Terminal program.....	53
5.1.3 Main-Command-Level - menu structure	54
5.1.4 General operating notes	56
5.2 CONFIGURATION	57
5.2.1 Set date.....	57
5.2.2 Set time.....	58
5.2.3 Serial interface configuration.....	58
5.2.4 Entry of the software licence number	60
5.2.5 Entry of software parameters	61
5.2.6 Fieldbus parameter.....	62
5.2.7 Entry of user-defined units.....	62
5.2.8 Printing all configuration data	62
5.3 WEIGHING POINT MASK	63
5.4 WEIGHING POINT PARAMETERS: STORING, SAVING, PROTECTING	64
5.4.1 Access protection: CAL switch.....	64
5.4.2 Saving the weighing point parameters in EAROM.....	66
5.4.3 Saving the weighing point parameters temporarily.....	66
5.5 WEIGHING POINT CONFIGURATION	66
5.5.1 Editing functions for parameter entry	66
5.5.2 Filter: Analog Filter.....	67
5.5.3 Analog test mode: Testmode	67
5.5.4 Measuring time: Measime.....	68
5.5.5 Standstill detection	68

5.5.6 Zero set range: <i>Zeroset.rn</i>	68
5.5.7 Automatic zero tracking.....	68
5.5.8 Automatic zero correction switch-on/off.....	68
5.5.9 Zero tracking range: <i>Zerotrk.rn</i>	68
5.5.10 Zero tracking stepwidth: <i>Zerotrk.st</i>	68
5.5.11 Zero tracking interval: <i>Zerotrk.ti</i>	69
5.5.12 Multirange scale.....	69
5.5.13 Tare time-out: <i>Tare timot</i>	69
5.5.14 Maximum permissible overload: <i>Overload</i>	69
5.5.15 Min. weight limit for print-out: <i>no p below</i>	69
5.5.16 Stepwidth (scale divisions): <i>Stepwidth</i>	69
5.5.17 W&M mode: <i>W & M</i>	69
5.6 WEIGHING POINT CALIBRATION.....	69
5.6.1 Weighing point calibration parameters.....	70
5.6.2 Editing functions for parameter entry.....	70
5.6.3 Adjusting the full scale value: <i>Fullscale</i>	71
5.6.4 Default span.....	71
5.6.5 Weighing point calibration procedure/sequence.....	71
5.6.6 Weighing point calibration with weights.....	72
5.6.7 Weighing point calibration without weights.....	77
5.6.8 Error messages in the calibration menu.....	80
5.7 ADDITIONAL WEIGHING POINTS.....	81
5.7.1 <i>PR1720 as second WP</i>	82
5.7.2 <i>Customer-specific weighing point</i>	82
5.8 SUB-MENU SERVICE.....	85
5.8.1 <i>Available memory in PR1713</i>	86
5.8.2 <i>Show hardware configuration</i>	87
5.8.3 <i>Testing the input and output modules</i>	87
5.8.4 <i>Printing all configuration data</i>	91
5.9 PROLOC OPERATING LEVEL.....	92
6 TECHNICAL DATA.....	93
6.1 ANALOG PART, A/D CONVERSION.....	93
6.1.1 <i>Accuracy and stability</i>	93
6.1.2 <i>Sensitivity</i>	93
6.1.3 <i>Load cells</i>	93
6.1.4 <i>Safe condition</i>	93
6.1.5 <i>Certificate of type approval</i>	94
6.1.6 <i>Location of seals</i>	95
6.2 DIGITAL PART.....	96
6.2.1 <i>Display</i>	96
6.2.2 <i>Keyboard</i>	96
6.2.3 <i>External keyboard</i>	96
6.2.4 <i>Built-in RS 232 interface</i>	96
6.2.5 <i>Power supply PR1713/00</i>	96
6.3 ENVIRONMENTAL EFFECTS.....	97
6.3.1 <i>Power voltage sags</i>	97
6.3.2 <i>Environmental conditions</i>	97
6.3.3 <i>Electromagnetic immunity</i>	97
6.3.4 <i>RF interference suppression</i>	97
6.3.5 <i>CE conformity marking</i>	97
6.4 MECHANICAL DATA.....	98
6.4.1 <i>Construction type</i>	98
6.4.2 <i>Dimensions</i>	98
6.4.3 <i>Connections</i>	98
6.4.4 <i>Accessories</i>	98
6.4.5 <i>Weight</i>	98
6.5 OPTIONS.....	99
6.5.1 <i>Analog output</i>	99

6.5.2 Digital inputs.....	99
6.5.3 Digital outputs.....	99
6.5.4 Serial interfaces.....	99
6.6 FIELD BUSES	100
6.6.1 Interbus-S/ Profibus-DP/ DeviceNet	100
6.6.2 GSD file for PR1721 Profibus DP.....	101
6.6.3 EDS-file for PR1721 DeviceNet.....	102
7 ANNEX.....	103
7.1 PR1713 /00 SPARE PARTS	103
7.2 OTHER PR1713 DOCUMENTS	103
7.3 GLOSSARY	103
7.4 INDEX.....	104
7.5 HINT FOR CUSTOMER FEEDBACK	107

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sartorius/PR-1713 installation manual.html](https://the-checkout-tech.com/manuals/sartorius/PR-1713%20installation%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)