


# PR 5210 Transmitter Series

PR 5210/00 Profibus Transmitter

PR 5210/10 Digital Process Transmitter

PR 5210/11 Profibus Transmitter (without Analog Output)

## Operating Manual



Operating manual

9499 050 52103

Edition 3

11.11.2004

for PR 5210

Release: 3

## Contents

<b>1</b>	<b>SAFETY HINTS, ELECTRICAL PROTECTION CLASS .....</b>	<b>7</b>
1.1	APPLICATION OF THE INSTRUMENT.....	7
1.2	INITIAL INSPECTION.....	7
1.3	BEFORE COMMISSIONING .....	7
1.3.1	Installation.....	7
1.3.2	Electrostatically sensitive components.....	7
1.3.3	Protective earth.....	8
1.3.4	Supply voltage connection .....	8
1.3.5	Failure and excessive stress.....	8
1.3.6	Fuse .....	8
1.4	REPAIR AND MAINTENANCE.....	8
1.4.1	Soldering work.....	8
1.4.2	Cleaning.....	8
1.4.3	Disposal.....	8
<b>2</b>	<b>PR 5210 TRANSMITTER SERIES .....</b>	<b>9</b>
2.1	THE TRANSMITTER VERSIONS.....	9
2.1.1	PR 5210/00 Version .....	9
2.1.2	PR 5210/10 Version (without Profibus).....	9
2.1.3	PR 5210/11 Version (without Analog Output).....	9
2.2	TRANSMITTER SURVEY.....	10
2.3	LABEL ON THE HOUSING.....	10
2.4	HOUSING .....	11
2.5	CONNECTIONS .....	12
2.5.1	Load cell connection .....	12
2.5.2	RS 232 Interface.....	14
2.5.3	RS 485 / 422 Interface .....	14
2.5.4	Analog output (PR 5210/00 and PR 5210/10 only).....	15
2.5.5	3 Opto inputs.....	16
2.5.6	3 Opto outputs.....	16
2.5.7	Profibus (PR 5210/00 and PR 5210/11 only).....	16
<b>3</b>	<b>OPERATING ELEMENTS .....</b>	<b>17</b>
3.1	STATUS LEDS.....	17
3.2	CAL SWITCH.....	18
3.2.1	Factory settings.....	18
<b>4</b>	<b>SETUP AND CONFIGURATION .....</b>	<b>19</b>
4.1	GENERAL .....	19
4.2	INSTALLATION WINDOWS TOOL .....	19
4.3	LOAD AND STORE SETUP AND CONFIGURATION .....	20
4.3.1	Data in the PR5210 .....	20
4.3.2	Archive data in the PC.....	20
4.4	PRINT DATA SET .....	20
4.5	SELECT LANGUAGE.....	21
4.6	STATUS LINE .....	21
4.7	ADU.....	22
4.7.1	Weighing point calibration.....	22
4.7.2	Weighing point configuration .....	24
4.8	PARAMETER.....	26
4.8.1	Analog output.....	26

4.8.2	Profibus Address.....	27
4.8.3	Bus size .....	28
4.8.4	Communication .....	28
4.8.5	Baudrate.....	28
4.8.6	Access.....	28
4.8.7	Outputs.....	28
4.8.8	Inputs.....	28
4.8.9	Limits.....	29
4.9	<b>CALIBRATE .....</b>	<b>30</b>
4.10	<b>ANALOG OUTPUT ADAPTION .....</b>	<b>31</b>
4.11	<b>STATUS.....</b>	<b>32</b>
4.11.1	Analog part weight status .....	32
<b>5</b>	<b>SMA PROTOCOL .....</b>	<b>33</b>
5.1	<b>GENERAL.....</b>	<b>33</b>
5.2	<b>KEY TO SYMBOLS USED.....</b>	<b>33</b>
5.3	<b>SCALE COMMAND SET .....</b>	<b>34</b>
5.3.1	Request Displayed Weight .....	34
5.3.2	Request High-Resolution Weight .....	34
5.3.3	Request Displayed Weight after Stability.....	34
5.3.4	Request Scale to Zero .....	34
5.3.5	Request Scale to Tare.....	35
5.3.6	Set Scale Tare Weight.....	35
5.3.7	Return Tare Weight .....	35
5.3.8	Clear Scale Tare Weight.....	35
5.3.9	Invoke Scale Diagnostics .....	35
5.3.10	About Scale First Line .....	35
5.3.11	About Scale Scroll.....	35
5.3.12	Scale Information .....	36
5.3.13	Scale Information Scroll .....	36
5.3.14	Abort Command .....	36
5.3.15	Repeat Displayed Weight Continuously .....	36
5.4	<b>SCALE RESPONSE MESSAGES .....</b>	<b>37</b>
5.4.1	Standard Scale Response Message.....	37
5.4.2	Unrecognized Command Response.....	38
5.4.3	Communication Error Response.....	38
5.4.4	Diagnostics Command Response .....	38
5.4.5	About 'A' and 'B' Command Response.....	38
5.4.6	Scale Information 'I' and 'N' Command Response.....	39
5.5	<b>COMMUNICATION ERROR HANDLING .....</b>	<b>40</b>
<b>6</b>	<b>PROFIBUS INTERFACE .....</b>	<b>41</b>
6.1	<b>PROFIBUS INTERFACE PROTOCOL.....</b>	<b>41</b>
6.1.1	Write window (Input area) .....	42
6.1.2	Read window (Output area).....	42
6.1.3	Data reading and writing.....	42
6.1.4	Description of I/O area (read/ write window) .....	43
6.1.5	Register read and write via Profibus.....	45
6.1.6	Parameter read and write via Profibus.....	48
6.2	<b>PROFIBUS REGISTER .....</b>	<b>50</b>
6.2.1	Register 0: IO-Status bits for reading.....	50
6.2.2	Register 1: Scale status.....	50
6.2.3	Register 2: Status of state controlled action bits.....	51
6.2.4	Register 3: Status of transition controlled action bits.....	51
6.2.5	Register 4: Calibration information, error byte.....	52
6.2.6	Register 5: Transmitter type and version.....	53
6.2.7	Register 6: Board number .....	53

6.2.8	Register 7: (Reserved) .....	53
6.2.9	Register 8 ...14: Weight data .....	53
6.2.10	Register 20 and 21: Parameter channel (read/write).....	53
6.2.11	Register 22 ... 27: Limit values (read/write).....	54
6.2.12	Register 30: Analog output (read/write).....	54
6.2.13	Register 31: Fixtare (read/write) .....	54
6.2.14	Register 80 ... 93: Action bits state controlled (write).....	54
6.2.15	Register 112 ... 125: Action bits transition controlled (write) .....	55
6.3	PROFIBUS PARAMETER NUMBERS.....	56
6.3.1	Configuration parameter.....	56
6.3.2	Calibration .....	59
6.3.3	ADU parameter .....	61
6.3.4	Parameter P99: Access code.....	66
<b>7</b>	<b>TECHNICAL DATA.....</b>	<b>67</b>
7.1	ANALOG PART, A/D CONVERSION.....	67
7.1.1	Accuracy and stability .....	67
7.1.2	Sensitivity.....	67
7.1.3	Load cells.....	67
7.2	RS 232 INTERFACE.....	68
7.3	RS 422 / 485 INTERFACE.....	68
7.4	ANALOG OUTPUT.....	68
7.5	DIGITAL INPUTS .....	68
7.6	DIGITAL OUTPUTS.....	68
7.7	PROFIBUS DP.....	68
7.8	POWER SUPPLY .....	68
7.9	ENVIRONMENTAL EFFECTS.....	69
7.9.1	Environmental conditions .....	69
7.9.2	Electromagnetic compatibility (EMC).....	69
7.9.3	RF interference suppression.....	69
7.10	MECHANICAL DATA .....	70
7.10.1	Construction type .....	70
7.10.2	Dimensions .....	70
7.10.3	Connections .....	70
7.10.4	Weight.....	70
7.11	ACCESSORIES.....	70
7.12	OPTIONS.....	70
<b>8</b>	<b>APPENDIX.....</b>	<b>71</b>
8.1	EC DECLARATION OF CONFORMITY .....	71
8.2	EC TYPE-APPROVAL CERTIFICATE PTB D03-09-025.....	74
8.3	SPARE PARTS .....	75
8.4	EXAMPLE PRINT OUT CONFIGURATION AND CALIBRATION DATA / PARAMETERS.....	75
8.5	GSD FILE FOR PROFIBUS DP.....	76
<b>9</b>	<b>INDEX.....</b>	<b>77</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*