


Operating Manual
Sartorius
PR 5220 Ethernet Transmitter Series

PR 5220/00 Ethernet Transmitter

PR 5220/01 Ethernet Transmitter with Profibus

PR 5220/04 Ethernet Transmitter with DeviceNet



Operating Manual

9499 050 52201

Edition 1

30.10.2007

for PR 5220

Release: 1.00

Contents

1	Safety Information	7
1.1	Intended Use	7
1.2	Initial Inspection	7
1.3	Before Commissioning	7
1.3.1	Installation	7
1.3.2	Electrostatically Sensitive Components	7
1.3.3	Protective Earth	8
1.3.4	Supply Voltage Connection	8
1.3.5	Failure and Excessive Stress	8
1.3.6	Fuse	8
1.3.7	EMC-Compliant Installation	8
2	PR 5220 Ethernet Transmitter Series.....	9
2.1	The Transmitter Versions	9
2.1.1	PR 5220/00 Version	9
2.1.2	PR 5220/01 Profibus	9
2.1.3	PR 5220/04 DeviceNet	9
2.2	Overview of the Instrument	10
2.3	Label on the Housing	10
2.4	Housing Dimensions.....	11
2.5	Operation Using the VNC program	12
2.5.1	Status Symbols	12
2.5.2	Transmitter Keys	12
2.5.3	Navigation Keys, Other Keys	12
2.5.4	Selection Using the Navigation Keys	13
2.5.5	System Messages during Input	14
3	Installing the Instrument	15
3.1.1	Network Port	16
3.2	Connections.....	17
3.2.1	Load Cell Connection	17
3.2.2	RS-422/485 Interface	19
3.2.3	Analog Output	20
3.2.4	3 Optocoupler Inputs	21
3.2.5	3 Optocoupler Outputs	22
3.2.6	Profibus Interface (PR 5220/01 only)	23
3.2.7	DeviceNet Interface (PR 5220/04 only)	24
4	Controls.....	25
4.1	Status Indicator LEDs.....	25
5	Commissioning	26
5.1	Data Backup/Power Failure	26
5.1.1	CAL Switch	26
5.1.2	Factory Settings	26
5.2	Switching on the Instrument.....	27
5.2.1	Resetting the Instrument, Activating 'DHCP'	27
5.2.2	Searching the Instrument in the Network Using 'IndicatorBrowser'	28
5.3	Operation Using a PC.....	28
5.3.1	Operation Using the VNC Program	28
5.3.2	Operation Using Internet Browser	29
5.3.3	INFO Function	30
5.3.4	Setup Function (VNC)	31
5.3.5	Setup Menu	31
5.3.6	Calibration Menu	32
5.4	Calibration	33

5.4.1	Displaying Calibration Data	33
5.4.2	Selecting the Calibration Mode	34
5.4.3	Determining the Maximum Capacity (Max)	35
5.4.4	Determining the Scale Interval	36
5.4.5	Determining the Dead Load	37
5.4.6	Calibration with Weight (by Load)	38
5.4.7	Calibration with mV/V Value	39
5.4.8	Calibration with Load Cell Data ("Smart Calibration")	40
5.4.9	Subsequent Dead Load Correction	41
5.4.10	Linearization	41
5.4.11	Test Value Determination/Display	42
5.4.12	Finishing/Saving the Calibration	42
5.4.13	Parameter Input	43
5.5	Error Messages.....	46
5.5.1	Measuring Circuit Error Messages	46
5.6	Configuring General Parameters.....	47
5.6.1	Serial Ports	47
5.6.2	SMA Protocol	48
5.6.3	Operating Parameters	49
5.6.4	Fieldbus Parameters	50
5.6.5	Network Parameters	51
5.7	Limit Values, Digital Inputs and Outputs.....	52
5.7.1	Conditions for Limit Values and Digital Inputs, States for Outputs	52
5.7.2	Configuring Digital Inputs and Outputs	53
5.7.3	Configuring Outputs	53
5.7.4	Configuring Inputs	54
5.7.5	Configuring Limit Values	56
5.8	Analog Output.....	58
5.8.1	Adapting the Analog Output	59
5.9	ConfigureIt Professional.....	60
5.9.1	Installation	60
5.9.2	Starting the Program	62
5.9.3	Establishing the Communication to the Instrument	64
5.9.4	Transferring a Data Set from the Instrument to the PC	65
5.9.5	Saving the Current Data Set on the PC	65
5.9.6	Transferring the Current Data Set or Selected Parameters to the Instrument	67
5.9.7	Resetting the Instrument to Default	67
5.9.8	Exporting a Data Set as a Printable File	67
5.9.9	Operating the Instrument Using the Browser (VNC Program)	68
5.9.10	Closing the Program	68
6	SMA Protocol.....	69
6.1	General.....	69
6.2	Description of Used Symbols.....	69
6.3	SMA Command Set.....	70
6.3.1	Requesting a Weight	70
6.3.2	Controlling the Scale	71
6.3.3	Scale Diagnosis	72
6.3.4	Scale Data	73
6.3.5	Scale Information	73
6.3.6	Escape Command	73
6.4	SMA Reply Messages.....	73
6.4.1	Standard Reply	74
6.4.2	Reply with Unknown Command	75
6.4.3	Reply in Case of Communication Error	75
6.4.4	Reply with Diagnosis Command	75
6.4.5	Reply with 'A' and 'B' Command	76
6.4.6	Scale Reply with 'I' and 'N' Commands	77
6.5	Communication Error.....	77

7	Fieldbus Interface	78
7.1	Fieldbus Interface Protocol.....	78
7.1.1	Write Window (Input Area)	79
7.1.2	Read Window (Output Area)	79
7.1.3	Reading and Writing Data	79
7.2	Description of the I/O Area (Read / Write Window).....	80
7.2.1	Input Area	80
7.2.2	Output Area	81
7.2.3	Reading and Writing Register via Fieldbus	82
7.2.4	Example: Reading the Gross Weight	84
7.3	Fieldbus Register.....	85
7.3.1	Register 0: I/O Status Bits for Reading	85
7.3.2	Register 1: Scale Status	85
7.3.3	Register 2: State of State-Controlled Action Bits	86
7.3.4	Register 3: State of Edge-Controlled Action Bits	86
7.3.5	Register 4: Calibration Information, Error Byte	86
7.3.6	Register 5: Device Type and Software Release	87
7.3.7	Register 6: Board Number	87
7.3.8	Register 7: (Reserved)	87
7.3.9	Register 8 ...15: Weight Data	87
7.3.10	Register 22 ... 27: Limit Values (Read/Write)	87
7.3.11	Register 30, 31: Fixed Values (Read/Write)	88
7.3.12	Register 80 ... 89: State-Controlled Action Bits (Write)	88
8	Global SPM Variables	89
9	Configuration Print-Out	91
10	Repairs and Maintenance	92
10.1	Solder Work.....	92
10.2	Cleaning.....	92
11	Disposal.....	92
12	Specifications	93
12.1	Instructions for Use of 'Free Software'.....	93
12.2	General Data.....	94
12.2.1	Power Supply	94
12.3	Effect of Ambient Conditions.....	94
12.3.1	Environmental Conditions	94
12.3.2	Electromagnetic Compatibility (EMC)	94
12.3.3	RF Interference Suppression	94
12.4	Weighing Electronics.....	95
12.4.1	Load Cells	95
12.4.2	Principle	95
12.4.3	Accuracy and Stability	95
12.4.4	Sensitivity	95
12.5	Mechanical Data	96
12.5.1	Construction	96
12.5.2	Dimensions	96
12.5.3	Weight	96
12.6	Use in Legal-for-Trade Mode	96
12.6.1	Documentation for Verification on the Enclosed CD	96
12.6.2	Additional Instructions	96
13	Index	97

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*