

# **NCR RealScan 7802 Price Verifier**

Release 1.0

## **User Guide**



497-0425530

Issue I

---

# Table of Contents

## **Chapter 1: Introduction**

What's in this Manual .....	1-11
NCR RealScan 7802 Configurations.....	1-12
The RealScan 7802 Description .....	1-14
Technical Knowledge Required .....	1-15
Installation .....	1-15
Operation .....	1-15
Application Program Interface (API).....	1-15
Technical Assistance.....	1-15
Service Responsibility .....	1-16

## **Chapter 2: Hardware Installation**

Items Shipped with the RealScan 7802.....	2-1
Mounting the RealScan 7802 .....	2-2
Mounting to a Wall .....	2-2
Mounting to Column.....	2-3
Mounting to a Pole.....	2-3
Mounting to a Stand.....	2-4
Wiring the RealScan 7802.....	2-5
Wiring the Ethernet Model .....	2-5
Wiring the RF Wireless Model.....	2-6
Entering the ESS ID .....	2-6
Load the ESS ID as follows.....	2-6
Setting up a Wireless RF Link.....	2-7
Adding a Serial Printer .....	2-7
Wiring and Configuring the Serial Port.....	2-8
Sending Data to the Printer.....	2-8
Wiring Precautions .....	2-9

## **Chapter 3: Software Installation**

Introduction .....	3-1
Server Install .....	3-1
Unit Configuration.....	3-2
NCR RealScan 7802 Software Updates.....	3-2
V3.XX Software .....	3-2
V4.XX Software .....	3-2

---

**Chapter 4: Network Configuration**

Introduction .....	4-1
Network Activity .....	4-1
NCR RealScan 7802 Configuration .....	4-3
Quick Start .....	4-3
Configuration Information Screens.....	4-3
UnitConfig Program .....	4-5
Using Unit Configuration.....	4-6
Configuration Rules.....	4-7
WEP Network Security .....	4-8
WEP Types .....	4-8
WEP Description .....	4-8
Setting WEP.....	4-8
Before You Start.....	4-8
Procedure.....	4-9
Network Diagnostics .....	4-10
Diagnostic Configurations .....	4-10
Diagnostic Screens and Messages .....	4-10
Internal Error.....	4-11
Transfer Error .....	4-11
Data Transfer .....	4-11
File Unavailable.....	4-11
No Attribute.....	4-11
Connect Error.....	4-11
Connect Fail .....	4-11
Connect Timeout .....	4-11
Refused.....	4-12
Logon.....	4-12
Protocol Fail .....	4-12
Share Unavailable.....	4-12
Host Resolution .....	4-12
Transfer .....	4-12

**Chapter 5: Interfacing to the Back Office Server**

Overview .....	5-2
Software Developers Kit (SDK) .....	5-2
ProductInfo Protocol Description .....	5-2
Protocol Implementation Rules .....	5-4
NCR RealScan 7802 Implementation Rules .....	5-5
NCR RealScan 7802 Supported Modes .....	5-6
Fixed Unit Identification.....	5-6

---

BuildInfo .....	5-6
ProductName .....	5-6
Serialnumber .....	5-6
User Configurable Unit identification .....	5-6
UnitID .....	5-6
UnitIP .....	5-6
Unitmask .....	5-6
GatewayIP .....	5-6
UserName .....	5-6
Password .....	5-6
Setup for Windows Networking (SMB) .....	5-7
Domain .....	5-7
DNS .....	5-7
NetworkName .....	5-7
WINSServerIP .....	5-7
WindowsServ .....	5-7
ShareName .....	5-7
RealScan 7802 FTP Server Configuration .....	5-7
FTPUserName .....	5-7
FTPPassword .....	5-7
FTPSuperName .....	5-7
FTPSuperPwd .....	5-7
Setup for FTP, QFX, NTP, PRODUCTINFO .....	5-8
ServerType .....	5-8
FTPServerIP .....	5-8
QFXPort .....	5-8
QFXServer .....	5-8
QFXTimeout .....	5-8
NTPHost .....	5-8
NTPTZOffset .....	5-8
SloppiIP .....	5-8
SloppiPort .....	5-8
SloppiTimeout .....	5-8
Product Query configuration .....	5-9
IgnoreAckNak .....	5-9
IgnoreResponseChars .....	5-9
QueryPadTo .....	5-9
QueryPrefix .....	5-9
SendError .....	5-9
SendResponse .....	5-9
SendUnitID .....	5-9

---

Trivialcomm .....	5-9
Presentation configuration .....	5-9
TextCols .....	5-9
TextRows.....	5-9
TextHPos .....	5-10
TextVPos .....	5-10
TextBackgnd .....	5-10
TextForegnd .....	5-10
TextDisplay .....	5-10
FontFile .....	5-10
MsgChecking.....	5-10
MsgUnavail .....	5-10
POStimeout .....	5-10
ShowShortPoll.....	5-10
ShowLongPoll .....	5-11
TextTransparent.....	5-11
Multiple Windows .....	5-11
Showtime.....	5-11
DelayNextImage.....	5-11
@ x,y .....	5-11
Real Time Clock Display.....	5-11
ClockFontFile.....	5-11
ClockHPos.....	5-11
ClockVPos.....	5-11
Clock_Fcolor .....	5-11
Clock_Bcolor.....	5-11
ClockFormat.....	5-12
ScanShowClock.....	5-12
ClockTransparent .....	5-12
Miscellaneous configuration.....	5-12
DateTime .....	5-12
EventEnd .....	5-12
EventStart .....	5-12
WallPaperEvent.....	5-12
User1 .....	5-13
RegisterINI .....	5-13
RegisterStart .....	5-13
DisplaySetup .....	5-13
DisplaySetup2 .....	5-13
DisplayAll .....	5-13
NoBarCodes .....	5-13

---

Version .....	5-13
Diversity .....	5-13
Wireless .....	5-13
FlashHash .....	5-14
WEPEncryption.....	5-14
WEPKeyIndex .....	5-14
WEPKey1, WEPKey2, WEPKey3, WEPKey4.....	5-14
Port2Function .....	5-14
BypassNCRPrefix.....	5-14
ExtCharacterSet.....	5-15
Command modes .....	5-15
Commit.....	5-15
Invalidate .....	5-15
Restart.....	5-15
TextReset.....	5-15
Programmatic Modes.....	5-15
GiveHelpText .....	5-15
Timeout .....	5-16
UnitStatus .....	5-16
QFX Quick File Transfer Protocol.....	5-17
Tokens.....	5-17
INFO.....	5-17
SEND.....	5-17
DIFF .....	5-17
ERRR.....	5-17
INFO exchange .....	5-17
Request .....	5-17
Response.....	5-17
Response.....	5-17
Request .....	5-18
Response.....	5-18
Response.....	5-18
Request .....	5-18
Response.....	5-18
Response.....	5-18
Using Graphics Characters.....	5-19
Using the Touch Screen .....	5-20
Introduction.....	5-20
Touch Screen Description .....	5-20
Configuring Scanvue for Input Devices .....	5-20
General .....	5-20

Enable Multiplexer .....	5-20
Start Event and End Event Masks .....	5-21
Touch Screen .....	5-21
Data Bytes (Parameters) .....	5-21
Structure of EVNT packet .....	5-21
Example (shown in hexadecimal form).....	5-22
New Touch Screen Modes.....	5-22

### **Chapter 6: RealScan 7802-2000 Vacuum Fluorescent Display**

Description .....	6-1
Operation.....	6-2
Text Slideshow .....	6-2
Changing Character Sets.....	6-2
Customer Messages .....	6-3
Changing Messages.....	6-3
Creating Customer Messages on VF Display Models .....	6-4
Network Messages.....	6-5
Example 1:.....	6-6
Example 2:.....	6-7
Greeting Message .....	6-8

### **Chapter 7: Programming the RealScan 7802-3000**

NCR 7802-3000 Programming Bar Code Tags.....	7-2
CONFIGURATION DEFAULT .....	7-2
LABEL IDENTIFIER.....	7-2
SAVE CONFIGURATION AND RESET .....	7-3
SET RS-232 PARAMETERS (BAUD RATE) .....	7-3
SET RS-232 PARAMETERS (PARITY).....	7-4
SET RS-232 PARAMETERS (STOP / BIT).....	7-4
SET RS-232 PARAMETERS (RTS / CTS) .....	7-6
SET RS-232 PARAMETERS (BCC) .....	7-7
SET RS-232 PARAMETERS (PREFIX) .....	7-7
SET RS-232 PARAMETERS (TERMINATOR).....	7-8
HEX CODES (0 to 9) .....	7-8
HEX CODES (A to F) .....	7-10
FONT SETS.....	7-11

### **Chapter 8: Using the Touch Screen**

Introduction .....	8-1
Touch Screen Description.....	8-1
Configuring Scanvue for Input Devices.....	8-2

General.....	8-2
Enable Multiplexer .....	8-2
Start Event and End Event Masks.....	8-2
Touch Screen .....	8-2
Data Bytes (Parameters) .....	8-2
Structure of EVNT packet .....	8-3
Example (shown in hexadecimal form) .....	8-3
New Touch Screen Modes.....	8-3

### **Chapter 9: Frequently Asked Questions**

### **Chapter 10 Troubleshooting**

Audible Indicators.....	10-1
Troubleshooting Flow Charts .....	10-1

### **Appendix A: Configuring with Barcodes**

Barcode Reader Settings .....	A-1
Recommended Scanner Settings.....	A-1
Configuring the NCR RealScan 7802.....	A-1

### **Appendix B: NCR RealScan 7802 Initialization File**

Overview .....	B-1
Real Time Clock.....	B-2
Rules for the realscan.ini File .....	B-2
Sections & Commands.....	B-3
Example of Initialization File.....	B-6

### **Appendix C: Creating a Slideshow**

Introduction .....	C-1
Creating a Slideshow File .....	C-1
Using Multiple Graphic Windows .....	C-1
Rules .....	C-2
Section & Commands .....	C-2
Multiple Windows Commands.....	C-3
Example of Slideshow File.....	C-3
Example 1 .....	C-3
Example 2.....	C-5

### **Appendix D: Font and Language Sets**

Graphics (TFT) Display Models .....	D-1
Vacuum Fluorescent (V) Display Models .....	D-2



**Appendix E: ProductInfo Protocol**

Introduction .....	E-1
Protocol Types .....	E-1
Symmetry.....	E-1
Errors .....	E-2
Status Requests .....	E-2
Client Mode Changes.....	E-2
Packet Types .....	E-3
Nominal Mode Packets.....	E-3
General .....	E-3
Terminate Connection .....	E-3
Capability Query .....	E-3
Capability Response .....	E-4
Mode Set/Query .....	E-4
Mode Response .....	E-4
Error Report.....	E-5
Product Query.....	E-6
Data .....	E-6
Registration .....	E-6
Event.....	E-7
Client Requirements .....	E-8
Capabilities .....	E-8
Modes .....	E-8

**Appendix F: Mounting Bracket Outlines****Appendix G: Application Notes**

Wallpaper .....	G-1
Description.....	G-1
Creating Wallpaper .....	G-2
Using Wallpaper .....	G-3
Text Over Graphics (Mixed Mode) Operation.....	G-4
Default Text Setting.....	G-4
Single TIB.....	G-4

**Appendix H: Regulatory Information**

Safety Warnings.....	H-1
Servicing.....	H-1
Fuse Replacement.....	H-1
Power Supply Cord Used as Disconnect Means .....	H-1
Grounding Instructions.....	H-1

Radio Frequency Interference Statements .....	H-2
Federal Communications Commission (FCC) .....	H-2
Information to User .....	H-2
Wireless Units .....	H-2
Canadian Department of Communications .....	H-2
Wireless Units .....	H-3
Voluntary Control Council for Interference (VCCI) .....	H-3
International Radio Frequency Interference Statement .....	H-3
European Union Countries.....	H-3
Laser Safety .....	H-3
Laser Safety Label.....	H-4
Laser Power.....	H-4
Declaration of Conformity.....	H-4

## Revision Record

Issue	Date	Remarks
A	Jun 2002	First Issue
B	Jul 2002	Added Service Responsibility (page 8) and updated Appendix A
C	Sep 2002	Added Serial Printer information
D	Dec 2002	Updated to software version 5.0
E	Jun 2003	Updated Chapter 5, Using the Touch Screen
F	Sep 2003	Updated Chapter 1 Configuration information
G	Oct 2003	Added Chapter 7 Using the Touch Screen
H	Nov 2003	Added Chapter 8 Frequently Asked Questions

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*