




# RealScan 7875 Installation/Owner Guide



16044

497-0001843  
Release K  
March 27, 2003

**Information Products**  
**RSD-Atlanta**

# Contents

- Contents ..... 3
- Revision Record ..... 5
- Obtaining Additional Information ..... 6
- Obtaining Technical Assistance ..... 6
- Scanner Models ..... 7
- Installation Instructions ..... 8
- Step 1 – Verify Checkstand Preparation ..... 9
  - Checkstand Cutout – RealScan 7875-1000/2000 ..... 9
  - Checkstand Cutout – RealScan 7875-3000 ..... 10
  - Checkstand Cutout – RealScan 7875-4000 ..... 11
  - Checkstand Cutout – RealScan 7875-7000/8000 ..... 12
  - Display Clearance ..... 13
  - Service Clearance ..... 13
  - Item Diverter ..... 14
  - Ventilation Requirements ..... 14
  - Electrical Wiring to the Checkstand ..... 15
  - Hole Requirements for Cables ..... 16
- Step 2 – Connect the Cables ..... 17
  - Single Cable Installation ..... 17
  - Dual Cable Installation ..... 18
  - RealScan 7875-7000/8000 ..... 19
  - Bizerba Scale Installation ..... 20
  - Sensormatic Antenna ..... 21
  - RS-232 Peripheral Cables ..... 22
  - Power Supply Location ..... 22
- Step 3 – Install RealScan 7875 in Checkstand ..... 23
  - Set the Communications Protocol Switch ..... 23
  - Installing the RealScan 7875 into the Checkstand Cutout ..... 24
  - Align the RealScan 7875 to the Checkstand ..... 24
  - Set Scale AC Voltage Frequency ..... 25
- Step 4 – Calibrate the Scale ..... 26
  - Exercise the Scale ..... 26
  - Access the Calibration Switch ..... 27
  - Calibrate the Scale ..... 29
  - Verify the Calibration ..... 29
  - Secure the Calibration Switch ..... 31
- Step 5 – Set Program Parameters ..... 32
  - Setting the Program Parameters ..... 32
  - Determining the Communication Protocol ..... 33
  - Reduced Space Symbology ..... 34
  - Sensormatic Deactivation System ..... 36

Step 6 – Check the Scanner Operation .....	38
Scan Sample Tags.....	38
Check Sensormatic Deactivation System.....	39
Operating the Scanner.....	40
Operating the Scale.....	41
Operating the Sensormatic Deactivation System .....	42
Normal Operation.....	42
Manual Deactivation .....	42
Cleaning the RealScan 7875 .....	43
Correcting Scanner Problems.....	44
Correcting Scale Problems.....	45
Isolating Bizerba Scale Problems .....	45
Isolating Sensormatic Problems .....	46
Voice Messages.....	46
Tones.....	46
Programming Worksheets.....	47
1 0 – Communications Protocol.....	47
1 1 – Good Read Tone.....	48
1 2 – Timers.....	48
1 3 – Bar Codes - 1.....	49
1 4 – Bar Codes - 2.....	51
1 5 – Bar Codes - 3.....	52
1 7 – Bar Codes - 4.....	53
1 8 – Bar Codes - 5.....	53
1 6 – Label Identifiers.....	54
2 0 – RS-232 Parameters - 1 .....	55
2 1 – RS-232 Parameters - 2 .....	56
2 2 – RS-232 Prefix Byte.....	57
2 3 – RS-232 Terminator Byte.....	57
2 4 – RS-232 Communications Options .....	58
3 0 – Scale Parameters.....	58
3 2 – Miscellaneous Parameters.....	59
3 6 – Dual Cable Interface Options .....	60
ASCII Code Chart .....	61
Regulatory Information.....	62
Federal Communications Commission (FCC) Radio Frequency Interference Statement.....	62
Voluntary Control Council for Interference (VCCI) Radio Frequency Interference Statement.....	62
Canadian Department of Communications Radio Frequency Interference Statement	62
Scale Regulatory .....	63
Declaration of Conformity.....	64
Laser Safety.....	65
Laser Safety and Name Plate Labels .....	65

Laser Module Label .....	65
IEC Class 1 Laser Identification .....	66
Laser Power .....	66

## Revision Record

Date	Issue	Pages	Remarks
09/30/1996	A	1 through 64	First Printing
12/10/1997	B	All	Complete Revision
07/09/1998	C	5	Added 7875-3000 Information
11/23/1998	D	6	Added 7875-3000 Cutout Drawing
		10	Added Hole Requirements for Cables
		11, 12	Added 7825 Compact Display
2/19/1999	E	17-21	Modified Scale Calibration
11/9/1999	F	30, 32, 35, 36	Updated Programming Parameters
10/08/2001	G	8, 15, 20, 32, 44	Added 7875-4005 Information
12/17/2002	H	All	Added Super ASIC and 7875-7000/8000 Information
02/14/2003	J	All	Modified Entire Document
03/27/2003	K	53	Added Worksheet 18 - Bar Codes - 5

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/NCR/7875 installation and owner manual.html](https://the-checkout-tech.com/manuals/NCR/7875%20installation%20and%20owner%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)