

ELECTRONIC CASH REGISTER

200CR

OPERATOR'S INSTRUCTION MANUAL



Contents

Introduction	2
Unpacking the register	2
Getting Started	6
Remove the cash register from its box	6
Remove the tape holding parts of the cash register in place	6
Install the three memory backup batteries	6
Plug the cash register into a wall outlet	6
Insert the mode key marked "PGM" into the Mode Switch	6
Turn the mode key to the "REG" position	6
Install receipt/journal paper	6
To load 1-ply paper for printing of receipts	6
To load 1-ply paper for printing of journal	6
To load 2-ply paper for printing of receipts	6
Set the date	6
Set the time	6
Select printouts receipt or journal	6
Tax table programming	6
Programming automatic tax calculation	6
Programming tax calculations (without special rounding)	6
Programming tax calculations (with special rounding)	6
Introducing 200CR	1
General guide	1
Mode key	1
Displays	1
Drawer, Mode switch	1
Keyboard	1
Basic Operations and Setups	2
How to read the printouts	2
How to use your cash register	2
Displaying the time and date	2
Preparing coins for change	2
Preparing and using department keys	2
Registering department keys	2
Programming department keys	2
Registering department keys by programming data	2
Preparing and using PLUs	2
Programming PLUs	2
Registering PLUs	2
Preparing and using discounts	2
Programming discounts	2
Registering discounts	2

Preparing and using reductions	32
Programming for reductions	32
Registering reductions	33
Registering charge and check payments	34
Registering returned goods in the REG mode	35
Registering returned goods in the RF mode	36
Registering money received on account	37
Registering money paid out	37
Making corrections in a registration	38
No sale registration	40
Printing the daily sales RESET report	41
Convenient Operations and Setups	42
About the clerk control function	42
About post-finalization receipt	43
Programming general printing control	44
Programming READ/RESET report printing control	45
Programming compulsory, clerk control function and other features	46
Setting/editing the store telephone number	47
Setting a store/machine number	48
High digit limitation for departments	49
Single-item-sales for departments and PLUs	50
Registering discounts and premiums	53
Other programmable options	55
Calculator functions	56
Printing READ/RESET reports	58
Printing the cash register's program	64
Troubleshooting	66
When an error occurs	66
When the register does not operate at all	67
In case of power failure	68
When the L sign appears on the display	68
User Maintenance and Options	69
To replace the ink ribbon	69
To replace journal paper	70
To replace receipt paper	71
Options	71
Specifications	72
Index	73

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)