


SERVICE MANUAL

(without price)

ELECTRONIC CASH REGISTER

TK-T500 (EX-579A*)

APR. 2000



Printer Model : LTP4242B-C432

CASIO®

CONTENTS

TK-T500	Page
1. SPECIFICATIONS	1
2. INITIALIZE (MAC) OPERATION	4
3. F-INIT (FMAC) OPERATION	4
4. BLOCK DIAGRAM	5
5. TO OPEN THE UPPER CASE	7
6. CIRCUIT EXPLANATION	9
6-1. Power supply circuit	9
6-2. Reset and power down circuit	10
6-3. CPU description	11
6-4. Memory chip selection circuit	13
6-5. Flash ROM1 address circuit	14
6-6. Flash ROM2 circuit	14
6-7. Flash Pack circuit (Memory Cassette RAC-9)	15
6-8. Memory map	16
6-9. Printer drive circuit	17
6-10. RS232C port COM1 circuit	17
6-11. RS232C port COM2 and COM3 circuit	18
6-12. Keyboard selection switch	19
6-13. To mount optional circuit	19
1) Clerk key circuit	19
2) Multi-drawer circuit	21
3) Paper near end sensor circuit	22
6-14. Display controller uPD78015FGC526-AB8	23
6-15. Segment display driver uPD16312GB-3B4	24
6-16. DC/DC convertor circuit	25
6-17. ARCNET circuit (IO-PB14)	25
7. DIAGNOSTIC OPERATION	31
7-1. To start the diagnostic program	31
7-2. Check item	31
7-3. Operation of each test	31
7-4. Switch status test	32
7-5. Individual function test	33
7-6. To exit the diagnostic mode	49
8. ERROR CODE LIST	50
9. IC DATA	53
10. PCB LAYOUT	67
11. CIRCUIT DIAGRAM	69
12. PARTS LIST	93

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/cashregisters/Casio_TK-T500_service_manual.html

Checkout our free online Keysheet Maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

THE-CHECKOUT-TECH.COM