


# NCR RealPOS™ 5953 PS/2 DynaKey™

Release 1.0

## User Guide



B005-0000-1161  
Issue C

---

# Table of Contents

## Chapter 1: Overview

Compatibility .....	1-1
Features .....	1-2
Wedge Controller.....	1-3
Decoded Scanner.....	1-4
Multi-Color Power LED.....	1-4
LCD Contrast Control .....	1-5
Keylock Positions .....	1-5
External Standard PC Keyboard Connector .....	1-6
Special “PC Setup” Keypad Layout.....	1-6
Three-Track MSR or Two-Track JIS MSR.....	1-6
Speaker .....	1-6
Integrated 2 x 20 Customer Display .....	1-7

## Chapter 2: Site Preparation

Physical Environment .....	2-1
Operating Range.....	2-1
Storage Range .....	2-1
Transit Range .....	2-1
Electrical Environment .....	2-2
Power Consumption .....	2-2
Cable Length Limitations .....	2-2
Dimensions .....	2-3

## Chapter 3: Installation

Introduction .....	3-1
Serial Number Location.....	3-2

Connector Panel Access.....	3-2
Mounting Options .....	3-2
Installing the 5953 .....	3-4
Installing a Remote Table Top Mounted 5953 DynaKey (5953-F022).....	3-4
Installing an Integrated Customer Display (5972-F039) .....	3-5
Installing a Wall Mounted 5953 DynaKey (7401-K533) .....	3-10
Installing a Checkstand-Mounted 5953 DynaKey .....	3-11
Installing a 5953-K023 Checkstand Mount.....	3-12
Installing a 5953-K023 Checkstand Mount.....	3-16
Installing the Integrated Customer Display (7454-K451) .....	3-17
Connecting the 5953 DynaKey to the Host.....	3-19
Installing the PCI LCD Card (5953-K152).....	3-19
Powering Up .....	3-22
Special Keypad Mode.....	3-22
Normal Operating Mode .....	3-25
Screen Saving Feature.....	3-26

#### **Chapter 4: Programming**

Software Drivers and Utilities.....	4-1
MicroTouch Touch Screen Drivers and Utilities.....	4-1
12.1-Inch DynaKey Video Drivers .....	4-2
Device Interfaces .....	4-3
Wedge Controller Interface.....	4-3
Touch Screen Interface .....	4-4
Analog MSR Interface.....	4-4
RS-232 Interface .....	4-5
PS/2 Keyboard Interface.....	4-5
Keyboard Firmware .....	4-5
Command Set.....	4-6
Commands from the Host Workstation to the DynaKey .....	4-7

POS Defaults .....	4-9
Special POS Capabilities.....	4-10
Num Lock Operation.....	4-10
NUM LOCK “OFF” .....	4-11
NUM LOCK “ON” .....	4-11
Cursor Control at the DynaKey.....	4-12
Alt-Control-Delete Protection.....	4-12
Alt-Control-Delete Disabled .....	4-12
Alt-Control-Delete Enabled .....	4-13
Calculator or Telephone Numeric Pad Layout .....	4-14
Detection of Double High/Wide Keys.....	4-15
Auto Detection of Double High/Wide Key Mode (default) ..	4-15
Blocking Key Locations .....	4-16
NCR POS-Compatible Double High/Wide Key Configuration Mode.....	4-17
Keyboard Options Command EA.....	4-17
Double High/Wide Keys.....	4-18
Double Key Error Detection.....	4-19
First Byte = Command Byte (EA Hex) .....	4-19
Second Byte = Parameter Byte 1 (Blocking Keys, Keypad, Double Key Error Detection) .....	4-19
Third Byte = Parameter Byte 2 (Blocking Keys) .....	4-20
Fourth Byte = Parameter Byte 3 = (Blocking Key Pairs).....	4-21
Fifth Byte = Parameter Byte 4 (Blocking Key Pairs).....	4-21
Keyboard Part Number/Type Command (EC Hex) .....	4-22
Key Position Diagram.....	4-23
Panel OFF/ON Sequence.....	4-25
PCI LCD Board (69000 Chips) .....	4-25

## **Chapter 5: Service and Repair**

Safety Requirements.....	5-1
--------------------------	-----

Problem Isolation Procedures.....	5-2
Troubleshooting Table.....	5-2
Servicing the DynaKey Module.....	5-8
Touch Screen Cleaning Procedures .....	5-8
Service Procedures.....	5-9
Servicing the DynaKey .....	5-9
Internal Components .....	5-12
Replacing the MSR.....	5-12
MSR Cleaning Cards.....	5-13
Replacing the DynaKey Controller Board .....	5-14
Replacing the Inverter Board.....	5-16
Replacing the Speaker Assembly .....	5-17
Replacing the LCD Bracket Assembly .....	5-18
Replacing the Keypad.....	5-18
Replacing the Touch Screen.....	5-19
Replacing the Keylock Adaptor Assembly.....	5-20
Re-Assembling the DynaKey .....	5-20
Connector Pin-Out Information .....	5-21
External Keyboard Connector .....	5-21
External RS-232 Scanner Connector .....	5-21
Spare Parts List.....	5-22
DynaKey Cleaning Procedures .....	5-25
Cleaning the Glass .....	5-25

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ncr/5953 user manual.html](https://the-checkout-tech.com/manuals/ncr/5953%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)