

SHARP[®]

**ELECTRONIC CASH REGISTER
CAISSE ENREGISTREUSE ELECTRONIQUE**

MODEL
MODELE **ER-A320**

INSTRUCTION MANUAL

MANUEL D'INSTRUCTIONS



CAUTION

The socket-outlet shall be installed near the equipment and shall be easily accessible.

ATTENTION

La prise de courant murale devra être installée à proximité de l'équipement et être facilement accessible.

INTRODUCTION

Thank you very much for your purchase of the SHARP Electronic Cash Register, Model ER-A320. Please read this manual carefully before operating your machine in order to gain a full understanding of its functions and features.

Please keep this manual for future reference. It will help you if you encounter any operational problems.

IMPORTANT

- **Install your cash register in a location that is not subject to direct radiation, unusual temperature changes, or high humidity or exposed to water sources.**
Installation in such locations could cause damage to the cabinet and the electrical components.
- **The register should not be operated by an individual with wet hands.**
The water could seep into the interior of the register and cause component failure.
- **When cleaning your register, use a dry, soft cloth. Never use solvents, such as benzine and thinner.**
The use of such chemicals will lead to discoloration or deterioration of the cabinet.
- **The register plugs into any standard wall outlet (local voltage $\pm 10\%$ AC).**
Other electrical devices on the same electrical circuit could cause the register to malfunction.
- **If the register malfunctions, call your local dealer for service - do not try to repair the register yourself.**
- **For a complete electrical disconnection, pull out the mains plug.**

PRECAUTION

This Electronic Cash Register has a built-in memory protection circuit which is operated by a rechargeable battery pack.

It should be known that all batteries will, in time, dissipate their charge even if not used. Therefore to insure an adequate initial charge in the protection circuit and to prevent any possible loss of memory upon installation, it is recommended that each unit be allowed to be recharged for a period of 24 to 48 hours prior to use by the customer.

In order to charge the battery pack, the machine must be plugged in and its power switch must be set to the "ON" position. This recharging precaution can prevent unnecessary initial service calls.

CONTENTS

INTRODUCTION	1
IMPORTANT	1
PRECAUTION	1
EXTERNAL VIEW	6
Front view	6
Rear view	6
Drawer lock key	6
KEYBOARD	7
Standard keys	7
Optional keys	8
MODE SWITCH AND MODE KEYS	8
DISPLAYS	9
Machine state symbols	9
BEFORE OPERATING THE CASH REGISTER	10
1. Installing the cash register	10
2. Preparing the paper roll and the ink roller	10

FOR THE OPERATOR

PRIOR TO ENTRIES	12
1. Preparations for entries	12
Receipt and journal paper rolls	12
2. Error warning	12
Error escape function	12
ENTRIES	13
1. Item entries	13
Single item entries	13
Repeat entries	14
Multiplication entries	15
Split-pricing entries	16
Single item cash sale (SICS) entries	17
2. Display of subtotals	17
Merchandise subtotal	17
Taxable subtotal	17
Including-tax subtotal (full subtotal)	17
3. Finalization of transaction	18
Cash or check tendering	18
Mixed tendering (check + cash)	18
Cash or check sale that does not need any tender entry	19
Charge (credit) sale	19
Mixed-tender sale (cash or check tendering + charge tendering)	19
4. Tax calculations	20
Automatic tax	20
Manual tax	20
Automatic-tax delete	20
Tax status shift	21
5. Auxiliary entries	21
Percent calculations (premium or discount)	21
Discount entries	22
Refund entries	23
Printing of non-add code numbers	23

6. Payment treatment	24
Currency conversion	24
Received on account entries	24
Paid out entries	25
No sale (exchange)	25
Cashing a check	25
7. Automatic sequencing key (entries	25
CALCULATION MODE	26
Basic calculations	26
Using the memory key	26
CORRECTION	27
1. Correction of the last entry (direct void)	27
2. Correction of the next-to-last or earlier entries (indirect void)	27
3. Subtotal void	28
4. Correction of incorrect entries not handled by the direct or indirect void function	28
CORRECTION AFTER FINALIZING A TRANSACTION	29
OVERRIDE ENTRIES	29
SPECIAL PRINTING FUNCTIONS	30
1. Receipt issuance after finalization	30
2. Validation printing function	30
Validation slip setting and printing	30
Validation printing examples	31
Validation slip specification	32
3. Printing of the employee arrival and departure times	32
 FOR THE MANAGER	
PROGRAMMING	33
 Direct Programming	33
1. Setting the date, time, and consecutive number	33
Date	33
Time	33
Consecutive number	34
2. Programming for departments	34
Unit price	34
Functional selection	35
3. Price lookup (PLU) programming	37
Unit price	37
Functional selection	37
PLU assignment to departments	39
4. Programming for discount keys	40
Discount amount ()	40
High amount lockout (HALO) and tax status ()	41
5. Programming for percent keys	42
Percent rate ()	42
Sign (+/-) and tax status ()	42
6. Programming for conversion keys	43
Currency conversion rate ()	43
7. Programming for the , , , , , and keys	43
High amount lockout (HALO) (, , , , , and)	43
 Job-Code-Based Programming	44
1. Setting the date and time	44
Date (#2610, Direct)	44
Time (#2611, Direct)	44

2. Setting the register and consecutive numbers	44
Register number (#2612)	44
Consecutive number (#2613, Direct)	44
3. Programming for the automatic tax calculation function	45
Tax table (applicable to the add-on tax)(#2710)	45
Tax rate (#2711).....	46
4. Programming for departments	46
Unit price (#1110, Direct)	46
Functional selection 1 (#2111, Direct).....	47
Limit amount (HALO) (#2112, Direct).....	47
Functional selection 2 (#2110)	47
Group number (#2116).....	48
5. Price lookup (PLU) programming	48
PLU assignment to departments (#1200, Direct)	48
Unit price (#1210, Direct)	48
Functional selection (#2210, Direct).....	49
6. Programming for the miscellaneous keys.....	49
Rate and discount amount (%, CONV, and ⊖) (#1310, Direct)	49
Limit amount (HALO) (⊖, TAX, RA, and PO) (#2312, Direct).....	50
Sign (+/-) and tax status (%, ⊖) (#2311, Direct)	50
7. Programming for the media keys.....	50
High amount lockout (HALO) for media keys (#2322, Direct)	50
Functional selection (#2320)	51
High amount lockout (HALO) for check change, check cashing, and cash in drawer (#2321)	51
8. Programming various functions	52
Optional feature selection (#2616)	52
Setting the time limit for THE TILL TIMER™ (#2617)	53
Setting the AUTO key - Automatic sequencing key (#2900)	53
9. Activating and deactivating the TRAINING mode.....	54
TRAINING-mode activation/deactivation (#2910, 2911)	54
TRAINING-mode operations	55
10. Reading stored programs	55
Program details and procedures for their reading	55
Sample printouts	56
READING (X) AND RESETTING (Z) OF SALES TOTALS	58
1. Summary of reading (X) and resetting (Z) reports and the key operations to obtain the reports	58
2. Daily sales totals	59
Full report	59
Hourly report	61
Full department report	61
Individual group report	62
PLU report	62
PLU by associated department report	62
Transaction report	62
3. Periodic consolidation.....	63
Full report	63
Daily net report	63
MAINTENANCE	64
1. In case of power failure	64
2. In case of printer's motor locking	64
3. Installing and removing the paper roll.....	65
Installing the paper roll	65

Removing the paper roll	65
Removing a paper jam	66
Recording paper specifications	66
4. Replacing the ink roller	67
5. Ink refill	68
6. Removing the till and the drawer	69
7. Opening the drawer by hand	69
8. Before calling for service	69
LIST OF OPTIONS	70
SPECIFICATIONS	71

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/sharp/ER-A320 instruction manual.html>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)