Samsung SRP-275 service Manual





# **SERVICE MANUAL** SRP-275

# IMPACT PRINTER



## All specifications are subjected to change without notice

www.samsungminiprinters.com

#### Precautions

Safety precautions i Servicing Precautions ii Precautions for electrostatically sensitive devices (ESDs) iii	Introc	duction ·····	iii
		Servicing Precautions	ii

# Table of contents

#### Chapter 1 Specifications

1.1	General specifications	1-1
1.2	Appearance	1-2
	1.2.1 Printer dimensions(mm) and Weight	1-2
	1.2.2 AC adapter dimensions (mm)	1-2
	1.2.3 Feature locations	1-3
1.3	Reference information	1-4
	1.3.1 Printer mechanism specifications	1-4
	1.3.2 Printing specifications	1-4
	1.3.3 Character specifications	1-5
	1.3.4 Paper specifications	1-7
	1.3.5 Ribbon cassette specifications	1-8
	1.3.6 Environment conditions	1-8
	1.3.7 Reliability	1-9
	1.3.8 Certification	1-9
	1.3.9 Printer(SMP715) pin descriptions	1-10
	1.3.10 Printer head specifications	1-11
	1.3.11 Printer head thermistor specifications	1-11
	1.3.12 PF(Paper Feed) motor specifications	1-12
	1.3.13 HF(Head Feed) motor specifications	1-12
	1.3.14 Auto cutter specifications	1-12
	1.3.15 Switch(Sensor) specifications	1-12
1.4	SMPS(AC adaptptor) specifications	1-13
	1.4.1 SMPS (Switching Mode Power Supply) specifications   1.4.2 SMPS output connector	1-13
	1.4.2 SMPS output connector	1-13
1.5	I/F(Interface) specifications	1-14
	1.5.1 RS-232C Serial I/F	1-14
	1.5.1.1 RS-232C Serial I/F specifications	1-14
	1.5.1.2 RS-232C Serial I/F cable ·····	1-14
	1.5.1.3 RS-232C Serial I/F cable connection	1-15
	1.5.1.4 RS-232C Serial I/F signal descriptions	1-15
	1.5.1.5 RS-232C Serial I/F H/W flow control	1-16
	1.5.1.6 RS-232C Serial I/F S/W flow control	1-16
	1.5.2 IEEE 1284 Parallel I/F	
	1.5.2.1 IEEE 1284 Parallel I/F forward mode specifications (Compatibility mode) …	
	1.5.2.2 IEEE 1284 Parallel I/F reverse mode specifications (Nibble/Byte mode)	1-16
	1.5.2.3 IEEE 1284 Parallel I/F signal specifications (Compatibility/ Nibble/ Byte mode) …	1-17
	1.5.2.4 IEEE 1284 Parallel I/F cable ·····	1-17
	1.5.3 USB I/F	1-18
	1.5.3.1 USB I/F specifications	1-18
	1.5.3.2 USB I/F signal description	1-18
	1.5.3.3 USB I/F cable	1-18
1.6	Drawer kick-out specifications	1-19
	1.6.1 Drawer kick-out cable ·····	1-19
	1.6.2 Drawer kick-out cable connection	1-19

#### Chapter 2 Installation and operation

2.1	Connection a	nd Installation	2-1
	2.1.1 Conn	ecting the AC adaptor	2-1
	2.1.2 Conn	ecting the interface cable and drawer kick-out cable	2-1
	2.1.3 Instal	ling the ribbon cassette	2-2
	2.1.4 Instal	ling the paper roll	2-3
	2.1.5 Chan	ging the paper width	2-4
	2.1.6 Instal	ling the wall mount (Option)	2-5
2.2			
		the operation panel	
	2.2.2 ERR0	OR LED blinking pattern	2-7
	2.2.3 Self t	est ·····	2-8
		decimal dumping	
2.3		vitches	
		ig the DIP Switches	
	2.3.1.1	DIP Switch setting for Epson(ESC/POS) mode	
	2.3.1.2	DIP Switch setting for Citizen(iDP3550) mode	
	2.3.1.3	DIP Switch setting for Star(SP500) mode	
	2.3.1.4	Changing the DIP Switches setting	2-14
	2.3.2 Settir	g the Memory Switches	
	2.3.2.1	Memory Switch setting for Epson(ESC/POS) mode	
	2.3.2.2	Memory Switch setting for Star(SP500) mode	2-19

#### Chapter 3 Mechanism operating principles

3.1	Transp	ort mechanism	3-1
	3.1.1		3-1
	3.1.2	Paper feeding system	3-2
	3.1.3	Ribbon feeding system	3-3
	3.1.4		3-3
	3		3-3
3.2	Printing	g mechanism	3-4
3.3	Detecti	on mechanism	3-5
	3.3.1	Home position detection mechanism	
	3.3.2	Paper near end detection mechanism	
	3.3.3	Paper end detection mechanism	3-7
	3.3.4		3-7
	3.3.5	Auto cutter home position detection mechanism	3-8
3.4		utter mechanism	
3.5	Easy pa	aper loading mechanism ······· 3	-10

### Chapter 4 Adjustments

4.1	Mainter	ance	4-1
	4.1.1	Cleaning	4-1
	4.1.2	Inspection	4.1
4.2	Lubrica	nts and adhesive application	4-2
	4.2.1	Eabhdant rogan onnonto	4-2
	4.2.2	Lubricant types	4-2
	4.2.3	Lubrication points	4-2
	4.2.4		4-3
	4.2.5		
	4.2.6	Adhesive application requirements	4-3
4.3	Tools, lu		4-3
	4.3.1		
	4.3.2	List of lubricants and adhesives	4-3
4.4	Adjustm	nents	4-4

#### Chapter 5 Troubleshooting

5.1	Trouble	eshooting flow chart	5-1
	A. PO	OWER LED does not light	5-2
	B. PA	APER LED is lit	5-3
	C. El	RROR LED is blink	5-4
	D. El	RROR LED is lit	5-5
	E. Se	elf test is not normal	5-6
	F. Da	ata from host is not printed normally	5-7
5.2	Trouble	eshooting tables	5-8
	5.2.1	Initialization problems	5-9
	5.2.2	Printing quality problems	5-11
	5.2.3	Printer mechanism problems	5-12
	5.2.4	Auto cut mechanism problems	5-13

#### Chapter 6 Disassembly and assembly

6.1	Disassembly	
6.2	SMP715 Printer mechanism unit assembly	
	6.2.1 SMP715 Printer mechanism unit component parts	6-1
	6.2.2 SMP715 Printer mechanism unit Sub-assembly	6-5
	6.2.3 SMP715 Printer mechanism unit Main-assembly	6-14
6.3	Auto cutter unit assembly	6-20
	6.3.1 Auto cutter unit component parts	6-20
	6.3.2 Auto cutter unit Sub-assembly	
	6.3.3 Auto cutter unit Main-assembly	6-24
6.4	SRP-275 Whole unit assembly	6-25
	6.4.1 SRP-275 Whole unit component parts	6-25
	6.4.2 SRP-275 Whole unit Sub-assembly	
	6.4.3 SRP-275 Whole unit Main-assembly	6-33

#### Chapter 7 Exploded view and parts list

7.1	SMP715A Printer mechanism unit exploded view and parts list	7-1
	7.1.1 SMP715A Printer mechanism unit exploded view	
	7.1.2 SMP715A Printer mechanism unit parts list	
7.2	SMP715C Printer mechanism unit exploded view and parts list	7-5
	7.2.1 SMP715C Printer mechanism unit exploded view	7-5
	7.2.2 SMP715C Printer mechanism unit parts list	7-7
7.3	Auto cutter unit exploded view and parts list	7-9
	7.3.1 Auto cutter unit exploded view	7-9
	7.3.2 Auto cutter unit parts list	7-10
7.4	SRP-275A Whole unit exploded view and parts list	
	7.4.1 SRP-275A Whole unit exploded view	
	7.4.2 SRP-275A Whole unit parts list	
7.5	SRP-275C Whole unit exploded view and parts list	7-15
	7.5.1 SRP-275C Whole unit exploded view	7-15
	7.5.2 SRP-275C Whole unit parts list	7-17

#### Chapter 8 Control commands list

8.2	Explan	and notation ation ation of terms	8-1
8.3	Explan	ation processing	8-2
8.4	Comm	ands for SRP-275 Series	8-3
	8.4.1	Commands list for Epson mode (TM-U220)	8-3
	8.4.2	Commands description for Epson mode (TM-U220)	8-4
	8.4.3	Commands list for STAR mode (SP500)	8-48
	8.4.4	Commands description for STAR mode (SP500)	8-50
	8.4.5	Commands list for CITIZEN mode (iDP3550/3551)	8-77
	8.4.6	Commands description for CITIZEN mode (iDP3550/3551) 8	8-78

C	hapte	er 9 Wiring diagram	
	9.1	Main board wiring diagram Connector sub PCB wiring diagram	· 9-1
	9.2 9.3	CPU pin function	· 9-2
	9.4	I/F connector pin (J6)	· 9-6
C	hapte	er 10 Block diagram	
C	hapte	er 11 PCB layout and parts list	
	11.1	Main PCB	11-1
		11.1.1 Main PCB layout	11-1
	11.2		11-3 11-5
		11.2.1 Connector sub PCB lavout	11-5
	11.3	11.2.2 Connector sub PCB parts list Operation panel PCB	11-5
	11.5	11.3.1 Operation panel PCB layout	11-6
		11.3.2 Operation panel PCB parts list	11-6
	11.4	Head PCB 11.4.1 Head PCB layout ······	11_7
		11.4.2 Head PCB parts list	11-7
	11.5	RS-232C serial I/F PCB	11-8
		11.5.1 RS-232C Serial I/F PCB layout	11-8 11-8
	11.6	11.5.2 RS-232C Serial I/F PCB parts list IEEE 1284 parallel I/F PCB	11-9
		11.6.1 IEEE 1284 parallel I/F PCB layout	11-9
	11.7	11.6.2 IEEE 1284 parallel I/F PCB parts list USB I/F PCB	11-9
		11.7.1 USB I/F PCB layout	11-10
		11.7.2 USB I/F PCB parts list	11-10
C	hapte	er 12 Schematic diagrams	
	12.1	Main circuit diagrams	12-1
	12.2 12.3	Head circuit diagram RS-232C Serial I/F circuit diagram	12-10
	12.3	IEEE 1284 Parallel I/F circuit diagram	12-12
	12.5	USB I/F circuit diagram	12-13
A	ppen	dix A Code Tables	
	A.1	Page 0 (PC437 : USA, Standard Europe (International Character Set : USA))	· A-1
	A.2	Page 1 (Katakana) Page 2 (PC850 : Multilingual)	· A-2
	A.3 A.4	Page 3 (PC860 · Portuguese)	· Δ_4
	A.5	Page 4 (PC863 : Canadian-French)	· A-5
	A.6 A.7	Page 5 (PC865 : Nordic)	· A-6
	A.8	Page 17 (PC866 : Russian)	· A-8
	A.9	Page 18 (PC852 : Latin2)	· A-9
	A.10 A.11	Page 19 (PC858 : Euro) Page 21 (PC862 : Israel)	A-10 A_11
	A.12	Page 22 (PC864 : Arabic)	A-12
	A.13	Page 23 (Thai character code 42)	A-13
	A.14 A.15		A-14 A-15
	A.16	Page 26 (WPC1257 : Baltic)	A-16
	A.17	Page 27 (Farsi)	A-17
	A.18 A.19		A-18 A-19
	A.20	Page 30 (PC775 : Baltic)	A-20
	A.21	Page 31 (Thai character code 16)	A-21
	A.22 A.23		A-22 A-23
	A.24	Page 34 (Thai character code 11)	A-24
	A.25		A-25
	A.26		A-20

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store: https://the-checkout-tech.com/manuals/Samsung/SRP-275 service manual.html

And our free Online Keysheet maker: https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM